



## Section: KANZAKI TRANSAXLE K46AG

| Pos. | Quantity | Spare part No | Description         | Kit | Notes | New |
|------|----------|---------------|---------------------|-----|-------|-----|
|      | K46      |               |                     |     |       |     |
|      | AG       |               |                     |     |       |     |
| 3    | 1        | 1139-1321-01  | Lower housing       |     |       |     |
| 7    | 1        | 1139-1100-01  | Vent valve assy     |     |       |     |
| 8    | 2        | 1139-1150-01  | Magnet              |     |       |     |
| 9    | 1        | 1139-1341-01  | Holder-magnet       |     |       |     |
| 11   | 1        | 1139-1028-01  | Spring              |     |       |     |
| 12   | 1        | 1139-1324-01  | Shaft-bypass        |     |       |     |
| 13   | 1        | 1139-1189-01  | Lever-bypass        |     |       |     |
| 14   | 1        | 1139-1161-01  | Ring                |     |       |     |
| 15   | 1        | 1139-1275-01  | Bore plug           |     |       |     |
| 16   | 1        | 1139-1104-01  | Snap ring           |     |       |     |
| 19   | 2        | 1139-1117-01  | O-ring              |     |       |     |
| 20   | 1        | 1139-1119-01  | Seal                |     |       |     |
| 21   | 2        | 1139-1295-01  | Tapping screw       |     |       |     |
| 22   | 14       | 1139-0244-01  | Tapping screw       |     |       |     |
| 24   | 1        | 1139-1340-01  | Center case assy    |     |       |     |
| 25   | 1        | 1139-1158-01  | Pin                 |     |       |     |
| 26   | 1        | 1139-1334-01  | Filter              |     |       |     |
| 27   | 3        | 1139-1294-01  | Bolt                |     |       |     |
| 28   | 2        | 1139-1339-01  | Valve               |     |       |     |
| 29   | 2        | 1139-1338-01  | Spring              |     |       |     |
| 30   | 2        | 1139-1346-01  | Ball                |     |       |     |
| 31   | 1        | 1139-1159-01  | Cylinder block assy |     |       |     |
| 32   | 1        | 1139-1245-01  | Spring              |     |       |     |
| 33   | 1        | 1139-1308-01  | Pump shaft          |     |       |     |
| 34   | 3        | 1139-1146-01  | Ring                |     |       |     |
| 35   | 1        | 1139-1110-01  | Ball bearing        |     |       |     |
| 36   | 1        | 1139-1157-01  | Housing             |     |       |     |
| 37   | 1        | 1139-1054-01  | Bearing             |     |       |     |
| 38   | 1        | 1139-1139-01  | Cylinder block assy |     |       |     |
| 39   | 1        | 1139-1160-01  | Washer              |     |       |     |
| 40   | 1        | 1139-1247-01  | Motor shaft         |     |       |     |
| 41   | 1        | 1139-1021-01  | Snap ring           |     |       |     |
| 42   | 1        | 1139-1272-01  | Motor gear          |     |       |     |
| 43   | 1        | 1139-1286-01  | Ball bearing        |     |       |     |
| 44   | 2        | 1139-1296-01  | Metal thrust        |     |       |     |
| 45   | 1        | 1139-1067-01  | Swash plate assy    |     |       |     |
| 46   | 1        | 1139-1068-01  | Bearing             |     |       |     |
| 47   | 1        | 1139-1070-01  | Thrust plate        |     |       |     |
| 48   | 1        | 1139-1069-01  | Thrust plate        |     |       |     |
| 49   | 1        | 1139-1315-01  | Control shaft       |     |       |     |
| 50   | 1        | 1139-1316-01  | Fulcrum             |     |       |     |
| 51   | 1        | 1139-1312-01  | Spring              |     |       |     |
| 52   | 1        | 1139-1314-01  | Control arm         |     |       |     |
| 53   | 1        | 1139-1325-01  | Control lever       |     |       |     |
| 54   | 1        | 1139-1250-01  | Jerky plate         |     |       |     |
| 55   | 1        | 1139-1102-01  | Washer              |     |       |     |
| 56   | 1        | 1139-1327-01  | Pin                 |     |       |     |
| 57   | 1        | 1139-1329-01  | Pin                 |     |       |     |
| 58   | 1        | 1139-1285-01  | Pin                 |     |       |     |
| 59   | 2        | 1139-1115-01  | O-ring              |     |       |     |
| 60   | 1        | 1139-1127-01  | Nut                 |     |       |     |
| 61   | 1        | 1139-1162-01  | Differential gear k |     |       |     |
| 62   | 1        | 1139-1258-01  | Final gear          |     |       |     |
| 63   | 1        | 1139-1255-01  | Collar              |     |       |     |
| 64   | 1        | 1139-1256-01  | Reduction shaft     |     |       |     |
| 65   | 2        | 1139-1257-01  | Washer              |     |       |     |
| 66   | 1        | 1139-1267-01  | Reduction gear      |     |       |     |
| 67   | 1        | 1139-1259-01  | Final pinion        |     |       |     |
| 68   | 1        | 1139-1342-01  | Axle shaft-left     |     |       |     |
| 69   | 1        | 1139-1343-01  | Axle shaft-right    |     |       |     |
| 70   | 2        | 1139-1078-01  | Thrust washer       |     |       |     |
| 71   | 2        | 1139-1163-01  | Ring                |     |       |     |
| 72   | 2        | 1139-1080-01  | Seal                |     |       |     |
| 73   | 2        | 1139-1164-01  | Bushing             |     |       |     |
| 75   | 1        | 1139-1260-01  | Brake shoe          |     |       |     |
| 76   | 1        | 1139-1261-01  | Brake arm           |     |       |     |

## Section: KANZAKI TRANSAXLE K46AG

| Pos. | Quantity | Spare part No | Description    | Kit | Notes | New |
|------|----------|---------------|----------------|-----|-------|-----|
|      | K46      |               |                |     |       |     |
|      | AG       |               |                |     |       |     |
| 77   | 1        | 1139-1320-01  | Brake shaft    |     |       |     |
| 78   | 1        | 1139-1263-01  | Return spring  |     |       |     |
| 79   | 1        | 1139-1264-01  | Brake actuator |     |       |     |
| 80   | 1        | 1139-1282-01  | Pin            |     |       |     |
| 81   | 2        | 1139-1114-01  | O-ring         |     |       |     |
| 82   | 2        | 1139-1281-01  | Pin            |     |       |     |
| 83   | 2        | 1139-1248-01  | Spline collar  |     |       |     |
| 84   | 1        | 1139-1309-01  | Pulley         |     |       |     |
| 85   | 1        | 1134-4190-01  | Fan            |     |       |     |
| 86   | 1        | 1139-1266-01  | Lock washer    |     |       |     |
| 87   | 1        | 1139-1149-01  | Snap ring      |     |       |     |
| 89   | 1        | 1139-1337-01  | Upper housing  |     |       |     |
| 90   | 1        | 1139-1280-01  | Pin            |     |       |     |
| 91   | 1        | 1139-1303-01  | Oil seal       |     |       |     |
| 95   | 1        | 1139-1279-01  | Pin            |     |       |     |
| 99   | 2        | 1139-1103-01  | Seal washer    |     |       |     |
| 100  | 2        | 1139-1123-01  | Bolt           |     |       |     |

test