



Section: KANZAKI TRANSAXLE K46G

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
K46G						
3	1	1139-1321-01	Lower housing			
5	1	1139-1301-01	Tube			
6	2	1139-1336-01	Hose clamp			
7	1	1139-1306-01	Adapter			
8	1	1139-1150-01	Magnet			
9	1	1139-1240-01	Holder-magnet			
11	1	1139-1028-01	Spring			
12	1	1139-1251-01	Shaft-bypass			
13	1	1139-1189-01	Lever-bypass			
14	1	1139-1161-01	Ring			
15	1	1139-1275-01	Bore plug			
16	1	1139-1104-01	Snap ring			
19	2	1139-1117-01	O-ring			
20	1	1139-1119-01	Seal			
21	2	1139-1295-01	Tapping screw			
22	14	1139-0244-01	Tapping screw			
24	1	1139-1273-01	Center case assy			
25	1	1139-1158-01	Pin			
26	1	1139-1063-01	Filter			
27	3	1139-1294-01	Bolt			
28	2	1139-1339-01	Valve			
29	2	1139-1338-01	Spring			
30	2	1139-1346-01	Ball			
31	1	1139-1159-01	Cylinder block assy			
32	1	1139-1245-01	Spring			
33	1	1139-1246-01	Pump shaft			
34	3	1139-1146-01	Ring			
35	1	1139-1110-01	Ball bearing			
36	1	1139-1157-01	Housing			
37	1	1139-1054-01	Bearing			
38	1	1139-1139-01	Cylinder block assy			
39	1	1139-1160-01	Washer			
40	1	1139-1247-01	Motor shaft			
41	1	1139-1021-01	Snap ring			
42	1	1139-1272-01	Motor gear			
43	1	1139-1286-01	Ball bearing			
44	2	1139-1296-01	Metal thrust			
45	1	1139-1067-01	Swash plate assy			
46	1	1139-1068-01	Bearing			
47	1	1139-1070-01	Thrust plate			
48	1	1139-1069-01	Thrust plate			
49	1	1139-1315-01	Control shaft			
50	1	1139-1316-01	Fulcrum			
51	1	1139-1312-01	Spring			
52	1	1139-1314-01	Control arm			
53	1	1139-1325-01	Control lever			
54	1	1139-1250-01	Jerky plate			
55	1	1139-1102-01	Washer			
56	1	1139-1327-01	Pin			
57	1	1139-1329-01	Pin			
58	1	1139-1285-01	Pin			
59	2	1139-1115-01	O-ring			
60	1	1139-1127-01	Nut			
61	1	1139-1162-01	Differential gear k			
62	1	1139-1258-01	Final gear			
63	1	1139-1255-01	Collar			
64	1	1139-1256-01	Reduction shaft			
65	2	1139-1257-01	Washer			
66	1	1139-1267-01	Reduction gear			
67	1	1139-1259-01	Final pinion			
68	1	1139-1344-01	Axle shaft-left			
69	1	1139-1345-01	Axle shaft-right			
70	2	1139-1078-01	Thrust washer			
71	2	1139-1163-01	Ring			
72	2	1139-1080-01	Seal			
73	2	1139-1164-01	Bushing			

Section: KANZAKI TRANSAXLE K46G

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
K46G						
75	1	1139-1260-01	Brake shoe			
76	1	1139-1261-01	Brake arm			
77	1	1139-1320-01	Brake shaft			
78	1	1139-1263-01	Return spring			
79	1	1139-1264-01	Brake actuator			
80	1	1139-1282-01	Pin			
81	2	1139-1114-01	O-ring			
82	2	1139-1281-01	Pin			
83	1	1139-1248-01	Spline collar			
84	1	1139-1249-01	Pulley			
85	1	1134-4190-01	Fan			
86	1	1139-1266-01	Lock washer			
87	1	1139-1149-01	Snap ring			
89	1	1139-1335-01	Upper housing			
90	1	1139-1280-01	Pin			
91	1	1139-1303-01	Oil seal			
95	1	1139-1279-01	Pin			
99	2	1139-1103-01	Seal washer			
100	2	1139-1123-01	Bolt			

test