



Section: SB 28-SB 30 BRUSH CUTTER ENGINE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	6111					
	6112					
1	12	1911-3007-01	Screw			
2	1	1911-3731-01	Transm.support case			
4	1	1911-3005-01	Screw			
5	1	1911-3016-01	Washer			
6	4	1911-3117-01	Grommet			
7	2	1911-3661-01	.Screw			
8	1	1911-3686-01	Spring			
9	2	1911-3689-01	.Clutch unit			
10	2	1911-3659-01	.Washer			
11	2	1911-3259-01	Screw			
12	2	1911-3272-01	Washer			
13	1	1911-3667-01	Electronic coil			
14	1	1911-3055-01	Spark plug cable			
15	1	1911-3128-01	Wire sheath			
16	1	1911-3060-01	Ground cable			
17	1	1911-3713-01	Flywheel assy		Inkl. pos 7, 9, 10	
18	2	1911-3030-01	Nut			
19	3	1911-3008-01	Screw			
20	2	1911-3043-01	Seal ring			
21	1	1911-3116-01	Grommet			
22	1	1911-3827-01	Crankcase			
23	1	1911-3048-01	Flywheel key			
24	2	1911-3072-01	Washer			
25	1	1911-3042-01	.Needle bearing			
26	2	1911-3682-01	..Washer			
27	1	1911-3715-01	Crankshaft assy		Inkl. pos 25	
28	2	1911-3039-01	Ball bearing			
29	1	1911-3121-01	Cable guide			
30	1	1911-3692-01	.Gasket			
31	5	1911-3022-01	Nut			
32	3	1911-3002-01	.Screw			
33	2	1911-3087-01	.Spring			
34	2	1911-3118-01	.Starter hook			
35	1	1911-3822-01	Starter cup assy		Inkl. pos 32 - 34	
36	1	1911-3006-01	Screw			
37	1	1911-3736-01	Cylinder cover			
38	1	1911-3708-01	Muffler			
41	1	1911-3694-01	.Gasket			
42	1	1911-3113-01	Spark plug cover			
43	1	1911-3093-01	Spark plug spring			
44	1	9400-0258-00	Spark plug		Champion CJ7Y	
45	2	1911-3011-01	Screw			
46	1	1911-3693-01	.Gasket			
47	1	1911-3665-01	..Piston ring			
48	1	1911-3666-01	..Piston pin			
49	2	1911-3069-01	..Lock ring			
50	1	1911-3826-01	.Piston assy		Inkl. pos 26, 47 -	
51	1	1911-3825-01	Cylinder assy w.pis		Inkl. pos 50	
52	1	1911-3150-01	.Intake filter			
53	1	1911-3208-01	.Hose grommet assy			
54	1	1911-3207-01	.Fuel cap			
55	1	1911-3716-01	Fuel tank assy		Inkl. pos 52 - 54	
62	1	1911-3833-01	Gasket set		Inkl. pos 30, 41, 4	
63	1	1911-3723-01	Bag w.tools			