



Section: TURBO 43-43S HERKULES MB430-MB432 HANDLE TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----

1181

1581 1586 1281 1686

1	1	1	1	1	1111-3112-01	Handlebar-upper par	
2	1	1	1	1	1111-3113-01	Handlebar-lower par	
3	2	2	2	2	1111-3021-01	Handlebar attachmen	
4	2	2	2	2	1111-3024-01	Attachment plate	
5	4	4	4	4	1111-3023-01	Locking knob	
6	4	4	4	4	9795-3531-02	Nut	
7	6	6	6	6	9699-0028-02	Flat washer	
8	2	2	2	2	1111-0178-00	Reinforcement	
9	2	2	2	2	9899-3545-12	Screw	L = 45 mm
10	2	2	2	2	9899-3557-12	Screw	L = 57 mm
11	2	2	2	2	9939-0820-16	Screw	
12	1	1	1	1	1111-3062-01	Eyelink	
13	1	1	1	1	9900-0060-00	Allen wrench	
20	1		1		9948-0640-16	Screw	L = 40 mm
20		1		1	9948-0660-16	Screw	L = 60 mm
21	1	1	1	1	9747-0631-02	Lock nut	
22	1	1	1	1	1111-2953-01	Control handle	
23	1		1		1111-2968-01	Engine brake cable	
23		1		1	1111-2968-03	Engine brake cable	
24	1	1	1	2	1111-2018-01	Cable holder	
25	1	1	1	2	9836-9216-12	Screw	
26		1		1	1111-3351-01	Throttle control	
27		1		1	9699-0060-02	Flat washer	
28			1	1	1111-2954-01	Control handle	
29			1	1	1111-2967-02	Clutch cable	
30	1	1	1	1	1111-2969-01	Cable attachment	
40			1	1	1111-2915-01	Engine belt pulley	
41			1	1	9910-0612-16	Set screw	
42			1	1	1111-9053-01	Drive belt	
43			1	1	1111-2822-01	Tension spring	
44			1	1	1111-3111-01	Transmission assy	
44A			1	1	1111-3447-01	.Spring	Ej ill/not ill.
45			1	1	1111-3047-01	Belt pulley	
46			1	1	9595-0235-00	Locating pin	
47			2	2	9404-0083-00	Seal ring	
48			2	2	1111-2382-01	Pin	
49			2	2	9695-0013-00	Washer	
50			2	2	1111-2829-01	Lock washer	
51			2	2	1111-3256-01	Drive key	
52				2	1111-3230-01	Pinion-alum. wheel	
52			2		1111-3075-01	Pinion-plastic whee	
53			2	2	1111-2830-01	Support washer	
54			2	2	9695-0013-00	Washer	
55			2	2	9652-0010-04	Snap ring	