



Section: 928-928T HANDLE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2837	2838				
720	1	1	1812-1194-01		Handle-upper	
723	2	2	9988-3751-12		Screw	
724	2	2	9988-3764-12		Screw	
725	6	6	9699-0035-02		Flat washer	
726	4	4	9683-0035-02		Lock washer	
727	4	4	9795-3731-02		Nut	
728	2	2	1812-0830-01		Plastic stop	
729	2	2	1812-0955-01		Handle grip	
739	2	2	1812-0520-01		Protection	
740	1	1	1812-1729-01		Clutch cable	
741	1	1	1812-1519-01		Control wire	
743	1	1	1133-0977-01		Cable adjust bracke	
744	1	1	1812-0254-01		Spring	
745	1	1	9743-3521-32		Nut	
750	1	1	1812-0553-01		Handle-lower	
751	4	4	1133-0057-01		Screw	
752	4	4	9683-0030-02		Lock washer	
758	1	1	1812-1755-01		Screw	
759	1	1	1812-1205-01		Spool	
760	1	1	1812-1702-01		Bracket	
762	1	1	1812-1727-01		Drive cable-lower	
764	1	1	9743-3521-32		Nut	
765	2	2	1133-0968-01		Clutch spring boot	
770	1	1	1812-1422-01		Gear shifter	
771	1	1	9988-3764-12		Screw	
772	1	1	1812-0304-01		Spring	
773	1	1	9699-0035-02		Flat washer	
774	1	1	9743-3721-32		Nut	
775	1	1	1812-1193-01		Spacer	
785	1	1	9795-3531-02		Nut	
787	1	1	1812-1293-01		Knob	
790	1	1	1812-1414-01		Bail rod-LH	
791	1	1	1812-1188-01		Bail rod-R.H.	
795	1	1	1812-1593-01		Cam retainer bracke	
796	1	1	9988-3619-16		Screw	
797	1	1	9683-0030-02		Lock washer	
798	1	1	9795-3631-02		Nut	
799	1	1	1812-0834-01		Cam lock spring	
800	1	1	1812-1280-01		Pin latch	
801	2	2	1812-1483-01		Retainer	
802	1	1	9599-0036-02		Split pin	
803	1	1	9699-0029-02		Flat washer	
804	1	1	1812-1242-01		Speed control rod	
805	1	1	9794-5131-02		Nut	
806	1	1	1812-0622-01		Adaptor	
807	1	1	9683-0030-02		Lock washer	
808	1	1	1812-0627-01		Ball joint	
809	1	1	9683-0030-02		Lock washer	
810	1	1	9794-5131-02		Nut	
811	1	1	1812-1219-01		Plastic bushing	
812	1	1	1812-1720-01		Yoke rod	
813	1	1	1812-1672-01		Retainer ring	