



## Section: ESTATE MASTER HST TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2512					
1	1	1136-0418-01	Engine belt pulley			
2	1	9987-5351-12	Screw			
3	1	9683-0045-02	Washer			
5	1	1136-1020-01	Drive belt			
6	1	1136-1079-01	Tension lever			
7	1	1136-0400-01	Stud bolt			
8	1	9677-0009-02	Lock washer			
9	1	1136-0088-01	Washer			
10	1	1136-0309-01	Washer			
11	1	9712-0831-02	Lock nut			
12	1	1136-0289-01	Idler pulley			
13	1	9699-0056-02	Flat washer			
14	1	9747-0831-02	Lock nut			
15	1	1136-0860-01	Spring			
21	1	1136-0838-01	Transmission		Peerless LTH 2000	
22	4	9997-0860-16	Screw			
24	4	9739-0831-22	Nut			
25	1	1136-1003-01	Clamp			
26	1	1136-0017-01	Screw			
27	1	9997-0825-16	Screw			
28	1	9699-0090-02	Flat washer			
29	1	9747-0831-02	Lock nut			
30	1	1136-0953-01	Lever			
31	1	9699-0037-02	Washer			
32	1	9699-0085-02	Flat washer			
33	1	9987-5016-16	Screw			
34	1	9683-0025-02	Lock washer			
39	1	1136-1026-01	Disengage control			
40	1	1136-0858-01	Handle			
41	1	9865-0412-16	Screw			
42	1	9799-0431-02	Nut			
43	2	1136-0876-01	Spacer			
44	2	1136-0812-01	Screw			
45	2	9747-0631-02	Lock nut			
46	1	1136-0971-01	Wire clamp			
47	1	9847-8016-16	Screw			
48	1	9699-0018-02	Washer			
62	2	1136-0568-01	Rim			
63	2	1136-0410-01	Tire (Turf Saver)			
63	2	1136-0412-01	Tire (Deli)			
64	2	9699-0119-02	Washer			
65	2	1136-0305-01	Washer			
66	2	9652-0015-04	Retaining ring			
67	0-4	9695-0015-00	Washer			
68	2	1136-0081-01	Hub cap			
69	2	9545-0500-00	Valve			