



## Section: PARK DIESEL HAND CONTROLS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
6231						
1	1	1134-4156-01	Panel bracket-inner			
2	2	9897-0820-16	Screw			
3	2	9739-0831-22	Nut			
5	1	1134-4065-01	Control shaft			
6	1	1134-4079-01	Spring			
7	1	1134-4080-03	Control sleeve			
8	2	9959-0820-16	Screw			
9	1	1134-4077-01	Throttle control			
10	1	1134-4078-01	Knob			
11	1	1134-0240-00	Shoulder screw			
12	2	1134-4242-01	Spacer washer			
13	1	9694-0001-00	Washer			
14	1	9739-0831-22	Nut			
15	1	1134-4923-01	Throttle cable			
16	1	9500-9991-00	Cable clamp			
17	1	9943-0516-16	Screw			
25	1	1134-4487-01	Panel bracket			
26	2	9893-0616-16	Screw			
27	1	1134-3986-01	Front plate			
28	4	9893-0616-16	Screw			
29	1	1134-4069-01	Control lever			
30	1	1134-2551-01	Knob			
31	1	1134-4073-01	Cable holder			
32	1	9942-0612-16	Screw			
33	1	1134-4006-01	Cable			
34	1	1134-2871-03	Relay			
35	1	1134-2871-01	Relay			
36	2	9997-0520-16	Screw			
37	2	9739-0531-22	Nut			
38	1	1134-3981-04	Dashboard			
39	4	9946-0525-16	Screw			
40	1	1134-4154-01	Cover			
42	1	1134-4908-01	Ignition switch			
46	1	9400-0296-01	Switch			
47	1	9699-0090-02	Flat washer			
48	4	9400-0282-01	Switch w.diode			
49	1	9400-0280-02	Cover-cruise contro			
50	1	9400-0280-03	Cover-height adjust			
51	1	9400-0280-01	Cover-PTO			
52	1	9400-0280-04	Cover-rear tools			
53	1	9400-0283-01	Switch			
54	1	9400-0280-05	Cover-12V			
55	1	1134-4179-01	Hour meter			
56	1	9699-0025-02	Washer			
57	1	9400-0295-01	Switch			
58	1	9400-0299-01	Gasket			
59	1	9400-0280-06	Cover-hydraulic lif			
99	1	9400-0290-01	Tool for cover		Tillbehör/Accessory	