



Section: ESTATE PRESIDENT BRAKE CONTROL DRIVE CONTROL

| Pos. | Quantity | Spare part No | Description | Kit | Notes | New |
|------|----------|---------------|-------------------|-----|-------|-----|
| | 2532 | | | | | |
| 1 | 1 | 1136-0510-01 | Pedal | | | |
| 2 | 1 | 1136-0151-01 | Pedal cover | | | |
| 3 | 1 | 1136-0254-01 | Clamp | | | |
| 4 | 4 | 9847-8016-16 | Screw | | | |
| 5 | 1 | 1136-0117-01 | Brake rod | | | |
| 6 | 1 | 9699-0090-02 | Flat washer | | | |
| 7 | 1 | 9675-0012-02 | Locking washer | | | |
| 8 | 1 | 1136-0248-01 | Pivot bolt | | | |
| 9 | 1 | 1136-0218-01 | Spring | | | |
| 10 | 2 | 9699-0035-02 | Flat washer | | | |
| 11 | 1 | 1136-1246-01 | Clamp | | | |
| 12 | 1 | 9799-1031-02 | Nut | | | |
| 13 | 1 | 9747-1031-02 | Lock nut | | | |
| 14 | 1 | 9699-0090-02 | Flat washer | | | |
| 15 | 1 | 9747-0831-02 | Lock nut | | | |
| 31 | 1 | 1136-0441-01 | Axle | | | |
| 32 | 1 | 1136-0217-01 | Spring | | | |
| 33 | 2 | 1136-0256-01 | Plate | | | |
| 34 | 4 | 9847-8016-16 | Screw | | | |
| 35 | 1 | 1136-0119-01 | P-brake lever | | | |
| 36 | 1 | 9675-0011-00 | Starlock | | | |
| 37 | 1 | 1136-0392-01 | Knob | | | |
| 51 | 1 | 1136-0507-01 | Drive pedal | | | |
| 52 | 1 | 1136-0149-01 | Pedal cover-front | | | |
| 53 | 1 | 1136-0150-01 | Pedal cover-rear | | | |
| 54 | 1 | 1136-0538-01 | Support | | | |
| 55 | 2 | 1136-0121-01 | Bushing | | | |
| 56 | 1 | 9501-0500-00 | Grease joint | | | |
| 57 | 2 | 9997-0616-16 | Screw | | | |
| 58 | 2 | 9739-0631-22 | Nut | | | |
| 59 | 1 | 1136-0500-01 | Pedal axle | | | |
| 60 | 2 | 9650-0020-04 | Circlip | | | |
| 61 | 1 | 1136-0090-01 | Washer | | | |
| 62 | 1 | 9997-0816-16 | Screw | | | |
| 63 | 1 | 9683-0030-02 | Lock washer | | | |
| 64 | 1 | 1136-0118-01 | Drive rod | | | |
| 65 | 1 | 1136-0241-01 | Pivot bolt | | | |
| 66 | 1 | 1136-0247-01 | Pivot bolt | | | |
| 67 | 2 | 9799-0831-02 | Nut | | | |
| 68 | 2 | 9747-0831-02 | Lock nut | | | |
| 69 | 1 | 9699-0035-02 | Flat washer | | | |
| 70 | 1 | 9699-0028-02 | Flat washer | | | |
| 71 | 1 | 9747-0631-02 | Lock nut | | | |
| 72 | 1 | 1136-0533-01 | Support | | | |
| 73 | 1 | 9699-0060-02 | Flat washer | | | |
| 74 | 1 | 9747-0631-02 | Lock nut | | | |
| 75 | 1 | 9997-0620-16 | Screw | | | |
| 76 | 1 | 9747-0631-02 | Lock nut | | | |
| 77 | 1 | 1136-0330-01 | Clamp | | | |
| 78 | 2 | 9848-8013-16 | Screw | | | |
| 80 | 1 | 1136-0407-01 | Plate | | | |
| 81 | 2 | 1136-1214-01 | Screw | | | |
| 82 | 2 | 9683-0005-02 | Lock washer | | | |
| 83 | 2 | 9799-0331-02 | Nut | | | |