Genuine Spare Parts


GH) \$\$ Model Year 2011

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative and might not represent the part in question exactly.
- The indications "right" "left" "front" "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

COPYRIGHT by GLOBAL GARDEN PRODUCTS

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permision in writing from GLOBAL GARDEN PRODUCTS.







Electric Trimmer

Pos Fig.	. Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
1 2 3 4 5 6	1 1 1 1 1	1911-1614-01 1911-1611-01 1911-1610-01 1911-1609-01 1911-1608-01 1911-1607-01	Handtag Skydd Ledkåpa, vä+hö Arm Fjäder Stift	Motor Housing Yellow Cover Joint Lever Spring Pin	
7 8 9	1 1 1	1911-1606-01 1911-1612-01 1911-1613-01	Växelhus-hö, gul Växelhus-vä, gul Lock	Right Housing, Yellow Left Housing, Yellow Cap	
10 11 12 13 14	1 1 1 1 1	1911-1630-01 1911-1604-01 1911-1629-01 1911-1631-01 1911-1628-01	Elmotor Skyddskåpa Fjäder Skärhuvud kpl Knopp	Motor Safety Cover Ass.Y Spring Cutting Line Assy Knob	
		1911-1628-01	Кпорр		