

FORWARDS



Joist Spare parts Joist

Utgåva Issue		Bildnr Picture No		KANZAKI TRANSAXEL K574F (s/n 0010000- 9999999)		KANZAKI TRANSAXLE K574F (s/n 0010000- 9999999)		Sida Page	
2011- 11		2220A						456	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	574F								
	1	1			1137-0125-01	Transaxel kpl.....	Transaxle assy.....		Kanzaki K574F Inkl. pos 74
	2	1			1139-1470-01	Hus- övre	Housing- upper		
	3	1			1139-1456-01	Hus- nedre	Housing- lower		
	5	1			1139-1301-01	Rör	Tube		
	6	2			1139-1336-01	Slangklämma.....	Hose clamp		
	7	1			1139-1306-01	Adapter.....	Adapter		
	8	2			1139-1150-01	Magnet	Magnet		
	9	1			1139-1341-01	Hållare- magnet	Holder- magnet		
	11	1			1139-1347-01	Fjäder.....	Spring		
	12	1			1139-1251-01	Axel- bypass	Shaft- bypass		
	13	1			1139-1189-01	Arm- bypass	Lever- bypass		
	14	1			1139-1161-01	Låsring	Ring		
	15	1			1139-1275-01	Plugg.....	Bore plug		
	16	1			1139-1104-01	Låsring	Snap ring		
	17	2			1139-1103-01	• Tätningbricka	• Seal washer	S	
	18	2			1139-1500-01	Dräneringsskruv	Drain bolt kit	S Inkl. pos 17	
	20	1			1139-1119-01	• Tätning	• Seal	S	
	21	4			1139-1455-01	Skruv	Tapping screw		
	22	12			1139-0244-01	Skruv	Tapping screw		
	24	1			1139-1605-01	• Centrumhus	• Center case	R	
	25	1			1139-1158-01	Stift	Pin		
X	27	2			1139-1718-01	Bult.....	Bolt		
	28	2			1139-1468-01	Ventil	IDS valve.....		
	29	2			1139-1243-01	Fjäder.....	Spring		
	30	2			1139-1307-01	• Filter	• Filter	S	
	31	1			1139-1356-01	• Cylinderblock kpl	• Cylinder block assy	R	
	32	1			1139-1245-01	Fjäder.....	Spring		
X	33	1			1139-1724-01	Pumpaxel.....	Pump shaft	Inkl. pos 96	
	34	3			1139-1146-01	Låsring	Ring		
	35	1			1139-1110-01	Kullager	Ball bearing		
	36	1			1139-1458-01	Hus	Housing		
	37	1			1139-1438-01	Lager	Bearing.....		
	38	1			1139-1509-01	• Cylinderblock kpl	• Cylinder block kit.....	R	
	39	1			1139-1160-01	Bricka	Washer.....		
	40	1			1139-1353-01	Motoraxel	Motor shaft		
	41	1			1139-1021-01	Låsring	Snap ring		
	42	1			1139-1272-01	Motordrev.....	Motor gear		
	43	1			1139-1453-01	Lager	Bearing.....		
	44	2			1139-1066-01	Tryckplatta	Metal thrust		
	45	1			1139-1597-01	Stänkplatta.....	Swash plate.....		
	46	1			1139-1508-01	Lager	Thrust bearing kit.....		
	49	1			1139-1354-01	Regleraxel.....	Control shaft		
	50	1			1139-1410-01	Excenter.....	Fulcrum.....		
	51	1			1139-1312-01	Fjäder.....	Spring		
	52	1			1139-1409-01	Reglerarm.....	Control arm.....		
	53	1			1139-1325-01	Reglerarm.....	Control lever		
	54	1			1139-1596-01	Ryckplatta.....	Jerky plate.....		
	55	1			1139-1102-01	Bricka	Washer.....		
	56	1			1139-1355-01	Saxpinne.....	Cotter pin		
	57	1			1139-1329-01	Stift.....	Pin		
	58	1			1139-1285-01	Stift.....	Pin		
	60	1			1139-1127-01	Mutter.....	Nut		
	61	1			1139-1404-01	Differentialdrev kpl	Differential gear kit.....		
	62	1			1139-1258-01	Slutdrev	Final gear		
	63	1			1139-1255-01	Hylsa	Collar		
	64	1			1139-1256-01	Reduktionsaxel	Reduction shaft.....		
	65	2			1139-1398-01	Bricka	Washer.....		
	66	1			1139-1267-01	Reduktionsdrev	Reduction gear.....		
	67	1			1139-1361-01	Slutdrev	Final pinion		
	68	1			1139-1344-01	Hjulaxel- vä	Axle shaft- left		
	69	1			1139-1345-01	Hjulaxel- hö	Axle shaft- right.....		
	70	2			1139-1078-01	Tryckbricka	Thrust washer		
	71	2			1139-1163-01	Låsring	Ring		

FORWARDS

Joists
Spare parts
Joists

Utgåva Issue		Bildnr Picture No		KANZAKI TRANSAXEL K574F (s/n 0010000- 9999999)		KANZAKI TRANSAXLE K574F (s/n 0010000- 9999999)		Sida Page	
2011- 11		2220A						458	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	574F								
72	2				1139- 1080- 01	• Tätning	• Seal	S	
73	2				1139- 1164- 01	Bussning	Bushing		
74	2				1139- 1414- 01	• Bussning	• Bushing		
75	1				1139- 1260- 01	Bromssko	Brake shoe		
76	1				1139- 1261- 01	Bromsarm	Brake arm		
77	1				1139- 1320- 01	Bromsaxel	Brake shaft		
78	1				1139- 1411- 01	Returfjäder	Return spring		
79	1				1139- 1264- 01	Bromstryckare	Brake actuator		
80	1				1139- 1282- 01	Stift	Pin		
82	2				1139- 1281- 01	Stift	Pin		
83	1				1139- 1248- 01	Krage	Spline collar		
84	1				1139- 1469- 01	Remskiva	Pulley		
85	1				1134- 4190- 01	Fläkt	Fan		
88	1				1139- 1276- 01	Bricka	Collar		
89	4				1139- 1166- 01	Tapp	Pin		
90	1				1139- 1280- 01	Stift	Pin		
91	1				1139- 1303- 01	• Tätningsring	• Oil seal	S	
92	1				1139- 1534- 01	• O- ring	• O- ring	S	
93	1				1139- 1510- 01	Lock	Cap kit		Inkl. pos 92
94	1				1139- 1186- 01	• Filter	• Filter	S	
95	1				1139- 1279- 01	Stift	Pin		
96	1				1139- 1148- 01	• Stift	• Pin		
99	1				1139- 1443- 01	• Tätningsmedel	• Sealant	S	
100	1				1139- 1462- 01	• Ventil	• Valve		
101	1				1139- 1234- 01	• Ventil kpl	• Check assy		
102	1				1139- 1463- 01	• Ventil	• Valve		
105	1				1139- 0239- 01	• Packning	• Packing	S	
106	2				1139- 1168- 01	• Packning	• Packing	S	
107	1				1139- 1459- 01	Nippel	Piping		
108	1				1139- 1460- 01	Nippel	Piping		
109	2				1139- 1464- 01	Anslutning	Connector		
110	1				1139- 1526- 01	Pumphus kpl	Pump case kit		Inkl. pos 100 - 102
111	1				1139- 1472- 01	Bult	Bolt		
112	1				1139- 1473- 01	Bult	Bolt		
113	1				1139- 1471- 01	Bult	Bolt		
X 114	1				1139- 1719- 01	• Bult	• Bolt		
X 115	1				1139- 1720- 01	• Låsbricka	• Lock washer		
X 116	1				1139- 1721- 01	• Bricka	• Washer		
X 120	1				1139- 1725- 01	Pumpaxel kpl	Pump shaft kit		Inkl pos 33,114- 116
200	1				1139- 1481- 01	Servicesats	Seal kit	R	Märkta S/Marked S
201	1				1139- 1527- 01	Reparationssats	Repair kit		Märkta R/Marked R



FORWARDS

Utgåva Issue		Bildnr Picture No		KANZAKI TRANSAXEL K574G (s/n 0015000- 9999999)		KANZAKI TRANSAXLE K574G (s/n 0015000- 9999999)		Sida Page	
2011- 11		2221A						460	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	574G								
1	1			1137-0124-01	Transaxel kpl.....	Transaxle assy.....		Kanzaki K574G Pos 74 incl.	
2	1			1139-1470-01	Hus- övre	Housing- upper			
3	1			1139-1457-01	Hus- nedre	Housing- lower			
5	1			1139-1301-01	Rör	Tube			
6	2			1139-1336-01	Slangklämma.....	Hose clamp			
7	1			1139-1306-01	Adapter.....	Adapter			
8	2			1139-1150-01	Magnet	Magnet			
9	1			1139-1341-01	Hållare- magnet	Holder- magnet			
11	1			1139-1347-01	Fjäder.....	Spring			
12	1			1139-1251-01	Axel- bypass	Shaft- bypass			
13	1			1139-1189-01	Arm- bypass	Lever- bypass.....			
14	1			1139-1161-01	Låsring	Ring			
15	1			1139-1275-01	Plugg.....	Bore plug			
16	1			1139-1104-01	Låsring	Snap ring			
17	2			1139-1103-01	• Tätningbricka	• Seal washer.....	S		
18	2			1139-1500-01	Dräneringsskruv	Drain bolt kit			
20	1			1139-1119-01	• Tätning	• Seal	S		
21	4			1139-1455-01	Skruv	Tapping screw			
22	12			1139-0244-01	Skruv	Tapping screw			
24	1			1139-1487-01	• Centrumhus	• Center case	R		
25	1			1139-1158-01	Stift	Pin			
26	2			1139-1497-01	Stift.....	Pin			
27	2			1139-1718-01	Bult.....	Bolt			
28	2			1139-1468-01	Ventil	IDS valve.....			
29	2			1139-1243-01	Fjäder.....	Spring			
30	2			1139-1307-01	• Filter	• Filter	S		
31	1			1139-1356-01	• Cylinderblock kpl	• Cylinder block assy	R		
32	1			1139-1245-01	Fjäder.....	Spring			
33	1			1139-1727-01	• Pumpaxel.....	• Pump shaft.....			
34	3			1139-1146-01	Låsring	Ring			
35	1			1139-1110-01	Kullager	Ball bearing			
36	1			1139-1458-01	Hus.....	Housing			
37	1			1139-1438-01	Lager	Bearing.....			
38	1			1139-1509-01	• Cylinderblock kpl	• Cylinder block kit.....	R		
39	1			1139-1160-01	Bricka	Washer.....			
40	1			1139-1353-01	Motoraxel	Motor shaft			
41	1			1139-1021-01	Låsring	Snap ring			
42	1			1139-1272-01	Motordrev.....	Motor gear			
43	1			1139-1453-01	Lager	Bearing.....			
44	2			1139-1066-01	Tryckplatta	Metal thrust.....			
45	1			1139-1597-01	Stänklatta.....	Swash plate.....			
46	1			1139-1508-01	Lager	Thrust bearing kit.....			
49	1			1139-1354-01	Regleraxel.....	Control shaft			
50	1			1139-1410-01	Excenter.....	Fulcrum.....			
51	1			1139-1312-01	Fjäder.....	Spring			
52	1			1139-1409-01	Reglerarm.....	Control arm			
53	1			1139-1325-01	Reglerarm.....	Control lever			
54	1			1139-1596-01	Ryckplatta.....	Jerky plate.....			
55	1			1139-1102-01	Bricka	Washer.....			
56	1			1139-1355-01	Saxpinne.....	Cotter pin			
57	1			1139-1329-01	Stift.....	Pin			
58	1			1139-1285-01	Stift.....	Pin			
60	1			1139-1127-01	Mutter.....	Nut			
61	1			1139-1404-01	Differentialdrev kpl	Differential gear kit.....			
62	1			1139-1258-01	Slutdrev	Final gear			
63	1			1139-1255-01	Hylsa	Collar			
64	1			1139-1256-01	Reduktionsaxel	Reduction shaft.....			
65	2			1139-1398-01	Bricka	Washer.....			
66	1			1139-1267-01	Reduktionsdrev	Reduction gear.....			
67	1			1139-1361-01	Slutdrev	Final pinion			
68	1			1139-1344-01	Hjulaxel- vä	Axle shaft- left			
69	1			1139-1345-01	Hjulaxel- hö	Axle shaft- right.....			
70	2			1139-1078-01	Tryckbricka	Thrust washer			



FORWARDS

Utgåva Issue		Bildnr Picture No		KANZAKI TRANSAXEL K574G (s/n 0015000- 9999999)		KANZAKI TRANSAXLE K574G (s/n 0015000- 9999999)		Sida Page	
2011- 11		2221A						462	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	574G								
71	2			1139-1163-01	Låsring	Ring			
72	2			1139-1080-01	• Tätning	• Seal	S		
73	2			1139-1164-01	Bussning	Bushing			
74	2			1139-1414-01	• Bussning	• Bushing			
75	1			1139-1260-01	Bromssko	Brake shoe			
76	1			1139-1261-01	Bromsarm	Brake arm			
77	1			1139-1320-01	Bromsaxel	Brake shaft			
78	1			1139-1411-01	Returfjäder	Return spring			
79	1			1139-1264-01	Bromstryckare	Brake actuator			
80	1			1139-1282-01	Stift	Pin			
82	2			1139-1281-01	Stift	Pin			
83	1			1139-1248-01	Krage	Spline collar			
84	1			1139-1469-01	Remskiva	Pulley			
85	1			1134-4190-01	Fläkt	Fan			
88	1			1139-1276-01	Bricka	Collar			
89	4			1139-1166-01	Tapp	Pin			
90	1			1139-1280-01	Stift	Pin			
91	1			1139-1303-01	• Tätningsring	• Oil seal	S		
92	1			1139-1534-01	• O-ring	• O-ring	S		
93	1			1139-1510-01	Lock	Cap kit			Pos 92 incl.
94	1			1139-1488-01	• Filter	• Filter	S		
95	1			1139-1279-01	Stift	Pin			
96	1			1139-1148-01	Stift	Pin			
97	1			1139-1492-01	Fjäder	Charge spring			
98	1			1139-1496-01	Pinne	Parallell pin			
99	1			1139-1443-01	• Tätningsmedel	• Sealant	S		
100	1			1139-1608-01	Pump kpl	Charge pump kit			Inkl. pos 101 - 102
104	1			1139-1013-01	• O-ring	• O-ring	S		
105	2			1139-0239-01	• Packning	• Packing	S		
107	1			1139-1459-01	Nippel	Piping			
108	1			1139-1460-01	Nippel	Piping			
110	1			1139-1505-01	Hydraulportblock	Hydraulic port block			
111	1			1139-1472-01	Bult	Bolt			
112	1			1139-1473-01	Bult	Bolt			
113	1			1139-1471-01	Bult	Bolt			
X 114	1			1139-1719-01	• Bult	• Bolt			
X 115	1			1139-1720-01	• Låsbricka	• Lock washer			
X 116	1			1139-1721-01	• Bricka	• Washer			
X 120	1			1139-1726-01	Pumpaxel kpl	Pump shaft kit			Inkl. pos 33,114- 116
200	1			1139-1506-01	Tätningssats	Seal kit	R		Märkta S/Marked S
201	1			1139-1507-01	Rep.sats	Repair kit			Märkta R/Marked R