

Genuine Spare Parts

www.stiga.com

SE 2516 Q Model Year 2013


- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

© Copyright 2013 Global Garden Products


All content is subject to copyright by Global Garden Products and may not be reproduced in whole or in part by any means, electronic or otherwise, without prior written approval.

THIS INFORMATION IS NOT INTENDED FOR SALE OR RESALE, AND THIS NOTICE MUST REMAIN ON ALL COPIES.





Position	Part No.	Q.Ty	Description
1	118801642/0	1	Cable Hook
2	118801681/0	1	Overload protection
3	4181307	1	Chain Cover
4	118801682/0	1	Chain Tension Wheel
5	118801683/0	2	Switching Unit
6	118801684/0	1	Gear
7	118801685/0	1	Pinion
8	118801686/0	1	Tank
9	118801687/0	1	Filter
11	118801688/0	1	Switch button
12	118801689/0	1	Switch Panel
13	118801690/0	1	Yellow Engine Cover
14	118801691/0	1	Motor Cap
15	118801692/0	1	Right Housing
16	118801693/0	1	Handle Cap
17	118801694/0	1	Left Housing
18	118801695/0	1	Lever
19	118801696/0	1	Rod
20	118801697/0	1	Tie Rod
21	118801698/0	1	Tie Rod
22	118801699/0	1	Spring
23	118801700/0	1	Spike
24	118801701/0	1	Sleeve
25	118801702/0	1	Chain Wheel
26	1911-1156-01	1	Bearing
27	118801703/0	1	Cylinder Gear
28	4113706	1	Chain
29	1911-1161-01	1	Ring
30	1911-1162-01	2	Screw
31	119216035/0	1	Bearing
32	118801704/0	1	Spring
33	118801705/0	1	Screw
34	118801706/0	1	Washer
35	118801707/0	1	Spring
36	118801708/0	1	Screw
37	118801709/0	1	Ball
38	118801710/0	1	Screw
39	118801711/0	1	Connection With Condenser
40	118801712/0	1	Connection Oil-Level
41	118801713/0	1	Wire
42	118801714/0	1	Wire
43	118801715/0	1	Wire
44	1911-1180-01	1	Grommet
45	118801716/0	1	Microswitch
46	118801717/0	1	Switch
47	118801718/0	1	Cable
48	118801719/0	1	Engine
49	118801720/0	1	Support
50	123900351/0	1	Bar
51	118801721/0	1	Brake Assembly
52	118801722/0	1	Spur Wheel
53	118801723/0	1	Gear Wheel
54	118801724/0	1	Bar Holder
55	118801725/0	2	Carbon Brush
56	118801726/0	2	Spring
57	118801727/0	1	Tension Knob



Position	Part No.	Q.Ty	Description
58	118801728/0	1	Oil tube
59	118801729/0	1	Oil tube
60	118801730/0	1	Hand Guard Grey
61	118801731/0	1	Tank Cap
62	118801732/0	1	Spring
63	1911-1104-01	1	Cable
64	1911-1105-01	23	Screw
65	118801660/0	1	Spring

Joist
Spareparts
Joist