



Genuine Spare Parts




Joist
Spareparts
Joist



STIGA
1362A
SPARE PARTS

Utgåva Issue		Bildnr Picture No		SP 370- SP 410 MC 382 VEVHUS		SP 370- SP 410 MC 382 CRANKCASE		Sida Page
2005- 12		1362A						350
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	4113	4114	MC 382					
X 1	1	1	1	1911-4208-01	Vevhus kpl	Crankcase assy		
2	1	1	1	1911-3550-01	Tanklock	Tank cap		
3	1	1	1	1911-3550-01	Tanklock	Tank cap		
4	1	1	1	1911-3539-01	Oljepump	Oil pump		D = 8 mm
5	1	1	1	1911-3462-01	Distans	Spacer		
6	2	2	2	1911-3247-01	Skruv	Screw		
7	1	1	1	1911-3368-01	Hållare	Retainer		
8	1	1	1	1911-3230-01	Svärd	Bar		13" (0.325"x0.050)
8	1	1	1	1911-3231-01	Svärd	Bar		16" (0.325"x0.050)
9	1	1	1	1911-3295-01	Kedjespännskruv	Chain tension screw		
10	1	1	1	1911-3942-01	Skruv	Screw		
11	1	1	1	1911-3387-01	Kedjespännare	Chain tensioner		
12	1	1	1	1911-3445-01	Lock-oljetillförsel	Cap- oil supply		
13	1	1	1	1911-3952-01	Förstärkning	Reinforcement		
14	1	1	1	1911-3563-01	Oljeslang	Tube		
X 15	1	1	1	1911-4168-01	Svärdplatta	Bar plate		
16	1	1	1	1519-9002-56	Kedja (56E)	Chain (56E)		95VP (0.325")
16	1	1	1	1519-9002-64	Kedja (64E)	Chain (64E)		95VP (0.325")
17	1	1	1	1911-3547-01	Kopplingshus- gul	Clutch housing- yellow		
X 17	1	1	1	4252593	Kopplingshus- röd	Clutch housing- red		
18	1	1	1	1911-3505-01	Bränsleledning	Fuel line		
19	1	1	1	1911-3150-01	Bränslefilter	Intake filter		
20	1	1	1	1911-3296-01	Mutter	Nut		
21	1	1	1	1911-3938-01	Förstärkning	Reinforcement		
22	1	1	1	1911-3560-01	Andningsventil	Breather valve		
23	1	1	1	1911-3249-01	Skruv	Screw		
24	1	1	1	1911-3856-01	Spikjärn	Spike		
25	2	2	2	1911-3002-01	Skruv	Screw		
26	1	1	1	1911-3519-01	Kedjeskydd	Chain cover		13"
26	1	1	1	1911-3520-01	Kedjeskydd	Chain cover		16"
27	1	1	1	1911-3557-01	Tbh- påse	Accessory bag		




STIGA
 1363
 SPARE PARTS


Utgåva Issue		Bildnr Picture No		SP 370- SP 410 MC 382 LUFFFILTER KEDJEBROMS		SP 370- SP 410 MC 382 AIR FILTER CHAIN BRAKE		Sida Page	
2005-12		1363						352	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	4113 4114	MC 382							
1	1	1		1911-3364-01	Bromsband	Brake band			
2	1	1		1911-3269-01	Bricka	Washer			
3	1	1		1911-3249-01	Skruv	Screw			
4	1	1		1911-3540-01	Kedjebromsarm	Chain brake lever			
5	1	1		1911-3310-01	Pinne	Pin			
6	1	1		1911-3366-01	Fjäder	Spring			
7	1	1		1911-3482-01	Bromskåpa	Brake cover			
8	2	2		1911-3002-01	Skruv	Screw			
9	1	1		1911-3415-01	Fjäder	Spring			
10	1	1		1911-3361-01	Bromsplåt	Brake plate			
11	1	1		1911-3311-01	Pinne	Pin			
12	1	1		1911-3358-01	Bussning	Bushing			
14	3	3		1911-3001-01	Skruv	Screw			
15	1	1		1252613	Cylinderkåpa- röd	Cylinder cover- red			
15	1	1		1911-3549-01	Cylinderkåpa- gul	Cylinder cover- yellow			
16	1	1		1911-3579-01	Handskydd	Hand guard			
17	1	1		1911-3618-01	Lufffilter	Air filter			
19	1	1		1911-3491-01	Primerknapp	Air purge cap button			
20	1	1		1911-3416-01	Fjäder	Spring			
21	1	1		1911-3490-01	Primerhandtag	Air purge button			

X

Joist Spareparts




Utgåva Issue		Bildnr Picture No		SP 370- SP 410 MC 382 HANDTAG		SP 370- SP 410 MC 382 HANDLE		Sida Page	
2005- 12		1358						354	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	4113 4114	MC 382							
1	1	1		1911-3577-01	Handtag	Handle			
2	1	1		1911-3578-01	Handtagskåpa	Handle cover			
3	1	1		1911-3453-01	Gasreglage	Throttle lever			
4	1	1		1911-3417-01	Fjäder	Spring			
5	1	1		1911-3454-01	Säkerhetsspärr	Safety lever			
6	3	3		1911-3414-01	Fjäder	Spring			
7	2	2		1911-3367-01	Bricka	Washer			
8	3	3		1911-3002-01	Skruv	Screw			
9	6	6		1911-3248-01	Skruv	Screw			
10	1	1		1911-3007-01	Skruv	Screw			
11	1	1		1911-3022-01	Mutter	Nut			
12	3	3		1911-3015-01	Bricka	Washer			






STIGA
1364
SPARE PARTS

Utgåva Issue		Bildnr Picture No		SP 370- SP 410 MC 382 START		SP 370- SP 410 MC 382 STARTER		Sida Page	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	4113 4114	MC 382							
X 1		1		1252603	Start kpl- röd.....	Starter assy- red.....		Inkl. pos 2 - 11	
1	1			1911-3548-01	Start kpl- gul.....	Starter assy- yellow.....		Inkl. pos 2 - 11	
2	1	1		1911-3130-01	• Startsnöre.....	• Starter cord.....			
3	1	1		1911-3479-01	• Starthandtag.....	• Starter handle.....			
4	3	3		1911-3001-01	• Skruv.....	• Screw.....			
5	1	1		1911-3176-01	• Startfjäder.....	• Starter spring.....			
6	1	1		1911-3372-01	• Bussning.....	• Bushing.....			
7	1	1		1911-3096-01	• Skiva.....	• Disc.....			
8	1	1		1911-3483-01	• Linhjul.....	• Starter pulley.....			
9	2	2		1911-3480-01	• Startspärr.....	• Starter hook.....			
10	1	1		1911-3484-01	• Fäste- startspärr.....	• Guide- starter hook.....			
11	1	1		1911-3423-01	• Hållare.....	• Retainer.....			



STIGA
1360B
 SPARE PARTS

Utgåva Issue		Bildnr Picture No		SP 370- SP 410 MC 382 CYLINDER VEVAXEL		SP 370- SP 410 MC 382 CYLINDER CRANKSHAFT		Sida Page
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	4113 4114	MC 382						
1	1	1		1911-3280-01	Mutter.....	Nut.....		
2	1	1		1911-3268-01	Bricka.....	Washer.....		
3	1	1		1911-3567-01	Svänghjul.....	Flywheel.....		
4	1	1		1911-3048-01	Svänghjulskil.....	Flywheel key.....		
5a	1	1		1911-3301-01	Tätningring.....	Seal ring.....		
5b	1	1		1911-3302-01	Tätningring.....	Seal ring.....		
6	2	2		1911-3297-01	Kullager.....	Ball bearing.....		
7	2	2		1911-3072-01	Bricka.....	Washer.....		
8	1	1		1911-3532-01	Vevaxel kpl.....	Crankshaft assy.....		Inkl. pos 19
9	1	1		1911-3488-01	Dammskydd.....	Dust guard.....		
10	1	1		1911-3538-01	Koppling.....	Clutch.....		
11	1	1		1911-3041-01	Nållager.....	Needle bearing.....		
12	1	1		1911-3514-01	Drev.....	Sprocket.....		0.325"
13	1	1		1911-3338-01	Drevbricka.....	Sprocket washer.....		
14	1	1		1911-3330-01	Låsring.....	Circlip.....		
15	2	2		1911-3069-01	•• Låsring.....	•• Lock ring.....		
18	1	1		1911-3051-01	•• Kolvbult.....	•• Piston pin.....		
19	1	1		1911-3042-01	• Nållager.....	• Needle bearing.....		
20	4	4		1911-3006-01	Skruv.....	Screw.....		
21	4	4		1911-3274-01	Bricka.....	Washer.....		
22	1	1		1911-3304-01	•• Kolvring.....	•• Piston ring.....		
23	1	1		1911-3861-01	• Kolv kpl.....	• Piston assy.....		Inkl. pos 15, 18, 22
24	1	1		1911-3597-01	Cylinder-kolv kpl.....	Cylinder-piston assy.....		Inkl. pos 23
25	1	1		9400-0258-00	Tändstift.....	Spark plug.....		Champion CJ7Y
26	1	1		1911-3546-01	Tändstiftshatt.....	Spark plug cover.....		
27	1	1		1911-3421-01	Fjäder.....	Spring.....		
28	1	1		1911-3434-01	Skydd.....	Protection.....		
29	1	1		1911-3053-01	Stoppkontakt.....	Stop switch.....		
32	1	1		1911-3321-01	Jordkabel.....	Ground cable.....		
33	1	1		1911-3320-01	Elektronikspole.....	Electronic coil.....		
34	1	1		1911-3418-01	Fjäder.....	Spring.....		
35	2	2		1911-3017-01	Bricka.....	Washer.....		
36	2	2		1911-3251-01	Skruv.....	Screw.....		
37	1	1		1911-3247-01	Skruv.....	Screw.....		



Utgåva Issue		Bildnr Picture No		SP 370- SP 410 MC 382 FÖRGASARE		SP 370- SP 410 MC 382 CARBURETTOR		Sida Page
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	4113 4114	MC 382						
1	2	2		1911-3007-01	Skruv	Screw		
2	1	1		1911-3513-01	Ljuddämpare	Muffler		
3	1	1		1911-3442-01	• Packning	• Gasket		
5	1	1		1911-3506-01	Bränsleledning	Fuel line		
7	1	1		1911-3455-01	Chokearm	Choke lever		
8	1	1		1911-3990-01	Insugningsrör	Air intake manifold		
8A	1	1		1911-3951-01	Kabel	Cable		
9	2	2		1911-3264-01	Skruv	Screw		
10	1	1		1911-3465-01	Gummihylsa	Grommet		
11	1	1		1911-3562-01	Förgasare kpl	Carburettor assy		Walbro WT534
12	1	1		1911-3440-01	• Packning	• Gasket		
13	1	1		1911-3545-01	Gaswire m.hölje	Throttle cable w.sh		
14	1	1		1911-3485-01	Insugningsrör	Intake manifold		
15	1	1		1911-3444-01	• Packning	• Gasket		
16	1	1		1911-3460-01	• Primerpump	• Primer pump		
17	1	1		1911-3381-01	• Nålventil	• Inlet needle		
18	1	1		1911-3613-01	• Membran- packningssats...	• Diaphragm- gasket set		
19	1	1		1911-3615-01	Packningssats	Gasket set		Inkl. pos 3,12,15,20
20	2	2		1911-3435-01	• Cylinderpackning	• Cylinder gasket		