



Genuine Spare Parts




Joist
Spareparts
Joist




Utgåva Issue		Bildnr Picture No		SP 340 VEVHUS		SP 340 CRANKCASE		Sida Page	
2003-21		1356						12	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	4110								
X	1	1			1911-3858-01	Vevhus kpl.....	Crankcase assy		Inkl. pos 12- 14, 22
	2	1			1911-3534-01	Tanklock	Tank cap		
	3	1			1911-3534-01	Tanklock	Tank cap		
	4	1			1911-3539-01	Oljepump	Oil pump		D = 8 mm
X	4	1			1911-3860-01	Oljepump	Oil pump		D = 9 mm
	5	1			1911-3462-01	Distans	Spacer		
	6	2			1911-3247-01	Skruv	Screw		
	7	1			1911-3368-01	Hållare	Retainer		
	8	1			1911-3225-01	Svärd	Bar		14" (3/8"x0.050)
	9	1			1911-3295-01	Kedjespännskruv	Chain tension screw		
	10	1			1911-3242-01	Skruv	Screw		
	11	1			1911-3387-01	Kedjespännare	Chain tensioner		
	12	1			1911-3445-01	• Lock-oljetillförsel	• Cap-oil supply		
	13	1			1911-3369-01	• Förstärkning	• Reinforcement		
	14	1			1911-3554-01	• Oljeslang	• Oil tube		
	15	1			1911-3365-01	Svärdplatta	Bar plate		
	16	1			1911-3233-01	Kedja (50E).....	Chain (50E)		91VG (3/8")
	17	1			1911-3541-01	Kopplingshus.....	Clutch housing		Inkl. pos 20
	18	1			1911-3505-01	Bränsleledning.....	Fuel line.....		
	19	1			1911-3150-01	Bränslefilter	Intake filter		
	20	1			1911-3296-01	• Mutter	• Nut		
	21	1			1911-3369-01	Förstärkning	Reinforcement.....		
	22	1			1911-3560-01	• Andningsventil.....	• Breather valve		
	23	1			1911-3249-01	Skruv	Screw		
	24	1			1911-3519-01	Kedjeskydd	Chain cover		14"
	25	1			1911-3557-01	Tbh- påse.....	Accessory bag.....		
	26	1			8215-3207-01	Bruksanvisning.....	Owner's manual		




Utgåva Issue 2003-21		Bildnr Picture No 1357		SP 340 LUFFFILTER KEDJEBROMS		SP 340 AIR FILTER CHAIN BRAKE		Sida Page 14	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	4110								
1	1				1911-3364-01	Bromsband.....	Brake band.....		
2	1				1911-3269-01	Bricka.....	Washer.....		
3	1				1911-3249-01	Skruv.....	Screw.....		
4	1				1911-3540-01	Kedjebromsarm.....	Chain brake lever.....		
5	1				1911-3310-01	Pinne.....	Pin.....		
6	1				1911-3366-01	Fjäder.....	Spring.....		
7	1				1911-3482-01	Bromskåpa.....	Brake cover.....		
8	2				1911-3002-01	Skruv.....	Screw.....		
9	1				1911-3415-01	Fjäder.....	Spring.....		
10	1				1911-3361-01	Bromsplåt.....	Brake plate.....		
11	1				1911-3311-01	Pinne.....	Pin.....		
12	1				1911-3358-01	Bussning.....	Bushing.....		
14	3				1911-3001-01	Skruv.....	Screw.....		
15	1				1911-3543-01	Cylinderkåpa.....	Cylinder cover.....		
16	1				1911-3575-01	Handskydd.....	Hand guard.....		
17	1				1911-3617-01	Lufffilter.....	Air filter.....		
19	1				1911-3487-01	Primerknapp.....	Air purge cap button.....		
20	1				1911-3416-01	Fjäder.....	Spring.....		
21	1				1911-3486-01	Primerhandtag.....	Air purge button.....		



Utgåva Issue		Bildnr Picture No		SP 340 HANDTAG		SP 340 HANDLE		Sida Page	
2003-21		1358						16	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	4110								
1	1				1911-3573-01 Handtag	Handle			
2	1				1911-3574-01 Handtagskåpa	Handle cover			
3	1				1911-3453-01 Gasreglage	Throttle lever			
4	1				1911-3417-01 Fjäder	Spring			
5	1				1911-3454-01 Säkerhetsspärr	Safety lever			
6	3				1911-3414-01 Fjäder	Spring			
7	2				1911-3367-01 Bricka	Washer			
8	3				1911-3002-01 Skruv	Screw			
9	6				1911-3248-01 Skruv	Screw			
10	1				1911-3007-01 Skruv	Screw			
11	1				1911-3022-01 Mutter	Nut			
12	3				1911-3015-01 Bricka	Washer			






Utgåva Issue		Bildnr Picture No		SP 340 START		SP 340 STARTER		Sida Page	
2003-21		1359						18	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	4110								
1	1				1911-3542-01 Start kpl.....	Starter assy.....		Inkl. pos 2 - 11	
2	1				1911-3130-01 • Startsnöre.....	• Starter cord.....			
3	1				1911-3479-01 • Starhandtag.....	• Starter handle.....			
4	3				1911-3001-01 • Skruv.....	• Screw.....			
5	1				1911-3176-01 • Startfjäder.....	• Starter spring.....			
6	1				1911-3372-01 • Bussning.....	• Bushing.....			
7	1				1911-3096-01 • Skiva.....	• Disc.....			
8	1				1911-3483-01 • Linhjul.....	• Starter pulley.....			
9	2				1911-3480-01 • Startspärr.....	• Starter hook.....			
10	1				1911-3484-01 • Fäste- startspärr.....	• Guide- starter hook.....			
11	1				1911-3423-01 • Hållare.....	• Retainer.....			



Utgåva Issue		Bildnr Picture No		SP 340 CYLINDER VEVAXEL		SP 340 CYLINDER CRANKSHAFT		Sida Page	
2003-21		1360A						20	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	4110								
1	1				1911-3280-01	Mutter.....	Nut.....		
2	1				1911-3268-01	Bricka.....	Washer.....		
3	1				1911-3567-01	Svånghjul.....	Flywheel.....		
4	1				1911-3048-01	Svånghjulskil.....	Flywheel key.....		
5a	1				1911-3301-01	Tätningring.....	Seal ring.....		
5b	1				1911-3302-01	Tätningring.....	Seal ring.....		
6	2				1911-3297-01	Kullager.....	Ball bearing.....		
7	2				1911-3072-01	Bricka.....	Washer.....		
8	1				1911-3532-01	Vevaxel kpl.....	Crankshaft assy.....		Inkl. pos 19
9	1				1911-3488-01	Dammskydd.....	Dust guard.....		
10	1				1911-3538-01	Koppling.....	Clutch.....		
11	1				1911-3041-01	Nållager.....	Needle bearing.....		
12	1				1911-3507-01	Kedjedrev.....	Sprocket.....		
13	1				1911-3338-01	Drevbricka.....	Sprocket washer.....		
14	1				1911-3330-01	Låsring.....	Circlip.....		
15	2				1911-3069-01	•• Låsring.....	•• Lock ring.....		
18	1				1911-3051-01	•• Kolvbult.....	•• Piston pin.....		
19	1				1911-3042-01	• Nållager.....	• Needle bearing.....		
20	4				1911-3006-01	Skruv.....	Screw.....		
21	4				1911-3274-01	Bricka.....	Washer.....		
22	1				1911-3304-01	•• Kolvring.....	•• Piston ring.....		
23	1				1911-3861-01	• Kolv kpl.....	• Piston assy.....		Inkl. pos 15, 18, 22
24	1				1911-3597-01	Cylinder- kolv kpl.....	Cylinder- piston assy.....		Inkl. pos 23
25	1				9400-0258-00	Tändstift.....	Spark plug.....		Champion CJ7Y
26	1				1911-3470-01	Tändstiftshatt.....	Spark plug cover.....		
27	1				1911-3421-01	Fjäder.....	Spring.....		
28	1				1911-3434-01	Skydd.....	Protection.....		
29	1				1911-3053-01	Stoppkontakt.....	Stop switch.....		
30	4				1911-3022-01	Mutter.....	Nut.....		
32	1				1911-3321-01	Jordkabel.....	Ground cable.....		
33	1				1911-3320-01	Elektronikspole.....	Electronic coil.....		
34	1				1911-3418-01	Fjäder.....	Spring.....		
35	2				1911-3017-01	Bricka.....	Washer.....		
36	2				1911-3251-01	Skruv.....	Screw.....		
37	1				1911-3247-01	Skruv.....	Screw.....		

X



Utgåva Issue		Bildnr Picture No		SP 340 FÖRGASARE		SP 340 CARBURETTOR		Sida Page	
2003-21		1361						22	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	4110								
1	2			1911-3007-01	Skruv.....	Screw.....			
2	1			1911-3513-01	Ljuddämpare.....	Muffler.....			
3	1			1911-3442-01	• Packning.....	• Gasket.....			
4	2			1911-3022-01	Mutter.....	Nut.....			
5	1			1911-3506-01	Bränsleledning.....	Fuel line.....			
7	1			1911-3451-01	Chokereglage.....	Choke lever.....			
8	1			1911-3564-01	Luftkollector.....	Air intake manifold.....			
9	2			1911-3264-01	Skruv.....	Screw.....			
10	1			1911-3465-01	Gummihylsa.....	Grommet.....			
11	1			1911-3562-01	Förgasare kpl.....	Carburettor assy.....		Walbro WT534	
12	1			1911-3440-01	• Packning.....	• Gasket.....			
13	1			1911-3545-01	Gaswire m.hölje.....	Throttle cable w.sh.....			
14	1			1911-3485-01	Insugningsrör.....	Intake manifold.....			
15	1			1911-3444-01	• Packning.....	• Gasket.....			
16	1			1911-3460-01	• Primerpump.....	• Primer pump.....			
17	1			1911-3381-01	• Nålventil.....	• Inlet needle.....			
18	1			1911-3613-01	• Membran- packningssats...	• Diaphragm- gasket set.....			
19	1			1911-3615-01	Packningssats.....	Gasket set.....		Inkl. pos 3,12,15,20	
20	2			1911-3435-01	• Cylinderpackning.....	• Cylinder gasket.....			