

# Genuine Spare Parts


---




Spareparts  
Joist



Utgåva Issue 2008- 12		Bildnr Picture No 2420		SILEX 50- G SILEX 50- H SILEX 50R- B JORDFRÄS		SILEX 50- G SILEX 50- H SILEX 50R- B TILLER		Sida Page 232	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	3121 -11	3119 -11	3122 -11						
X	1	1	1	1	1483-2182-01	Panel- gul.....	Panel- yellow.....		
X	1	1	1	1	1483-2182-02	Panel- röd.....	Panel- red.....		
	2	1	1	1	1483-2005-01	Skruv.....	Screw.....		
	3	1	1	1	1483-2008-01	Kopplingshandtag.....	Clutch handle.....		
	4			1	9948-0655-16	Skruv.....	Screw.....		
	5	1	1	1	9747-0531-02	Mutter.....	Nut.....		
	6			1	1483-2018-01	Stöd.....	Reverse lever support.....		
	7			1	1483-2017-01	Kopplingshandtag- back.....	Clutch lever- reverse.....		
	8			1	9699-0100-02	Bricka.....	Washer.....		
	9			1	9747-0631-02	Låsmutter.....	Lock nut.....		
	10	1	1	1	9898-0855-12	Skruv.....	Screw.....		
	11	1	1	1	1483-2053-01	Kopplingswire.....	Clutch cable.....		
X	12			1	1483-2178-01	Styrrör- hö.....	Handlebar tube- RH.....		
X	12	1	1	1	1483-2179-01	Styrrör- hö.....	Handlebar tube- RH.....		
	13	1	1	1	9699-0025-02	Planbricka.....	Washer.....		
	14	1	1	1	81007279/1	Gasarm.....	Throttle lever.....		
X	15	1	1	1	322981740/1	Gasreglagehus.....	Throttle box.....		
	16	1	1	1	12508100/0	Låsbricka.....	Washer.....		
	17	1	1	1	22171006/0	Distans.....	Spacer.....		
X	18	1	1	1	1483-2177-01	Styrrör- vä.....	Handlebar tube- LH.....		
	19	2	2	2	9747-0631-02	Låsmutter.....	Lock nut.....		
X	20	1	1	1	1483-2180-01	Panelstag.....	Panel bracket.....		
	21	2	2	2	9699-0122-02	Bricka.....	Washer.....		
	22	2	2	2	9997-0635-12	Skruv.....	Screw.....		
	23	1	1	1	9699-0035-02	Planbricka.....	Flat washer.....		
X	24	2	2	2	1483-2079-01	Handtagsgrepp.....	Handgrip.....		
	25	1	1	1	9699-0024-02	Planbricka.....	Flat washer.....		
	26	1	1	1	9799-0531-02	Mutter.....	Nut.....		
	27	1	1	1	1483-2006-01	Ratt m.mutter.....	Knob w.nut.....		
	28	5	5	5	9747-0831-02	Mutter.....	Lock nut.....		
X	29	2	2	2	1483-2200-01	Skruv.....	Screw.....		
	30	2	2	2	9699-0056-02	Planbricka.....	Flat washer.....		
	31			1	1483-2051-01	Kopplingswire- back.....	Clutch cable- reverse.....		
	32			1	1483-2019-01	Fjäder.....	Spring.....		
	33	1	1	1	1483-2046-01	Styrförstärkning.....	Handle reinforcement.....		
X	36	1	1	1	9997-0813-02	Skruv.....	Screw.....		
	37	1	1	1	9997-0812-02	Skruv.....	Screw.....		
	38	1	1	1	1483-2045-01	Ratt utan mutter.....	Knob w/o nut.....		
X	39	1	1	1	1483-2181-01	Gaswire.....	Throttle cable.....		
	40	1	1	1	1483-2042-01	Styrfäste- gul.....	Handle support- yellow.....		
X	40	1	1	1	1483-2042-02	Styrfäste- röd.....	Handle support- red.....		
	41	3	3	3	1483-2073-01	Tallriksbricka.....	Cup washer.....		
	42	4	4	4	9959-0820-16	Skruv.....	Screw.....		
	43	1	1	1	1483-2044-01	Låshandtag.....	Handlebar lever.....		
	44	1	1	1	1483-2043-01	Platta- gul.....	Plate- yellow.....		
X	44	1	1	1	1483-2043-02	Platta- röd.....	Plate- red.....		
	45	1	1	1	9699-0121-02	Planbricka.....	Flat washer.....		
	46	1	1	1	9747-1231-02	Låsmutter.....	Lock nut.....		
	47	4	4	3	9699-0028-02	Planbricka.....	Flat washer.....		
	49			1	1483-2021-01	Vinkelfäste.....	Wire support plate.....		
	50	1	1	1	1483-2029-01	Platta- gul.....	Plate- yellow.....		
X	50	1	1	1	1483-2029-02	Platta- röd.....	Plate- red.....		



B  
B



56

Utgåva Issue		Bildnr Picture No		SILEX 50- G SILEX 50- H SILEX 50R- B JORDFRÄS		SILEX 50- G SILEX 50- H SILEX 50R- B TILLERS		Sida Page	
2008- 12		2421						234	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	3121 -11	3119 -11	3122 -11						
1	1	1	1	1483-2076-01	Skruv.....	Screw.....			
2	1	1	1	1483-2004-01	Spännrulle.....	Idler pulley.....			
3	1	1	1	1483-2032-01	Spännarm.....	Tension arm.....			
4	1	1	1	9747-1231-02	Låsmutter.....	Lock nut.....			
5	1	1	1	9997-1020-16	Skruv.....	Screw.....			
6	1	1	1	9699-0105-02	Bricka.....	Washer.....			
7	1	1	1	1483-2001-01	Bussning.....	Bushing.....			
8	1	1	1	1483-2020-01	Distans.....	Spacer.....			
9	1	1	1	1483-2033-01	Returfjäder.....	Return spring.....			
10			1	1483-2036-01	Drivrem- back.....	Belt- reverse.....			
11	1	1	1	9747-1031-02	Låsmutter.....	Lock nut.....			
12			2	9799-1031-02	Mutter.....	Nut.....			
13			2	9699-0035-02	Planbricka.....	Flat washer.....			
14	1	1	1	1483-2035-01	Drivrem- fram.....	Belt- forward.....			
15			1	1483-2031-01	Spännarm- back.....	Tension arm- reverse.....			
16	1	1	1	1483-2040-01	Transm.hus- gul.....	Transm.housing- yellow.....			
X 16	1	1	1	1483-2040-02	Transm.hus- röd.....	Transm.housing- red.....			
17			1	9599-0052-02	Saxsprint.....	Split pin.....			
18			2	9699-0035-02	Planbricka.....	Flat washer.....			
19	1	1	1	12139100/0	Kil.....	Key.....			
20A	1	1		1483-2027-01	Distans.....	Spacer.....			
20B			1	9799-1231-02	Mutter.....	Nut.....			
21A	1	1		1483-2028-01	Remskiva.....	Belt pulley.....			
21B			1	1483-2025-01	Remskiva.....	Belt pulley.....			
22	1	1	1	1483-2002-01	Remskiva.....	Belt pulley.....			
23			2	1483-2003-01	Spännrulle.....	Idler roller.....			
24	1	1	1	9699-0035-02	Planbricka.....	Flat washer.....			
25			1	1483-2030-01	Remstyrning.....	Belt guide.....			
26	4	4	4	9959-0816-16	Skruv.....	Screw.....			
28	1	1	1	9987-5225-16	Skruv.....	Screw.....			
29			2	9997-1025-16	Skruv.....	Screw.....			
30	4	4	3	9747-0831-02	Mutter.....	Lock nut.....			
31	6	6	6	9699-0028-02	Planbricka.....	Flat washer.....			
32		3	1	9997-0835-12	Skruv.....	Screw.....		L = 35 mm	
32	3			9997-0840-16	Skruv.....	Screw.....		L = 40 mm	
33			2	9997-0860-16	Skruv.....	Screw.....		L = 60 mm	
34	1	1	1	1483-2071-01	Kullager.....	Ball bearing.....			
35	1	1	1	1483-2068-01	Seegerring.....	Seeger ring.....			
36	1	1	1	1483-2000-01	Distans.....	Spacer.....			
37	1	1	1	9997-0820-16	Skruv.....	Screw.....			
38	1	1	1	1483-2060-01	Låsratt.....	Locking knob.....			
39	1	1	1	9997-0825-16	Skruv.....	Screw.....			
40	1	1	1	1483-2045-01	Ratt utan mutter.....	Knob w/o nut.....			
41	1	1	1	1483-2072-01	Nållager.....	Needle roller case.....			
42	1	1	1	1483-2026-01	Snäckskruv.....	Endless screw.....			
43	1	1	1	1483-2023-01	Rotor kpl- hö.....	Tine assy- RH.....			
44	1	1	1	9747-0831-02	Mutter.....	Lock nut.....			
45	1	1	1	1483-2056-01	Hjulstöd.....	Wheel support.....			
46	2	2	2	1483-2061-01	Stödhjul.....	Wheel.....			
47	1	1	1	1483-2059-01	Hjulaxel.....	Wheel axle.....			
48	2	2	2	1483-2074-01	Låsning.....	Fixing device.....			
49	1	1	1	1483-2039-01	Växelhus kpl- gul.....	Gear housing- yellow.....			
X 49	1	1	1	1483-2039-02	Växelhus kpl- röd.....	Gear housing- red.....			
50	1	1	1	1483-2075-01	Lock.....	Cap.....			
51	2	2	2	1483-2070-01	Tätningring.....	Seal ring.....			
52	2	2	2	1483-2010-01	Dammskydd.....	Dust protection.....			
53	6	6	6	9997-1050-16	Skruv.....	Screw.....			
55	1	1	1	1483-2064-01	Bromssporre.....	Depth skid.....			
56	6	6	6	9747-1031-02	Låsmutter.....	Lock nut.....			
58	2	2	2	1483-2022-01	Sidotalrik.....	Side disc.....			
59	1	1	1	1483-2024-01	Rotor kpl- vä.....	Tine assy- LH.....			
60	2	2	2	1483-2062-01	Hjulhylsa.....	Wheel spacer.....			