


# Genuine Spare Parts

---



Joist  
Spareparts  
Joist




Utgåva Issue		Bildnr Picture No		ESTATE TORNADO ESTATE TORNADO HST KAROSS		ESTATE TORNADO ESTATE TORNADO HST BODY WORK		Sida Page
2003-11		1561						88
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2521	2522						
1	1	1		1136-1038-01	Motorhuv.....	Engine hood.....		Inkl. pos 2, 5
2	1	1		1136-0905-01	• Platta.....	• Plate.....		
3	2	2		1136-0230-01	Bult.....	Bolt.....		
4	2	2		1136-0009-01	Låsplatta.....	Lock plate.....		
5	1	1		1136-0888-01	• Grill.....	• Grill.....		
6	1	1		1136-0866-01	Motorhuv- nedre.....	Engine hood- lower.....		
7	1	1		1136-0923-01	Avskiljare.....	Intake separator.....		
10	2	2		1136-0179-01	Huvskydd.....	Grommet.....		
11	1	1		1136-0871-01	Instrumentbräda.....	Dashboard.....		
14	2	2		9848-8013-16	Skruv.....	Screw.....		
15	2	2		1136-0010-01	Låsplatta.....	Lock plate.....		
16	3	3		9836-9618-12	Skruv.....	Screw.....		
17	1	1		1136-0926-01	Stöd.....	Support.....		
18	1			1136-0475-01	Hjulkäpa.....	Wheel cover.....		Inkl. pos 19, 20 Inkl. pos 19, 20
18		1		1136-0476-01	Hjulkäpa.....	Wheel cover.....		
19	1	1		1136-0148-01	• Fotstegsskydd- hö.....	• Footboard cover- RH.....		
20	1	1		1136-0147-01	• Fotstegsskydd- vä.....	• Footboard cover- LH.....		
21	6	6		9836-9635-12	Skruv.....	Screw.....		
22	4	4		9836-9618-12	Skruv.....	Screw.....		
23	1	1		9836-9525-12	Skruv.....	Screw.....		
24	5	5		9699-0060-02	Planbricka.....	Flat washer.....		
25	4	4		9699-0085-02	Planbricka.....	Flat washer.....		
31	1	1		1136-0440-01	Gasreglage.....	Throttle control.....		
32	2	2		9997-0412-16	Skruv.....	Screw.....		
33	2	2		9683-0010-02	Bricka.....	Washer.....		
34	1	1		1136-0192-01	Knopp.....	Handle.....		
35	1	1		9865-0412-16	Skruv.....	Screw.....		
36	1	1		9799-0431-02	Mutter.....	Nut.....		
41	1	1		1136-0315-01	Sits.....	Seat.....		
43	1	1		1136-0252-01	Sitsplatta.....	Seat plate.....		
44	4	4		9997-0820-16	• Skruv.....	• Screw.....		
45	4	4		9683-0030-02	• Låsbricka.....	• Lock washer.....		
46	4	4		9699-0056-02	• Planbricka.....	• Flat washer.....		
47	1	1		1136-0891-01	Fjäder.....	Spring.....		
48	1	1		9997-0512-16	Skruv.....	Screw.....		
49	1	1		9747-0531-02	Mutter.....	Nut.....		
51	1	1		1136-0360-01	Ratt.....	Steering wheel.....		
52	1	1		9595-0272-00	• Stift.....	• Pin.....		
54	1	1		1136-0942-01	Kam.....	Cam.....		
55	2	2		1136-0820-01	Skruv.....	Screw.....		
56	2	2		9699-0018-02	Bricka.....	Washer.....		
57	2	2		9747-0531-02	Mutter.....	Nut.....		
61	1	1		1136-0869-01	Käpa.....	Cover.....		
62	2	2		9836-9635-12	Skruv.....	Screw.....		
63	2	2		9699-0035-02	Planbricka.....	Flat washer.....		
64	2	2		9836-9618-12	Skruv.....	Screw.....		
81	1	1		1136-0275-01	Skydd- övre.....	Guard- upper.....		
82	1	1		1136-0276-01	Skydd- nedre.....	Guard- lower.....		
83	2	2		9847-8038-16	Skruv.....	Screw.....		
84	2	2		9699-0024-02	Planbricka.....	Flat washer.....		
85	2	2		1136-0010-01	Låsplatta.....	Lock plate.....		
91	1	1		1136-0318-01	Bränsletank.....	Fuel tank.....		
92	1	1		1136-0344-01	Tanklock.....	Tank cap.....		
93	1	1		1136-0327-01	Tankfäste.....	Tank support.....		
94	1	1		9848-8013-16	Skruv.....	Screw.....		
99	1	1		1136-1108-01	Tillbehörspåse.....	Key outfit.....		Inkl. pos 44 - 46, 52




Utgåva Issue 2003-11		Bildnr Picture No 1562		ESTATE TORNADO ESTATE TORNADO HST DEKALER		ESTATE TORNADO ESTATE TORNADO HST LABELS		Sida Page 90	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2521	2522							
1	1	1		1136-0832-01	Dekal .....	Label .....			
2	1	1		1136-0026-01	Dekal .....	Label .....			
3	1	1		1136-0020-01	Dekal .....	Label .....			
5	1	1		1136-0031-01	Dekal .....	Label .....			
6	1			1136-0027-01	Dekal .....	Label .....			
7	1	1		1136-0028-01	Dekal .....	Label .....			
8	1	1		1136-0029-01	Dekal .....	Label .....			
9	2	2		1136-0021-01	Dekal .....	Label .....			
11	1	1		1136-1217-01	Dekal .....	Label .....			

X

Joist Spareparts Joist




Utgåva Issue 2003-11		Bildnr Picture No 1563		ESTATE TORNADO ESTATE TORNADO HST CHASSI		ESTATE TORNADO ESTATE TORNADO HST CHASSIS		Sida Page 92	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2521	2522							
X	1	1	1	1136-1290-01	Ram.....	Frame.....		Inkl. pos 2	
X	2	1	1	1136-1226-01	• Bussning.....	• Bushing.....			
	3	1	1	1136-0548-01	Fotstegsstöd- hö.....	Footboard support- RH.....			
	4	1	1	1136-0549-01	Fotstegsstöd- vä.....	Footboard support- LH.....			
	5	4	4	9898-0645-12	Skruv.....	Screw.....			
	6	4	4	9699-0060-02	Planbricka.....	Flat washer.....			
	7	4	4	9747-0631-02	Låsmutter.....	Lock nut.....			
	8	1	1	1136-0553-01	Ljuddämparskydd.....	Muffler protection.....			
	9	2	2	1136-0061-01	Plugg.....	Cap.....			
	10	4	4	9847-8216-16	Skruv.....	Screw.....			
	11	1	1	1136-0259-01	Huvfäste- hö.....	Hood plate- RH.....			
	12	1	1	1136-0260-01	Huvfäste- vä.....	Hood plate- LH.....			
	13	4	4	9847-8009-16	Skruv.....	Screw.....			
	21		1	1136-0267-01	Remstyrning.....	Belt guide.....			
	22		2	9739-0631-22	Mutter.....	Nut.....			
	23	2	2	1136-0261-01	Platta.....	Plate.....			
	24	2	2	9997-0820-16	Skruv.....	Screw.....			
	25	2	2	9747-0831-02	Mutter.....	Lock nut.....			
	26	2	2	1136-0907-01	Remstyrning.....	Belt guide.....			
	27	2	2	1136-0004-01	Fyrkantmutter.....	Square nut.....			
	28	1	1	1136-0881-01	Remstyrning.....	Belt guide.....			
	29	1	1	1136-0896-01	Fjäder.....	Spring.....			
X	30	2	2	1136-1247-01	Platta.....	Plate.....			
	31	2	2	9847-8216-16	Skruv.....	Screw.....			
	32	2	2	9699-0035-02	Planbricka.....	Flat washer.....			
	41	1	1	1136-0906-01	Plåt- bak.....	Plate- rear.....			
	42	2	2	9997-0825-16	Skruv.....	Screw.....			
	43	1	1	1136-1051-01	Förstärkning.....	Reinforcement.....			
	45	1	1	9997-0816-16	Skruv.....	Screw.....			
	46	1	1	9739-0831-22	Mutter.....	Nut.....			
	48	2	2	9699-0090-02	Planbricka.....	Flat washer.....			
	49	2	2	9747-0831-02	Mutter.....	Lock nut.....			
	50	1	1	9997-0840-16	Skruv.....	Screw.....			
	51	1	1	9699-0090-02	Planbricka.....	Flat washer.....			
	52	1	1	9747-0831-02	Mutter.....	Lock nut.....			
	53	2	2	9739-0831-22	Mutter.....	Nut.....			
	61	1	1	1136-0337-01	Sitsfäste.....	Seat support.....			
	62	2	2	1136-0301-01	Förstärkningsstag.....	Reinforcement plate.....			
	63	4	4	9997-0612-16	Skruv.....	Screw.....			
	64	4	4	9739-0631-22	Mutter.....	Nut.....			
	65	4	4	9997-0620-16	Skruv.....	Screw.....			
	66	4	4	9699-0060-02	Planbricka.....	Flat washer.....			
	67	4	4	9739-0631-22	Mutter.....	Nut.....			
	68	1	1	1136-0302-01	Förstärkningsstag.....	Reinforcement plate.....			
	69	2	2	9699-0056-02	Planbricka.....	Flat washer.....			
	70	2	2	1136-0202-01	Fjäder.....	Spring.....			
	71	2	2	9699-0090-02	Planbricka.....	Flat washer.....			
	72	2	2	9739-0831-22	Mutter.....	Nut.....			
	73	2	2	1136-0358-01	Skruv.....	Screw.....			
	74	2	2	1136-0003-01	Fyrkantmutter.....	Square nut.....			
	76	2	2	1136-0321-01	Vinkelfäste.....	Bracket.....			
	77	2	2	9997-0816-16	Skruv.....	Screw.....			
	78	2	2	9739-0831-22	Mutter.....	Nut.....			
	79	2	2	1136-0086-01	Bult.....	Bolt.....			
	80	2	2	9712-0831-02	Låsmutter.....	Lock nut.....			
	81	2	2	9997-0512-16	Skruv.....	Screw.....			
	82	1	1	1136-0322-01	Vinkelfäste.....	Bracket.....			
	83	2	2	9747-0531-02	Mutter.....	Nut.....			
	84	1	1	1136-0925-01	Vinkelfäste.....	Angle bracket.....			
	85	2	2	9847-8009-16	Skruv.....	Screw.....			
	91	1	1	1136-0333-01	Stöd.....	Support.....			
	92	4	4	9997-0612-16	Skruv.....	Screw.....			
	93	4	4	9739-0631-22	Mutter.....	Nut.....			








Utgåva Issue		Bildnr Picture No		ESTATE TORNADO ESTATE TORNADO HST STYRNING		ESTATE TORNADO ESTATE TORNADO HST STEERING		Sida Page	
2003-11		1213A						94	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2521	2522							
1	1	1		1136-0466-01	Framaxel kpl .....	Front wheel axle assy .....		Inkl. pos 2, 3	
2	4	4		1136-0121-01	• Bussning .....	• Bushing .....			
3	2	2		9501-0500-00	• Smörjnippel .....	• Grease joint .....			
4	1	1		1136-0485-01	Hjulspindel- hö .....	Stub axle- RH .....			
5	1	1		9652-0015-04	Låsring .....	Retaining ring .....			
6	1	1		1136-0486-01	Hjulspindel- vä .....	Stub axle- LH .....			
7	1	1		1136-0349-01	Parallellstag .....	Tie rod .....			
8	2	2		1136-0092-01	Kulled .....	Ball joint .....			
9	2	2		9747-1031-02	Låsmutter .....	Lock nut .....			
11	1	1		1136-0188-01	Styrmarm .....	Steering arm .....			
12	1	1		9997-1055-12	Skruv .....	Screw .....			
13	1	1		9747-1031-02	Låsmutter .....	Lock nut .....			
14	1	1		1136-0165-01	Distans .....	Spacer .....			
15	1	1		9997-1260-02	Skruv .....	Screw .....			
16	2	2		1136-0016-01	Bricka .....	Washer .....			
17	1	1		9683-0055-02	Låsbricka .....	Lock washer .....			
18	1	1		9799-1231-02	Mutter .....	Nut .....			
31	1	1		1136-0335-01	Stöd .....	Support .....			
32	4	4		9997-0816-16	Skruv .....	Screw .....			
33	4	4		9747-0831-02	Mutter .....	Lock nut .....			
34	1	1		1136-0541-01	Rattstångsfäste .....	Support .....			
35	4	4		9847-8216-16	Skruv .....	Screw .....			
36	1	1		1136-0124-01	Bussning .....	Bushing .....			
37	1	1		1136-0250-01	Rattstång .....	Steering column .....			
38	1	1		1136-0263-01	Styrdrev .....	Steering pinion .....			
39	1	1		9595-0262-00	Spännstift .....	Locating pin .....			
40	1	1		9699-0037-02	Bricka .....	Washer .....			
41	1	1		1136-0008-01	Låsplatta .....	Lock plate .....			
42	1	1		1136-0128-01	Bussning .....	Bushing .....			
43	1	1		1136-0246-01	Pinnbult .....	Stud bolt .....			
44	1	1		9799-1031-02	Mutter .....	Nut .....			
45	2	2		1136-0310-01	Bricka .....	Washer .....			
46	1	1		1136-0320-01	Styrsektor .....	Steering sector .....			
47	1	1		1136-0311-01	Bricka .....	Washer .....			
48	1	1		1136-0083-01	Fjäderbricka .....	Elastic washer .....			
49	1	1		9699-0035-02	Planbricka .....	Flat washer .....			
50	2	2		9799-1031-02	Mutter .....	Nut .....			
51	2	2		1136-0087-01	Bricka .....	Washer .....			
52	1	1		1136-0015-01	Bricka .....	Washer .....			
53	1	1		9599-0070-02	Saxsprint .....	Split pin .....			
54	1	1		9747-1031-02	Låsmutter .....	Lock nut .....			
55	1	1		1136-0111-01	Styrstag .....	Steering rod .....			
56	2	2		1136-0092-01	Kulled .....	Ball joint .....			
58	2	2		9747-1031-02	Låsmutter .....	Lock nut .....			
59		1		1136-0279-01	Brytarskydd .....	Micro protection .....			
60		2		9847-7813-16	Skruv .....	Screw .....			
61	2	2		9699-0035-02	Planbricka .....	Flat washer .....			
72	2	2		1136-0454-01	Fälg .....	Rim .....			
73	4	4		1136-0157-01	Lager .....	Bearing .....			
74	2	2		1136-0269-01	Däck (Turf Saver) .....	Tire (Turf Saver) .....			
74	2	2		1136-0271-01	Däck (Deli) .....	Tire (Deli) .....			
75	2	2		1136-0305-01	Bricka .....	Washer .....			
76	2	2		9652-0015-04	Låsring .....	Retaining ring .....			
77	2	2		1136-0081-01	Navkapsel .....	Hub cap .....			
78	2	2		1136-0359-01	Ventil .....	Valve .....			




Utgåva Issue		Bildnr Picture No		ESTATE TORNADO BROMSREGLAGE VÅXELREGLAGE		ESTATE TORNADO BRAKE CONTROL GEAR SHIFTER CONTROL		Sida Page	
2003-11		1214A						96	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2521								
1	1				1136-0506-01	Bromspedal .....	Brake pedal .....		
2	1				1136-0152-01	Pedalskydd .....	Pedal cover .....		
3	1				1136-0254-01	Bygel .....	Clamp .....		
4	1				1136-0255-01	Bygel .....	Clamp .....		
5	6				9847-8016-16	Skruv .....	Screw .....		
6	1				1136-0116-01	Bromsstång .....	Brake rod .....		
7	1				1136-0244-01	Ledbult .....	Pivot bolt .....		
8	1				1136-0218-01	Fjäder .....	Spring .....		
9	2				9699-0035-02	Planbricka .....	Flat washer .....		
10	1				9799-1031-02	Mutter .....	Nut .....		
11	1				1136-0172-01	Distans .....	Spacer .....		
12	1				1136-0329-01	Bygel .....	Clamp .....		
13	1				9699-0060-02	Planbricka .....	Flat washer .....		
14	1				9747-0631-02	Låsmutter .....	Lock nut .....		
15	1				9699-0090-02	Planbricka .....	Flat washer .....		
16	1				1136-0009-01	Låsplatta .....	Lock plate .....		
17	1				1136-0441-01	Spårraxel .....	Axle .....		
18	1				1136-0217-01	Fjäder .....	Spring .....		
19	2				1136-0256-01	Bygel .....	Plate .....		
20	4				9847-8016-16	Skruv .....	Screw .....		
21	1				1136-0119-01	P- bromsarm .....	P- brake lever .....		
22	1				9675-0011-00	Starlock .....	Starlock .....		
23	1				1136-0392-01	Knopp .....	Knob .....		
24	1				9747-1031-02	Låsmutter .....	Lock nut .....		
31	1				1136-0233-01	Pinnbult .....	Stud bolt .....		
32	1				9712-0831-02	Låsmutter .....	Lock nut .....		
33	1				1136-0088-01	Bricka .....	Washer .....		
34	1				1136-0529-01	Spakhållare .....	Gear lever bracket .....		
35	1				1136-0490-01	Växelspak .....	Gear lever .....		
36	1				1136-0212-01	Fjäder .....	Spring .....		
37	1				9997-0880-16	Skruv .....	Screw .....		
38	1				9747-0831-02	Mutter .....	Lock nut .....		
39	1				9699-0056-02	Planbricka .....	Flat washer .....		
40	1				9712-0831-02	Låsmutter .....	Lock nut .....		
41	1				1136-0197-01	Handtag .....	Knob .....		
42	1				1136-0107-01	Växlestag .....	Shifter rod .....		
43	1				1136-0093-01	Kulled .....	Ball joint .....		
44	1				9683-0030-02	Låsbricka .....	Lock washer .....		
45	1				9799-0831-02	Mutter .....	Nut .....		
46	1				1136-0187-01	Växelarm .....	Gearshift arm .....		
47	1				9997-0640-12	Skruv .....	Screw .....		
48	2				9699-0035-02	Planbricka .....	Flat washer .....		
49	1				9747-0631-02	Låsmutter .....	Lock nut .....		
50	1				9599-0070-02	Saxsprint .....	Split pin .....		



Utgåva Issue		Bildnr Picture No		ESTATE TORNADO HST BROMSREGLAGE DRIVREGLAGE		ESTATE TORNADO HST BRAKE CONTROL DRIVE CONTROL		Sida Page	
2003-11		1215						98	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2522								
X 1	1				1136-0510-01	Pedal .....	Pedal .....		
2	1				1136-0151-01	Pedalskydd .....	Pedal cover .....		
3	1				1136-0254-01	Bygel .....	Clamp .....		
4	4				9847-8016-16	Skruv .....	Screw .....		
5	1				1136-0117-01	Bromsstång .....	Brake rod .....		
6	1				9699-0090-02	Planbricka .....	Flat washer .....		
7	1				9675-0012-02	Starlock .....	Locking washer .....		
8	1				1136-0248-01	Ledbult .....	Pivot bolt .....		
9	1				1136-0218-01	Fjäder .....	Spring .....		
10	2				9699-0035-02	Planbricka .....	Flat washer .....		
X 11	1				1136-1246-01	Bygel .....	Clamp .....		
12	1				9799-1031-02	Mutter .....	Nut .....		
13	1				9747-1031-02	Låsmutter .....	Lock nut .....		
14	1				9699-0090-02	Planbricka .....	Flat washer .....		
15	1				9747-0831-02	Mutter .....	Lock nut .....		
31	1				1136-0441-01	Spärraxel .....	Axle .....		
32	1				1136-0217-01	Fjäder .....	Spring .....		
33	2				1136-0256-01	Bygel .....	Plate .....		
34	4				9847-8016-16	Skruv .....	Screw .....		
35	1				1136-0119-01	P-bromsarm .....	P-brake lever .....		
36	1				9675-0011-00	Starlock .....	Starlock .....		
37	1				1136-0392-01	Knopp .....	Knob .....		
51	1				1136-0507-01	Drivpedal .....	Drive pedal .....		
52	1				1136-0149-01	Pedalskydd- fram .....	Pedal cover-front .....		
53	1				1136-0150-01	Pedalskydd- bak .....	Pedal cover-rear .....		
54	1				1136-0538-01	Fäste .....	Support .....		
55	2				1136-0121-01	Bussning .....	Bushing .....		
56	1				9501-0500-00	Smörjnippel .....	Grease joint .....		
57	2				9997-0616-16	Skruv .....	Screw .....		
58	2				9739-0631-22	Mutter .....	Nut .....		
59	1				1136-0500-01	Pedalaxel .....	Pedal axle .....		
60	2				9650-0020-04	Spårring .....	Circlip .....		
61	1				1136-0090-01	Bricka .....	Washer .....		
62	1				9997-0816-16	Skruv .....	Screw .....		
63	1				9683-0030-02	Låsbricka .....	Lock washer .....		
64	1				1136-0118-01	Stag .....	Drive rod .....		
65	1				1136-0241-01	Ledbult .....	Pivot bolt .....		
66	1				1136-0247-01	Ledbult .....	Pivot bolt .....		
67	2				9799-0831-02	Mutter .....	Nut .....		
68	2				9747-0831-02	Mutter .....	Lock nut .....		
69	1				9699-0035-02	Planbricka .....	Flat washer .....		
70	1				9699-0028-02	Planbricka .....	Flat washer .....		
71	1				9747-0631-02	Låsmutter .....	Lock nut .....		
72	1				1136-0533-01	Fäste .....	Support .....		
73	1				9699-0060-02	Planbricka .....	Flat washer .....		
74	1				9747-0631-02	Låsmutter .....	Lock nut .....		
75	1				9997-0620-16	Skruv .....	Screw .....		
76	1				9747-0631-02	Låsmutter .....	Lock nut .....		
77	1				1136-0330-01	Bygel .....	Clamp .....		
78	2				9848-8013-16	Skruv .....	Screw .....		
80	1				1136-0407-01	Plåt .....	Plate .....		
X 81	2				1136-1214-01	Skruv .....	Screw .....		
82	2				9683-0005-02	Låsbricka .....	Lock washer .....		
83	2				9799-0331-02	Mutter .....	Nut .....		




Utgåva Issue		Bildnr Picture No		ESTATE TORNADO ESTATE TORNADO HST ELUTRUSTNING		ESTATE TORNADO ESTATE TORNADO HST EL. EQUIPMENT		Sida Page	
2003-11		1447A						100	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2521	2522							
1	1	1		1136-1035-01	Kabelhärva.....	Harness.....			
2	1	1		1136-0919-01	Elektronikkort .....	Electronic card .....			
3	2	2		9847-7813-16	Skruv .....	Screw .....			
4	1	1		1136-0428-01	• Säkring .....	• Fuse .....		6.3 A	
5	1	1		786194	Brytare.....	Neutral start switch .....		Neutral	
6	3	3		1136-0073-01	Mikrobrytare.....	Micro switch .....			
10	1	1		1136-0469-01	Kabelhärva.....	Harness.....		Inkl. pos 11	
11	1	1		1136-0056-01	• Tändningslås .....	• Ignition switch .....		Inkl. pos 12 - 14	
12	1	1		1136-0049-01	•• Mutter.....	•• Nut .....			
13	1	1		1134-4097-01	•• Täckkåpa.....	•• Cap .....			
14	1	1		1134-2848-01	•• Tändningsnyckel.....	•• Ignition key .....			
15	1	1		1136-0065-01	Startrelä.....	Solenoid .....			
16	2	2		9997-0620-16	Skruv .....	Screw .....			
17	2	2		9794-5131-02	Mutter.....	Nut .....			
18	1	1		1136-0055-01	Brytare.....	Switch .....		Strålkastare/light	
19	1	1		1136-0468-01	Kabel .....	Cable .....			
20	2	2		1136-0429-01	Lamphållare.....	Lamp holder .....			
21	2	2		1136-0058-01	Glödlampa .....	Bulb .....			
22	1	1		1136-0135-01	Kabel .....	Cable .....			
23	1	1		1136-0134-01	Kabel .....	Cable .....			
24	1	1		1136-0136-01	Kabelhärva.....	Harness.....			
25	1	1		1134-4804-01	Batteri.....	Battery .....			
26	1	1		1136-0215-01	Fjäder.....	Spring .....			
27	1	1		1136-0059-01	Polskydd.....	Protection .....			
28	1	1		9795-3531-02	Mutter.....	Nut .....			
29	4	4		1136-0427-01	Kabelhållare.....	Cable holder .....			
30	1	1		1136-0426-01	Kabelhållare.....	Cable holder .....			
31		1		1136-0076-01	Mikrobrytare.....	Micro switch .....			
32		1		1136-0865-01	Kabel .....	Cable .....			
33	2	2		9739-0631-22	Mutter.....	Nut .....			
99	1	1		1136-1108-01	Tillbehörspåse .....	Key outfit.....		Inkl. pos 4, 14	






Utgåva Issue		Bildnr Picture No		ESTATE TORNADO ESTATE TORNADO HST MOTOR		ESTATE TORNADO ESTATE TORNADO HST ENGINE		Sida Page	
2003-11		1216						102	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2521	2522							
2	1			1136-0354-01	Bränsleslang.....	Fuel hose.....			
3	3			1136-0045-01	Slangklämma.....	Hose clamp.....			
4	1			1136-1050-01	Avgasrör.....	Exhaust tube.....			
5	4			9847-7809-16	Skruv.....	Screw.....			
6	1			1136-0518-01	Ljuddämparskydd.....	Muffler protection.....			
7	1			9988-3513-16	Skruv.....	Screw.....			
8	1			9677-0009-02	Låsbricka.....	Lock washer.....			
9	1			9847-8113-16	Skruv.....	Screw.....			
10	1			1136-0273-01	Oljeavtappningsrör.....	Oil drain tube.....			
11	1			1136-0066-01	Oljeavtappningsplugg.....	Oil drain plug.....			
12	2			1136-0054-01	Tätningring.....	Oil seal.....			
13	3			9997-0835-12	Skruv.....	Screw.....			
14	1			9799-0831-02	Mutter.....	Nut.....			
15	3			9739-0831-22	Mutter.....	Nut.....			
16	2			9677-0009-02	Låsbricka.....	Lock washer.....			
17	1			1136-0353-01	Bränsleslang.....	Fuel hose.....			
18	1			1136-0046-01	Slangklämma.....	Hose clamp.....			
19	1			9997-0840-16	Skruv.....	Screw.....			




Utgåva Issue		Bildnr Picture No		ESTATE TORNADO TRANSMISSION		ESTATE TORNADO TRANSMISSION		Sida Page
2003-11		1217						104
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2521							
1	1			1136-0286-01	Motorremskiva .....	Engine belt pulley .....		
2	1			9987-5351-12	Skruv .....	Screw .....		
3	1			9683-0045-02	Bricka .....	Washer .....		
5	1			1136-0433-01	Kilrem .....	V-belt .....		
6	1			1136-0489-01	Spännarm .....	Tension arm .....		
7	1			9997-0630-12	Skruv .....	Screw .....		
8	2			1136-0123-01	Bussning .....	Bushing .....		
9	1			9747-0831-02	Mutter .....	Lock nut .....		
10	1			1136-0166-01	Distans .....	Spacer .....		
11	1			1136-0289-01	Spännrulle .....	Idler pulley .....		
12	1			9699-0056-02	Planbricka .....	Flat washer .....		
13	1			9747-0831-02	Mutter .....	Lock nut .....		
14	1			1136-0235-01	Ledbult .....	Pivot bolt .....		
15	2			1136-0309-01	Bricka .....	Washer .....		
16	1			9747-0831-02	Mutter .....	Lock nut .....		
17	1			1136-0348-01	Spännstång .....	Tie rod .....		
18	2			9799-0831-02	Mutter .....	Nut .....		
19	1			1136-0208-01	Fjäder .....	Spring .....		
20	1			1136-0162-01	Distans .....	Spacer .....		
21	1			9997-0880-16	Skruv .....	Screw .....		
22	1			9739-0831-22	Mutter .....	Nut .....		
23	1			9747-0831-02	Mutter .....	Lock nut .....		
24	1			1136-0346-01	Spännstång .....	Tie rod .....		
25	1			1136-0093-01	Kulled .....	Ball joint .....		
26	1			9683-0030-02	Låsbricka .....	Lock washer .....		
27	1			9799-0831-02	Mutter .....	Nut .....		
28	1			9699-0090-02	Planbricka .....	Flat washer .....		
29	1			9675-0012-02	Starlock .....	Locking washer .....		
30	1			1136-0290-01	Remrulle .....	Belt roller .....		
31	1			1136-0234-01	Pinnbult .....	Stud bolt .....		
32	1			9699-0056-02	Planbricka .....	Flat washer .....		
33	2			9747-0831-02	Mutter .....	Lock nut .....		
34	2			1136-0915-01	Remrulle .....	Belt roller .....		
35	1			1136-0167-01	Distans- vä .....	Spacer- LH .....		
36	1			1136-0164-01	Distans- hö .....	Spacer- RH .....		
37	1			9997-0835-12	Skruv .....	Screw .....		
38	1			9997-0845-12	Skruv .....	Screw .....		
39	2			9699-0056-02	Planbricka .....	Flat washer .....		
40	2			9747-0831-02	Mutter .....	Lock nut .....		
41	1			1136-0520-01	Remskiva .....	Belt pulley .....		
42	1			9600-0050-00	Woodruffkil .....	Key .....		
43	1			9650-0016-04	Spårring .....	Lock ring .....		
44	1			1136-0050-01	Transaxel .....	Transaxle .....		
45	4			9997-0860-16	Skruv .....	Screw .....		
47	4			9739-0831-22	Mutter .....	Nut .....		
48	2			1136-0325-01	Momentstag .....	Stay .....		
49	2			1136-0017-01	Skruv .....	Screw .....		
50	2			9997-0816-16	Skruv .....	Screw .....		
51	2			9739-0831-22	Mutter .....	Nut .....		
52	1			1136-0181-01	Remstyrning .....	Belt guide .....		
53	4			9699-0035-02	Planbricka .....	Flat washer .....		
54	2			9747-0831-02	Mutter .....	Lock nut .....		
55	2			1136-0868-01	Lock .....	Cover .....		
72	2			1136-0455-01	Fälg .....	Rim .....		
73	2			1136-0270-01	Däck (Turf Saver) .....	Tire (Turf Saver) .....		
73	2			1136-0272-01	Däck (Deli) .....	Tire (Deli) .....		
74	2-4			9699-0119-02	Bricka .....	Washer .....		
75	2			1136-0305-01	Bricka .....	Washer .....		
76	2			9652-0015-04	Låsring .....	Retaining ring .....		
77	2			1136-0081-01	Navkapsel .....	Hub cap .....		
78	2			9545-0500-00	Ventil .....	Valve .....		


Peerless MST 205-535



Utgåva Issue		Bildnr Picture No		ESTATE TORNADO HST TRANSMISSION		ESTATE TORNADO HST TRANSMISSION		Sida Page	
2003-11		1564						106	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2522								
1	1			1136-0287-01	Motorremskiva .....	Engine belt pulley .....			
2	1			9987-5351-12	Skruv .....	Screw .....			
3	1			9683-0045-02	Bricka .....	Washer .....			
5	1			1136-0432-01	Kilrem .....	V-belt .....			
6	1			1136-0489-01	Spännarm .....	Tension arm .....			
7	1			9997-0630-12	Skruv .....	Screw .....			
8	2			1136-0123-01	Bussning .....	Bushing .....			
9	1			9747-0831-02	Mutter .....	Lock nut .....			
10	1			1136-0166-01	Distans .....	Spacer .....			
11	1			1136-0289-01	Spännrulle .....	Idler pulley .....			
12	1			9699-0056-02	Planbricka .....	Flat washer .....			
13	1			9747-0831-02	Mutter .....	Lock nut .....			
14	1			1136-0235-01	Ledbult .....	Pivot bolt .....			
15	2			1136-0309-01	Bricka .....	Washer .....			
16	1			9747-0831-02	Mutter .....	Lock nut .....			
17	1			1136-0348-01	Spännstång .....	Tie rod .....			
18	2			9799-0831-02	Mutter .....	Nut .....			
19	1			1136-0208-01	Fjäder .....	Spring .....			
20	1			1136-0162-01	Distans .....	Spacer .....			
21	1			9997-0880-16	Skruv .....	Screw .....			
22	1			9739-0831-22	Mutter .....	Nut .....			
23	1			9747-0831-02	Mutter .....	Lock nut .....			
24	1			1136-0290-01	Remrulle .....	Belt roller .....			
25	1			1136-0234-01	Pinnbult .....	Stud bolt .....			
26	1			9699-0056-02	Planbricka .....	Flat washer .....			
27	2			9747-0831-02	Mutter .....	Lock nut .....			
28	2			1136-0915-01	Remrulle .....	Belt roller .....			
29	1			1136-0174-01	Distans-vä .....	Spacer-LH .....			
30	1			1136-0170-01	Distans-hö .....	Spacer-RH .....			
31	1			9997-0840-16	Skruv .....	Screw .....			
32	1			9997-0850-16	Skruv .....	Screw .....			
33	2			9699-0056-02	Planbricka .....	Flat washer .....			
34	2			9747-0831-02	Mutter .....	Lock nut .....			
35	2			1136-0868-01	Lock .....	Cover .....			
41	1			1136-0053-01	Transaxel .....	Transaxle .....		Kanzaki K46S	
42	4			9997-0860-16	Skruv .....	Screw .....			
44	4			9739-0831-22	Mutter .....	Nut .....			
45	1			1136-1056-01	Stöd .....	Support .....			
46	1			9997-0845-12	Skruv .....	Screw .....			
47	2			9699-0090-02	Planbricka .....	Flat washer .....			
48	1			9747-0831-02	Mutter .....	Lock nut .....			
50	1			9997-0816-16	Skruv .....	Screw .....			
52	1			1136-0190-01	Arm .....	Lever .....			
53	1			9997-0820-16	Skruv .....	Screw .....			
54	1			1136-0006-01	Fjäderbricka .....	Elastic washer .....			
55	1			1136-0309-01	Bricka .....	Washer .....			
56	1			9747-0831-02	Mutter .....	Lock nut .....			
57	1			1136-0114-01	Stag .....	Rod .....			
58	1			9675-0009-02	Starlock .....	Starlock .....			
61	1			1136-0918-01	Förstärkning .....	Reinforcement .....			
62	2			1136-0821-01	Skruv .....	Screw .....			
63	2			9699-0090-02	Planbricka .....	Flat washer .....			
64	4			9739-0831-22	Mutter .....	Nut .....			
65	1			1136-0822-01	Skruv .....	Screw .....			
72	2			1136-0455-01	Fälg .....	Rim .....			
73	2			1136-0270-01	Däck (Turf Saver) .....	Tire (Turf Saver) .....			
73	2			1136-0272-01	Däck (Deli) .....	Tire (Deli) .....			
74	2			9545-0500-00	Ventil .....	Valve .....			
75	4			1136-0305-01	Bricka .....	Washer .....			
76	2			1136-0175-01	Distans .....	Spacer .....			
77	2			1136-0312-01	Bricka .....	Washer .....			
78	2			9652-0015-04	Låsring .....	Retaining ring .....			
79	2			1136-0081-01	Navkapsel .....	Hub cap .....			





Utgåva Issue 2003- 11		Bildnr Picture No 1219		ESTATE TORNADO ESTATE TORNADO HST AGGREGATSLYFT		ESTATE TORNADO ESTATE TORNADO HST MOWER DECK LIFT		Sida Page 108	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2521	2522							
1	1				1136-0487-01	Lyftspak kpl .....	Lift lever Assy.....		Inkl. pos 2 - 9
2	1				1136-0493-01	• Lyftspak .....	• Lift lever .....		
3	1				1136-0298-01	• Tryckknapp .....	• Button .....		
4	1				1136-0222-01	• Spärrhake .....	• Dog .....		
5	1				1136-0227-01	• Sprint.....	• Pin.....		
6	1				1136-0105-01	• Tryckstäng .....	• Push rod .....		
7	1				1136-0193-01	• Handtag .....	• Handle.....		
8	1				1136-0203-01	• Fjäder .....	• Spring .....		
9	1				9675-0012-02	• Starlock .....	• Locking washer.....		
10	1				1136-0444-01	Lyftaxel .....	Axle .....		
11	2				1136-0078-01	Bussning .....	Bushing.....		
12	1				1136-0163-01	Distans .....	Spacer.....		
13	1				9699-0119-02	Bricka .....	Washer.....		
14	2				9595-0235-00	Spännstift .....	Locating pin .....		
15	1				1136-0319-01	Höjdställn.segment.....	Height adjust sector .....		
16	2				9997-0816-16	Skruv.....	Screw.....		
17	2				9739-0831-22	Mutter.....	Nut .....		
18	1				1136-0460-01	Lyftwire.....	Lift wire.....		
19	1				1136-0291-01	Wirerulle.....	Cable pulley.....		
20	1				1136-0232-01	Distans .....	Spacer.....		
21	1				9997-0850-16	Skruv.....	Screw.....		
22	1				9699-0056-02	Planbricka.....	Flat washer.....		
23	1				9739-0831-22	Mutter.....	Nut .....		
24	1				1136-0443-01	Lyftaxel .....	Lift axle .....		
25	2				1136-0253-01	Bygel .....	Clamp.....		
26	4				9997-0616-16	Skruv.....	Screw.....		
27	4				9739-0631-22	Mutter.....	Nut .....		
28	1				1136-0492-01	Lyftarm .....	Lift arm .....		
29	2				1136-0255-01	Bygel .....	Clamp.....		
30	4				9847-8016-16	Skruv.....	Screw.....		
31	1				1136-0108-01	Lyftstag.....	Lift rod .....		
32	1				1136-0235-01	Ledbult .....	Pivot bolt.....		
33	1				9799-0831-02	Mutter.....	Nut .....		
34	1				9747-0831-02	Mutter.....	Lock nut .....		
35	2				1136-0309-01	Bricka .....	Washer.....		
36	1				9747-0831-02	Mutter.....	Lock nut .....		
37	1				9699-0090-02	Planbricka.....	Flat washer.....		
38	1				1136-0095-01	Låsnål.....	Hair pin .....		







Utgåva Issue		Bildnr Picture No		ESTATE TORNADO ESTATE TORNADO HST AGGREGATSINKOPPLING		ESTATE TORNADO ESTATE TORNADO HST MOWER DECK ENGAGEMENT		Sida Page	
2003-11		1448A						110	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2521	2522							
1	1			1136-0494-01	Spännarm .....	Tension arm .....			
2	1			1136-0917-01	Remskiva .....	Pulley .....			
3	1			1136-0070-01	Kullager .....	Ball bearing .....			
4	1			9651-0035-04	Låsring .....	Lock ring .....			
5	1			9650-0015-04	Låsring .....	Lock ring .....			
6	1			9997-0890-12	Skruv .....	Screw .....			
7	2			1136-0014-01	Bricka .....	Washer .....			
8	1			1136-0089-01	Bricka .....	Washer .....			
9	1			9747-0831-02	Mutter .....	Lock nut .....			
10	1			1136-0859-01	Fjäder .....	Spring .....			
11	1			1136-0348-01	Spännstång .....	Tie rod .....			
12	2			9799-0831-02	Mutter .....	Nut .....			
13	1			1136-1028-01	Stag .....	Rod .....			
14	1			1136-0836-01	Gaffel .....	Fork .....			
15	1			9799-0831-02	Mutter .....	Nut .....			
16	1			1136-0835-01	Låsbult .....	Clip .....			
17	1			1136-0009-01	Låsplatta .....	Lock plate .....			
18	1			1136-0886-01	Arm-hö .....	Lever- RH .....			
19	1			1136-0885-01	Arm-vä .....	Lever- LH .....			
20	2			1136-0089-01	Bricka .....	Washer .....			
21	2			9997-0816-16	Skruv .....	Screw .....			
22	2			1136-0079-01	Bussning .....	Bushing .....			
23	2			9739-0831-22	Mutter .....	Nut .....			
24	1			1136-0904-01	Sprint .....	Pin .....			
25	2			1136-0309-01	Bricka .....	Washer .....			
26	1			9747-0831-02	Mutter .....	Lock nut .....			
27	1			1136-0862-01	Stång .....	Rod .....			
28	3			9699-0090-02	Planbricka .....	Flat washer .....			
29	1			1136-0895-01	Fjäder .....	Spring .....			
30	1			9799-0831-02	Mutter .....	Nut .....			
31	1			9747-0831-02	Mutter .....	Lock nut .....			
32	1			1136-0095-01	Låsnål .....	Hair pin .....			
33	1			1136-1022-01	Drivrem .....	Drive belt .....			
34	1			1136-0878-01	Remstyrning .....	Belt guide .....			
35	2			9847-8116-16	Skruv .....	Screw .....			
36	1			1136-0880-01	Remstyrning .....	Belt guide .....			
37	2			9739-0831-22	Mutter .....	Nut .....			
38	2			9747-0831-02	Mutter .....	Lock nut .....			
39	1			1136-0879-01	Remstyrning .....	Belt guide .....			
40	1			9739-0831-22	Mutter .....	Nut .....			
41	1			9747-0831-02	Mutter .....	Lock nut .....			
42	1			9699-0035-02	Planbricka .....	Flat washer .....			
43	1			9747-0631-02	Låsmutter .....	Lock nut .....			
44	2			1136-0864-01	Remkåpa .....	Belt cover .....			
45	4			9848-8013-16	Skruv .....	Screw .....			
71	1			1136-0537-01	Fäste .....	Support .....			
72	2			9997-0816-16	Skruv .....	Screw .....			
73	2			9739-0831-22	Mutter .....	Nut .....			
74	1			1136-0088-01	Bricka .....	Washer .....			
75	1			1136-0528-01	Spåkhållare .....	Lever holder .....			
76	1			1136-0491-01	Inkopplingsspak .....	Engagement lever .....			
77	1			1136-0213-01	Fjäder .....	Spring .....			
78	1			9997-0880-16	Skruv .....	Screw .....			
79	1			9747-0831-02	Mutter .....	Lock nut .....			
83	1			9699-0056-02	Planbricka .....	Flat washer .....			
84	1			9712-0831-02	Låsmutter .....	Lock nut .....			
85	1			1136-1075-01	Inkopplingswire .....	Cable .....			
86	1			9699-0056-02	Planbricka .....	Flat washer .....			
87	1			1136-0197-01	Handtag .....	Knob .....			
88	1			1136-0957-01	Fjäder .....	Spring .....			






Utgåva Issue		Bildnr Picture No		ESTATE TORNADO ESTATE TORNADO HST KLIPPAGGREGAT		ESTATE TORNADO ESTATE TORNADO HST MOWER DECK		Sida Page	
2003-11		1449A						112	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2521	2522							
1	1				1136-1044-01 Klippagggregatskåpa .....	Mower deck casing .....			Inkl. pos 2 - 4
2	2				1136-0120-01 • Vattenslangnippel .....	• Water hose connection.....			
3	2				1136-0068-01 • O-ring.....	• O-ring.....			
4	2				1136-0012-01 • Nit.....	• Rivet.....			
5	2				1136-0481-01 Lagerbox kpl.....	Bearing box assy.....			Inkl. pos 6 - 10
6	2				1136-0099-01 • Knivaxel .....	• Blade shaft .....			
8	4				1136-0069-01 • Kullager .....	• Ball bearing .....			
9	2				1136-0176-01 • Dammskydd .....	• Dust cover.....			
10	2				9650-0020-04 • Spårring.....	• Circlip.....			
11	6				9898-0825-16 Skruv .....	Screw.....			
12	6				9739-0831-22 Mutter.....	Nut.....			
13	2				1136-0221-01 Knivfäste.....	Blade hub.....			
14	2				9600-0014-00 Kil .....	Key.....			
15	2				1136-1029-01 Kniv .....	Blade.....			
16	2				1136-0083-01 Fjäderbricka .....	Elastic washer.....			
17	2				1136-0015-01 Bricka .....	Washer.....			
18	2				9987-5238-12 Knivbult .....	Blade bolt.....			
19	2				1136-0916-01 Remskiva.....	Pulley.....			
20	2				1136-0001-01 Kil .....	Key.....			
21	2				9997-0820-16 Skruv .....	Screw.....			
22	2				1136-0307-01 Bricka .....	Washer.....			
23	2				9683-0030-02 Låsbricka .....	Lock washer.....			
31	2				1136-1052-01 Stödhjul .....	Anti scalp wheel.....			
32	2				1136-0901-01 Distans .....	Spacer.....			
33	2				9997-0880-16 Skruv .....	Screw.....			
34	2				9699-0056-02 Planbricka .....	Flat washer.....			
35	2				9739-0831-22 Mutter.....	Nut.....			
51	2				1136-0231-01 Ledbult .....	Pivot bolt.....			
52	4				1136-0308-01 Bricka .....	Washer.....			
53	2				9747-1031-02 Låsmutter .....	Lock nut.....			
54	2				1136-0347-01 Lyftlänk.....	Lift tie rod.....			
55	2				9799-1031-02 Mutter.....	Nut.....			
56	2				9747-1031-02 Låsmutter .....	Lock nut.....			
57	2				9699-0035-02 Planbricka.....	Flat washer.....			
58	2				1136-0095-01 Låsnål.....	Hair pin.....			
59	1				1136-0231-01 Ledbult .....	Pivot bolt.....			
60	2				1136-0308-01 Bricka .....	Washer.....			
61	1				9747-1031-02 Låsmutter .....	Lock nut.....			
62	1				1136-0928-01 Spännlänk.....	Tie rod.....			
63	1				9799-1031-02 Mutter.....	Nut.....			
64	1				9747-1031-02 Låsmutter .....	Lock nut.....			
65	1				9699-0035-02 Planbricka.....	Flat washer.....			
66	1				1136-0095-01 Låsnål.....	Hair pin.....			
67	2				1136-0448-01 Stång .....	Equalizer rod.....			
68	4				9699-0056-02 Planbricka.....	Flat washer.....			
69	4				9747-1031-02 Låsmutter .....	Lock nut.....			
70	8				1136-0308-01 Bricka .....	Washer.....			
72	1				1136-1107-01 Deflektor.....	Deflector.....			
73	1				1136-0229-01 Sprint.....	Pin.....			
74	1				9598-0002-02 Låsnål.....	Pin lock.....			
81	1				1136-0910-01 Utkastskydd.....	Discharge protection.....			
82	1				1136-0902-01 Axel .....	Pivot.....			
83	1				1136-0894-01 Fjäder.....	Spring.....			
84	1				9599-0070-02 Saxsprint .....	Split pin.....			



Utgåva Issue		Bildnr Picture No		DRAG ART.NR 13-0933-11		TOW BAR ART.NO 13-0933-11		Sida Page	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	0933								
42	1			1136-0463-01	Balk .....	Girder .....			
43	1			1136-0228-01	Dragsprint .....	Tow pin .....			
44	1			1136-0096-01	Låsnål .....	Hair pin .....			
45	2			9997-0825-16	Skruv .....	Screw .....			
46	6			9739-0831-22	Mutter .....	Nut .....			




Utgåva Issue		Bildnr Picture No		SNÖBLAD (120 cm) ART.NR 13-0924-11		SNOW BLADE (120 cm) ART.NO 13-0924-11		Sida Page	
2003-11		1453						162	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	0924								
1	1			1319-1528-01	Blad .....	Blade .....			
2	1			1319-1812-01	Bladfäste.....	Blade holder.....			
3	1			1319-1816-01	Ram .....	Frame .....			
4	2			1319-1817-01	Skruv .....	Screw .....			
5	2			1319-1526-01	Släpsko.....	Skid .....			
6	2			1319-1818-01	Stag .....	Rod .....			
7	1			1319-1819-01	Stagfäste .....	Rod bracket.....			
8	1			1319-1820-01	Stagfäste .....	Rod bracket.....			
9	1			1319-1815-01	Lyftarm .....	Lift rod .....			
10	1			1319-1822-01	Handtag .....	Grip .....			
11	1			1319-1527-01	Fjäder.....	Spring .....			
12	1			1319-1821-01	Axel .....	Shaft .....			
13	2			9997-1030-16	Skruv .....	Screw .....			
14	1			1319-1551-01	Skruv .....	Screw .....			
15	8			9747-1031-02	Låsmutter .....	Lock nut .....			
16	1			1319-1692-01	Låsnål .....	Spring pin .....			
17	2			9699-0037-02	Bricka .....	Washer .....			
18	1			1319-1811-01	Saxpinne.....	Cotter pin .....			
19	3			9997-0816-16	Skruv .....	Screw .....			
20	7			9747-0831-02	Mutter.....	Lock nut .....			
21	2			9747-1031-02	Låsmutter .....	Lock nut .....			
22	6			9997-1025-16	Skruv .....	Screw .....			
24	4			9997-0880-16	Skruv .....	Screw .....			
25	4			9699-0028-02	Planbricka.....	Flat washer.....			
26	2			9997-1220-16	Skruv .....	Screw .....			
27	1			9747-1631-02	Låsmutter .....	Lock nut .....			
28	1			1319-1531-01	Sprint.....	Pin .....			
29	1			1319-1813-01	Monteringsfäste.....	Mounting plate.....			
30	1			1319-1814-01	Monteringsfäste.....	Mounting plate.....			






Utgåva Issue		Bildnr Picture No		SNÖKEDJOR ART.NR 13-0925-11		SNOW CHAINS ART.NO 13-0925-11		Sida Page	
2003-11		1454						164	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	0925								
1	2			1134-5064-01	Låsbygel .....	Lock .....		Ø5,5 x 40	
2	2			1134-5065-01	Krok .....	Hook .....			
3	ERF			1134-4416-04	Länk .....	Link .....			

A




Utgåva Issue		Bildnr Picture No		BRIGGS & STRATTON 286707, 28M707 CYLINDER (A) VEVHUS (A)		BRIGGS & STRATTON 286707, 28M707 CYLINDER (A) CRANKCASE (A)		Sida Page	
2003- 11		1182A						206	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	286 707- 1185	28M 707- 1194							
A01	3	3		691655	Skruv.....	Screw.....			
A02		1		690492	Skyddsnet.....	Rotating screen.....			
A02	1			691748	Skyddsnet.....	Rotating screen.....			
A03	2	2		691058	Skruv.....	Screw.....			
A04	1			690452	Fläkthållare.....	Fan retainer.....			
A05	1			691905	Fläkt.....	Flywheel fan.....			
A05		1		695056	Fläkt.....	Flywheel fan.....			
A06	1	1		691323	Distans.....	Spacer.....			
A07	1	1		690582	Bricka.....	Washer.....			
A08	1	1		691173	Svänghjuls kopp.....	Flywheel cup.....			
A09	1	1		19203	Avdragare.....	Puller.....			
A10	1	1		693556	Svänghjul.....	Flywheel.....			
A11	1	1		691265	• Låsring.....	• Retaining ring.....			
A12	1	1		693713	• Drev.....	• Pinion gear.....			
A13	1	1		496413	Cylinder.....	Cylinder.....			
A14	1	1		399265	• Bussning.....	• Bushing.....			
A15	1	1		391086	•• Tätningssring.....	•• Seal.....			
A16	1	1		691003	• Skruv.....	• Screw.....			
A17	1	1		690459	Cylinderskydd.....	Cylinder shield.....			
A18	1	1		231218	• Ventilstyrning- insug.....	• Valve guide- intake.....			
A18	1	1		261961	• Ventilstyrning- utblås.....	• Valve guide- exhaust.....			
A19	1	1		691802	• Ventilsåte- insug.....	• Valve seat- intake.....			
A20	1	1		691844	• Ventilsåte- utblås.....	• Valve seat- exhaust.....			
A21	1	1		491986	• Bussning.....	• Bushing.....			
A22	1	1		692407	•• Tätning.....	•• Seal.....			
A23	1	1		89838	Tändstiftsnyckel.....	Spark plug wrench.....			
A24	1	1		66538	Tändstiftsskydd.....	Spark plug elbow.....			
A25	1	1		9400- 0225- 00	Tändstift.....	Spark plug.....			
A26	1	1		491490	Skydd.....	Cover.....			
A27		2		690960	Skruv.....	Screw.....			
A27	2			692198	Skruv.....	Screw.....			
A28	1	1		690510	• Distans.....	• Spacer.....			
A29	1	1		691681	• Skruv.....	• Screw.....			
A30	1	1		271866	Packning.....	Gasket.....			
A31	1	1		494240	Topplöck.....	Cylinder head.....			
A32	8	8		690904	Skruv.....	Screw.....			
A33	1	1		490666	Bussning.....	Bushing.....			
A34	1	1		291675	• Tätningssring.....	• Oil seal.....			
A35	1	1		690946	Avtappningsplugg.....	Oil drain plug.....			
A36	1	1		494238	Vevhus.....	Oil sump.....			
A37	1	1		692405	Packning.....	Gasket.....			
A37	1	1		692406	Packning.....	Gasket.....		.009"	
A37	1	1		692226	• Packning.....	• Gasket.....		.005"	
A38		1		691328	Ventilationsrör.....	Breather tube.....		.015" Standard	
A38	1			692253	Ventilationsrör.....	Breather tube.....			
A39	1	1		495735	Vevhusventilation.....	Breather.....			
A40	1	1		27803	• Packning.....	• Gasket.....			
A41	2	2		691666	Skruv.....	Screw.....			
A42	10	10		692125	Skruv.....	Screw.....			
A50		1		691658	Skruv.....	Screw.....			

A




B




Utgåva Issue		Bildnr Picture No		BRIGGS & STRATTON 286707, 28M707 INSUGNINGSRÖR (A) VEVAXEL (B)		BRIGGS & STRATTON 286707, 28M707 INTAKE TUBE (A) CRANKSHAFT (B)		Sida Page
2003-11		1183						208
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	286 707- 1185	28M 707- 1194						
A30	1	1		272554	Packning.....	Gasket.....		
A31	1	1		691711	Insugningsrör.....	Intake manifold.....		
A32	2	2		690953	Skruv.....	Screw.....		
A33	2	2		691098	Pinnbult.....	Stud.....		
A34	2	2		690958	Mutter.....	Nut.....		
B01	1	1		262247	Insugningsventil.....	Intake valve.....		
B02	1	1		691605	Ventilfjäder-insug.....	Valve spring-intake.....		
B03	1	1		690656	Ventilhållare.....	Valve retainer.....		
B04	2	2		691811	Ventillyftare.....	Valve tappet.....		
B05	1	1		262246	Utblåsningsventil.....	Exhaust valve.....		
B06	1	1		691597	Ventilfjäder-utblås.....	Valve spring-exhaust.....		
B07	1	1		691939	Ventilhållare.....	Valve retainer.....		
B08	1	1		494553	Hållare.....	Retainer.....		
B09	1			499284	Kolv kpl.....	Piston assy.....		Standard
B09	1			499288	Kolv kpl.....	Piston assy.....		.010" O.S.
B09	1			499292	Kolv kpl.....	Piston assy.....		.020" O.S.
B09	1			499296	Kolv kpl.....	Piston assy.....		.030" O.S.
B09		1		696397	Kolv kpl.....	Piston assy.....		Standard
B09		1		696398	Kolv kpl.....	Piston assy.....		.010" O.S.
B09		1		696399	Kolv kpl.....	Piston assy.....		.020" O.S.
B09		1		696400	Kolv kpl.....	Piston assy.....		.030" O.S.
B10	2	2		691299	• Låsring.....	• Piston pin lock.....		
B11	1			392331	• Kolvringsatts.....	• Ring set.....		Chrome standard
B11	1			499996	• Kolvringsatts.....	• Ring set.....		Standard
B11	1			499997	• Kolvringsatts.....	• Ring set.....		.010" O.S.
B11	1			499998	• Kolvringsatts.....	• Ring set.....		.020" O.S.
B11	1			499999	• Kolvringsatts.....	• Ring set.....		.030" O.S.
B11		1		696403	• Kolvringsatts.....	• Ring set.....		Standard
B11		1		696404	• Kolvringsatts.....	• Ring set.....		.010" O.S.
B11		1		696405	• Kolvringsatts.....	• Ring set.....		.020" O.S.
B11		1		696406	• Kolvringsatts.....	• Ring set.....		.030" O.S.
B12	1	1		498319	Kolvbult.....	Piston pin.....		Standard
B12	1	1		498320	Kolvbult.....	Piston pin.....		.005" O.S.
B13	1	1		494504	Vevstake.....	Connecting rod.....		Standard
B13	1	1		495490	Vevstake.....	Connecting rod.....		.020" U.S.
B14	1	1		690348	• Skruv.....	• Screw.....		
B15	1	1		690356	• Skruv.....	• Screw.....		
B16	1	1		222698	Kil.....	Key.....		
B17	1	1		693944	Vevaxel.....	Crankshaft.....		
B18	1	1		691658	• Skruv.....	• Screw.....		
B19	1	1		691779	• Vevaxelförlängning.....	• Crankshaft extension.....		
B20	1	1		691639	• Kil.....	• Timing key.....		
B21	1	1		691284	• Drev.....	• Timing gear.....		
B22	1	1		692423	Motvikt.....	Counter weight.....		
B23	1	1		691239	• Axel.....	• Pin.....		
B24	1	1		691714	Länk.....	Link.....		
B25	1	1		691096	Skruv.....	Screw.....		
B26	1	1		692123	Kamaxel.....	Camshaft.....		
B27	1	1		691968	Oljekastardrev.....	Oil slinger.....		
B28	1	1		496415	Oljesticka kpl.....	Oil filler group.....		
B29	1	1		692014	• Oljesticka.....	• Oil dipstick.....		
B30	1	1		691002	• Skruv.....	• Screw.....		
B31	1	1		691398	• Påfyllningsrör.....	• Dipstick tube.....		
B32	1	1		691870	• Tätning.....	• Seal.....		
B33	1	1		281370	• Tätning.....	• Seal.....		
B34	1			691874	Ljuddämpare.....	Muffler.....		
B35	1			692236	• Packning.....	• Gasket.....		
B36	1			692198	• Skruv.....	• Screw.....		
B37	1			691416	• Skruv.....	• Screw.....		
B38	1			690420	• Värmskydd.....	• Heat shield.....		
B39	2			690661	Skruv.....	Screw.....		Deflector

A





B



Utgåva Issue		Bildnr Picture No		BRIGGS & STRATTON 286707, 28M707 REGULATOR (A) LUFTFILTER (B)		BRIGGS & STRATTON 286707, 28M707 GOVERNOR (A) AIR CLEANER (B)		Sida Page
2003- 11		1184A						210
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	286 707- 1185	28M 707- 1194						
A01	1	1		490324	Skyddskåpa .....	Cover .....		
A02	2	2		691002	• Skruv .....	• Screw .....		
A03	1			690485	Fläkthus .....	Blower housing .....		
A03		1		691399	Fläkthus .....	Blower housing .....		
A04		1		690960	Skruv .....	Screw .....		
A04	1			692198	Skruv .....	Screw .....		
A05	2	2		690661	Skruv .....	Screw .....		
A06	1	1		690456	Svänghjulsskydd .....	Flywheel guard .....		
A07	2	2		692127	Skruv .....	Screw .....		
A08	1	1		694042	Reglageplåt .....	Control bracket .....		
A09	1	1		691795	Regulatorfjäder .....	Governor spring .....		
A10	2	2		691693	Skruv .....	Screw .....		
A11	1	1		691972	Isolator .....	Insulator .....		
A12	1	1		691084	Anslutningsbleck .....	Ground terminal .....		
A13	1	1		691077	Bricka .....	Washer .....		
A14	1	1		691612	Mutter .....	Nut .....		
A15	1	1		691024	Klämma .....	Clamp .....		
A16	1	1		690804	Skruv .....	Screw .....		
A17	1	1		691840	Chokelänk .....	Choke link .....		
A18	2	2		691183	Skruv .....	Screw .....		
A19	1			691065	Generator .....	Alternator .....		
A19		1		696457	Generator .....	Alternator .....		
A20		1		691842	Fjäder .....	Spring .....		
A21	1	1		398808	Kortslutningskabel .....	Ground wire .....		
A22	1	1		492341	Tändsystem .....	Armature magneto .....		
A23	2	2		691061	Skruv .....	Screw .....		
A24	1	1		493880	• Anslutningshylsa .....	• Terminal .....		
A25	1	1		691691	Bricka .....	Washer .....		
A26	1	1		692012	Regulatoraxel .....	Governor crank .....		
A27	1	1		691620	Låsnål .....	Cotter pin .....		
A28	1	1		394358	Bränslefilter .....	Fuel filter .....		
A29	1	1		691050	Bränsleslang .....	Fuel line .....		
A30	2	2		95162	• Slangklämma .....	• Hose clamp .....		
A31	1	1		691374	Regulatorarm .....	Governor lever .....		
A32	1	1		691119	• Bult .....	• Bolt .....		
A33	1	1		691251	• Mutter .....	• Nut .....		
A34		1		691841	Regulatorlänk .....	Governor link .....		
A35		1		692236	Packning .....	Gasket .....		
A37		1		691188	Regulator .....	Regulator .....		
A38		1		694475	Fäste .....	Mounting bracket .....		
A39		2		694476	Skruv .....	Screw .....		
B25	1	1		691668	Låsrott .....	Air cleaner knob .....		
B26		1		691332	Lock .....	Cover .....		
B26	1			691916	Lock .....	Cover .....		
B27	1	1		272403	Filterelement .....	Air cleaner element .....		
B28	1	1		692297	Tätning .....	Seal .....		
B29	1	1		496894	Pappersfilter .....	Cartridge .....		
B30	2	2		692126	Skruv .....	Screw .....		
B31	1	1		696129	Luftrenarfäste .....	Air cleaner base .....		
B32	1	1		691328	• Ventilationsrör .....	• Breather tube .....		
B33	1	1		691917	• O- ring .....	• O- ring .....		
B34	1	1		693675	• Skruv .....	• Screw .....		
B35	2	2		690958	Mutter .....	Nut .....		

A


WALBRO



B




NIKKI







Utgåva Issue		Bildnr Picture No		BRIGGS & STRATTON 286707, 28M707 FÖRGASARE WALBRO (A) FÖRGASARE NIKKI (B)		BRIGGS & STRATTON 286707, 28M707 CARBURETOR WALBRO (A) CARBURETOR NIKKI (B)		Sida Page
2003-11		1185A						212
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	286 707- 1185	28M 707- 1194						
A01	1	1		495931	Chokeaxel .....	Choke shaft .....		Choke A Matic
A02	1	1		692344	• Chokespjäll .....	• Choke valve .....		
A03	1	1		690802	• Fjäder o tätning .....	• Spring and seal .....		
A04	1			498027	Förgasare kpl .....	Carburettor assy .....		Walbro
A04		1		697594	Förgasare kpl .....	Carburettor assy .....		
A05	1	1		494379	• Spjällaxel .....	• Shaft .....		
A06	1	1		691750	•• Spjäll .....	•• Throttle valve .....		
A07	1	1		691636	•• Skruv .....	•• Screw .....		
A08	1	1		691326	•• Axeltätning .....	•• Shaft seal .....		
A09	1	1		690602	•• Axelbussning .....	•• Shaft bushing .....		
A10	1	1		690572	• Fjäder .....	• Spring .....		
A11	1	1		495097	• Chokeaxel .....	• Choke shaft .....		Manual Choke
A12	1	1		690464	•• Chokespjäll .....	•• Choke valve .....		
A13	1	1		691636	•• Skruv .....	•• Screw .....		
A14	1	1		690801	•• Fjäder o tätning .....	•• Spring and seal .....		
A15		1		694524	• Plugg .....	• Welch plug .....		
A15	1			695005	• Expansionsplugg .....	• Welch plug .....		
A16	1	1		692284	• Packning .....	• Gasket .....		
A17	1			497737	• Munstycke .....	• Nozzle .....		High Altitude Standard Standard
A17	1			691434	• Munstycke .....	• Nozzle .....		
A17		1		697592	• Munstycke .....	• Nozzle .....		
A18	1	1		495800	• Justerskruv .....	• Idle adjust screw .....		
A19	1	1		498030	• Nålventil .....	• Needle valve .....		
A20	1	1		691333	•• Begränsningshuv .....	•• Limiter cap .....		
A21	1	1		690577	• Säte .....	• Inlet seat .....		
A22	1	1		231855	• Nålventil .....	• Inlet needle valve .....		
A23	1	1		494381	• Flottör .....	• Float .....		
A24	1	1		690525	•• Flottöraxel .....	•• Float hinge pin .....		
A25	1	1		495933	• Flottörhus .....	• Bowl .....		
A26	1	1		281165	•• Packning .....	•• Gasket .....		
A27	1	1		692255	•• Tätningsbricka .....	•• Sealing washer .....		
A28	1	1		691657	•• Skruv .....	•• Float bowl screw .....		
A29	1			692317	• Nippel .....	• Hose connector .....		
A39		1		494768	Bränslekran .....	Shut-off valve .....		
B01	1			694941	Förgasare kpl .....	Carburettor assy .....		Nikki
B02	1			694909	• Spjällaxel .....	• Throttle shaft .....		
B03	1			694917	•• Spjäll .....	•• Throttle valve .....		
B04	1			690718	•• Skruv .....	•• Screw .....		
B05	1			690998	•• Tätning .....	•• Shaft seal .....		
B06	1			694913	• Chokeaxel .....	• Choke shaft .....		
B07	1			694923	•• Chokespjäll .....	•• Choke valve .....		
B08	1			690718	•• Skruv .....	•• Screw .....		
B09	1			694912	•• Fjäder o tätning .....	•• Spring and seal .....		
B10	1			692284	• Packning .....	• Gasket .....		
B11	1			694921	• Plugg .....	• Carburettor plug .....		
B12	1			694927	• Munstycke .....	• Pilot jet .....		
B13	1			694907	• Justerskruv .....	• Idle speed kit .....		
B14	1			694914	• Flottör .....	• Float .....		
B15	1			694918	•• Flottöraxel .....	•• Float hinge pin .....		
B16	1			694916	• Expansionsplugg .....	• Welch plug .....		
B17	1			694908	• Flottörhus .....	• Float bowl .....		
B18	1			690880	• Huvudmunstycke .....	• Main jet .....		Standard High Altitude
B18	1			694925	• Huvudmunstycke .....	• Main jet .....		
B19	1			694920	•• Packning .....	•• Gasket .....		
B20	1			694924	• Förgasarpplugg .....	• Carburettor plug .....		
B21	1			694922	• Nålventil .....	• Float needle valve .....		
B22	1			694926	• Tomgångsventil .....	• Idle mixture valve .....		
B23	1			690997	•• Tätningsbricka .....	•• Sealing washer .....		
B24	1			694919	•• Skruv .....	•• Float bowl screw .....		

A







Utgåva Issue		Bildnr Picture No		BRIGGS & STRATTON 286707, 28M707 STARTMOTOR (A)		BRIGGS & STRATTON 286707, 28M707 STARTER MOTOR (A)		Sida Page	
2003- 11		1186						214	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	286 707- 1185	28M 707- 1194							
A01	1	1		693551	Startmotor kpl .....	Starter motor assy .....			
A02	1	1		693699	• Startdrev .....	• Starter drive .....			
A03	1	1		691265	• • Låsring .....	• • Retaining ring .....			
A04	1	1		693713	• • Drev .....	• • Pinion gear .....			
A05	1	1		692024	• • Koppling .....	• • Drive clutch .....			
A06	1	1		692034	• Rotor .....	• Armature .....			
A07	1	1		693757	• Startmotorhus .....	• Starter housing .....			
A08	1	1		691283	• Lock .....	• Drive cap .....			
A08	1	1		691429	• Lock .....	• Drive cap .....			
A09	1	1		691293	• Borsthållare .....	• Brush retainer .....			
A10	1	1		497608	• • Släpkolssats .....	• • Brush set .....			
A11	1	1		693167	• • Mutter .....	• • Nut .....			
A12	1	1		691286	• Botten .....	• End cap .....			
A13	1	1		691029	• Mutter .....	• Nut .....			
A14	2	2		690323	• Bult .....	• Bolt .....			
A15	2	2		690372	Skruv .....	Screw .....			

A



B



Utgåva Issue		Bildnr Picture No		BRIGGS & STRATTON 286707, 28M707 PACKN.SATS MOTOR (A) PACKN.SATS FÖRG. (B)		BRIGGS & STRATTON 286707, 28M707 GASKET SET ENGINE (A) GASKET SET CARB. (B)		Sida Page 216
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	286 707- 1185	28M 707- 1194						
A01	1	1		494241	Packnings-sats- motor.....	Gasket set- engine.....		
A02	1	1		391086	• Tätningssring .....	• Seal .....		
A03	1	1		291675	• Tätningssring .....	• Oil seal .....		
A04	1	1		281370	• Tätning .....	• Seal .....		
A05	1	1		691917	• O- ring.....	• O- ring .....		
A06	1	1		691870	• Tätningssring .....	• Seal .....		
A07	1	1		692407	• Tätning .....	• Seal .....		
A08	1	1		692226	• Packning .....	• Gasket .....		.015" Standard
A08	1	1		692405	• Packning .....	• Gasket .....		.009"
A08	1	1		692406	• Packning .....	• Gasket .....		.005"
A09	1	1		271866	• Packning .....	• Gasket .....		
A10	1	1		27803	• Packning .....	• Gasket .....		
A11	1	1		692236	• Packning .....	• Gasket .....		
A12	1	1		498539	Packnings-sats- ventil.....	Gasket set- valve .....		
B01	1			499220	Reparationssats- förg. ....	Overhaul kit- carb. ....		Walbro
B01		1		697884	Rep.sats- förgas. ....	Carb. overhaul kit.....		
B02		1		694524	• Plugg .....	• Welch plug .....		
B02	1			695005	• Expansionsplugg .....	• Welch plug .....		
B03	1	1		281165	• Packning .....	• Gasket .....		
B04	1	1		692255	• Tätningssbricka .....	• Sealing washer .....		
B05	1	1		690577	• Säte .....	• Inlet seat .....		
B06	1	1		690525	• Flottöraxel.....	• Float hinge pin.....		
B07	1			691434	• Munstycke .....	• Nozzle .....		Standard
B07		1		697592	• Munstycke .....	• Nozzle .....		
B08	1	1		691636	• Skruv .....	• Screw .....		
B09	1	1		691326	• Axeltätning.....	• Shaft seal .....		
B10	1	1		231855	• Nålventil.....	• Inlet needle valve.....		
B11	1	1		691636	• Skruv .....	• Screw .....		
B12	1	1		692284	• Packning .....	• Gasket .....		
B13	1	1		690802	• Fjäder o tätning.....	• Spring and seal .....		Choke A Matic
B14	1	1		494385	Packningssats- förg. ....	Gasket set- carb. ....		Walbro
B15	1	1		690602	• Axelbussning .....	• Shaft bushing .....		
B16	1	1		690801	• Fjäder o tätning.....	• Spring and seal .....		Manual Choke
B17	1			694930	Reparationssats- förg. ....	Overhaul kit- carb. ....		Nikki
B18	1			690718	• Skruv .....	• Screw .....		
B19	1			690880	• Huvudmunstycke.....	• Main jet .....		Standard
B19	1			694925	• Huvudmunstycke.....	• Main jet .....		High Altitude
B20	1			690997	• Tätningssbricka .....	• Sealing washer .....		
B21	1			694918	• Flottöraxel.....	• Float hinge pin.....		
B22	1			694916	• Expansionsplugg .....	• Welch plug .....		
B23	1			694912	• Fjäder o tätning.....	• Spring and seal .....		
B24	1			694922	• Nålventil.....	• Float needle valve.....		
B25	1			694927	• Munstycke .....	• Pilot jet .....		
B26	1			690998	• Tätning .....	• Shaft seal .....		
B27	1			694920	• Packning .....	• Gasket .....		
B28	1			690718	• Skruv .....	• Screw .....		
B29	1			694924	• Förgasarplugg.....	• Carburettor plug.....		
B30	1			694931	Packningssats- förg. ....	Gasket set- carb. ....		Nikki