



Genuine Spare Parts




Joist
Spareparts
Joist




Utgåva Issue		Bildnr Picture No		ESTATE BASIC KAROSS		ESTATE BASIC BODY WORK		Sida Page	
2006-13		2074						60	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2572								
1	1			1136-1974-01	Motorhuv- gul.....	Engine hood- yellow.....		Inkl. pos 2, 8 - 10	
2	1			1136-0905-01	• Platta- gul	• Plate			
3	2			1136-0897-01	Bult	Bolt			
4	2			1136-0009-01	Låsplatta	Lock plate			
8	1			1136-1968-01	• Styrpinne- hö	• Pin- RH			
9	1			1136-1969-01	• Styrpinne- vä	• Pin- LH			
10	2			1136-1963-01	• Skruv	• Screw			
11	1			1136-1966-01	Instrumentbräda	Dashboard			
12	1			1136-1967-01	Platta	Plate			
14	2			9848-8013-16	Skruv	Screw			
15	2			1136-0010-01	Låsplatta	Lock plate			
16	3			9836-9618-12	Skruv	Screw			
17	1			1136-1971-01	Stöd	Dashboard support			
18	1			1136-0475-01	Hjulååpa- gul.....	Wheel cover- yellow.....	Inkl. pos 19 - 20		
19	1			1136-0148-01	• Fotstegsskydd- hö	• Footboard cover- RH			
20	1			1136-0147-01	• Fotstegsskydd- vä	• Footboard cover- LH			
21	6			9836-9635-12	Skruv	Screw			
22	4			9836-9618-12	Skruv	Screw			
23	1			9836-9525-12	Skruv	Screw			
24	5			9699-0060-02	Planbricka	Flat washer			
25	1			1136-1970-01	Avskiljare	Intake separator			
26	4			9699-0085-02	Planbricka	Flat washer			
31	1			1136-0440-01	Gasreglage	Throttle control			
32	2			9997-0412-16	Skruv	Screw			
33	2			9683-0010-02	Bricka	Washer			
34	1			1136-0192-01	Knopp	Handle			
35	1			9865-0412-16	Skruv	Screw			
36	1			9799-0431-02	Mutter	Nut			
41	1			1136-0920-01	Sits	Seat			
43	1			1136-0252-01	Sitsplatta	Seat plate			
44	4			9997-0820-16	Skruv	Screw			
45	4			9683-0030-02	Låsbricka	Lock washer			
46	4			9699-0056-02	Planbricka	Flat washer			
47	1			1136-0891-01	Fjäder	Spring			
48	1			9997-0512-16	Skruv	Screw			
49	1			9747-0531-02	Mutter	Nut			
51	1			1136-1155-01	Ratt	Steering wheel	Inkl. pos 53		
52	1			9595-0272-00	Stift	Pin			
53	1			1136-0873-01	• Lock	• Cap			
54	1			1136-0942-01	Kam	Cam			
55	2			1136-0820-01	Skruv	Screw			
56	2			9699-0018-02	Bricka	Washer			
57	2			9747-0531-02	Mutter	Nut			
61	1			1136-0869-01	Kåpa	Cover			
62	2			9836-9635-12	Skruv	Screw			
63	2			9699-0035-02	Planbricka	Flat washer			
64	2			9836-9618-12	Skruv	Screw			
81	1			1136-0275-01	Skydd- övre	Guard- upper			
82	1			1136-0276-01	Skydd- nedre	Guard- lower			
83	2			9847-8038-16	Skruv	Screw			
84	2			9699-0024-02	Planbricka	Flat washer			
85	2			1136-0010-01	Låsplatta	Lock plate			
91	1			1136-0318-01	Bränsletank	Fuel tank			
92	1			1136-0344-01	Tanklock	Tank cap			
93	1			1136-0327-01	Tankfäste	Tank support			
94	1			9848-8013-16	Skruv	Screw			
101	1			1136-1975-01	Ljuddämparskydd	Muffler protection	Inkl. pos 102		
102	2			1136-0061-01	• Plugg	• Cap			
103	4			9847-8216-16	Skruv	Screw			
104	1			1136-0259-01	Huvfäste- hö	Hood plate- RH			
105	1			1136-0260-01	Huvfäste- vä	Hood plate- LH			
106	4			9847-8009-16	Skruv	Screw			




Utgåva Issue 2006-13		Bildnr Picture No 2075		ESTATE TORNADO ESTATE TORNADO HST KAROSS		ESTATE TORNADO ESTATE TORNADO HST BODY WORK		Sida Page 62
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2546	2547						
X	1	1	1	1136-2072-01	Motorhuv-övre, gul.....	Engine hood-upper, ye.....		
X	2	1	1	1136-2101-01	Huv-övre hö, gul.....	Hood-upper RH, yellow.....		
X	3	1	1	1136-2106-01	Huv-undre hö, grå.....	Hood-lower RH, grey.....		
X	4	1	1	1136-2102-01	Huv-övre vä, gul.....	Hood-upper LH, yellow.....		
X	5	1	1	1136-2105-01	Huv-undre vä, grå.....	Hood-lower LH, grey.....		
X	6	1	1	1136-2176-01	Huv-främre, grå.....	Hood-front, grey.....		Inkl. pos 7 - 8
X	7	1	1	1136-2124-01	• Skydd, hö.....	• Grill, RH.....		
X	8	1	1	1136-2125-01	• Skydd, vä.....	• Grill, LH.....		
X	9	1	1	1136-2071-01	Huv-främre undre, grå.....	Hood-front lower, gre.....		
	10	2	2	1136-0179-01	Huvskydd.....	Grommet.....		
	11	1	1	1136-0871-01	Instrumentbräda.....	Dashboard.....		
X	12	6	6	1136-0816-01	Skruv.....	Screw.....		
	13	1	1	1136-2075-01	Kåpa.....	Conveyor.....		
	14	2	2	9848-8013-16	Skruv.....	Screw.....		
	15	2	2	1136-0010-01	Låsplatta.....	Lock plate.....		
	16	3	3	9836-9618-12	Skruv.....	Screw.....		
	17	1	1	1136-0926-01	Stöd.....	Support.....		
	18	1	1	1136-0475-01	Hjulkåpa- gul.....	Wheel cover-yellow.....		Inkl. pos 19, 20
	18		1	1136-0476-01	Hjulkåpa.....	Wheel cover.....		Inkl. pos 19, 20
	19	1	1	1136-0148-01	• Fotstegsskydd- hö.....	• Footboard cover- RH.....		
	20	1	1	1136-0147-01	• Fotstegsskydd- vä.....	• Footboard cover- LH.....		
	21	6	6	9836-9635-12	Skruv.....	Screw.....		
	22	4	4	9836-9618-12	Skruv.....	Screw.....		
	23	1	1	9836-9525-12	Skruv.....	Screw.....		
	24	5	5	9699-0060-02	Planbricka.....	Flat washer.....		
	25	4	4	9699-0085-02	Planbricka.....	Flat washer.....		
X	29	1	1	1136-2103-01	Kåpa, vä.....	Cover, LH.....		
X	30	1	1	1136-2104-01	Kåpa, hö.....	Cover, RH.....		
	31	1	1	1136-0440-01	Gasreglage.....	Throttle control.....		
	32	2	2	9997-0412-16	Skruv.....	Screw.....		
	33	2	2	9683-0010-02	Bricka.....	Washer.....		
	34	1	1	1136-0192-01	Knopp.....	Handle.....		
	35	1	1	9865-0412-16	Skruv.....	Screw.....		
	36	1	1	9799-0431-02	Mutter.....	Nut.....		
	41	1	1	1136-0315-01	Sits.....	Seat.....		
	43	1	1	1136-0252-01	Sitsplatta.....	Seat plate.....		
	44	4	4	9997-0820-16	Skruv.....	Screw.....		
	45	4	4	9683-0030-02	Låsbricka.....	Lock washer.....		
	46	4	4	9699-0056-02	Planbricka.....	Flat washer.....		
	47	1	1	1136-0891-01	Fjäder.....	Spring.....		
	48	1	1	9997-0512-16	Skruv.....	Screw.....		
	49	1	1	9747-0531-02	Mutter.....	Nut.....		
	51	1	1	1136-0360-01	Ratt.....	Steering wheel.....		
	52	1	1	9595-0272-00	Stift.....	Pin.....		
	54	1	1	1136-0942-01	Kam.....	Cam.....		
	55	2	2	1136-0820-01	Skruv.....	Screw.....		
	56	2	2	9699-0018-02	Bricka.....	Washer.....		
	57	2	2	9747-0531-02	Mutter.....	Nut.....		
	61	1	1	1136-0869-01	Kåpa.....	Cover.....		
	62	2	2	9836-9635-12	Skruv.....	Screw.....		
	63	2	2	9699-0035-02	Planbricka.....	Flat washer.....		
	64	2	2	9836-9618-12	Skruv.....	Screw.....		
	81	1	1	1136-0275-01	Skydd-övre.....	Guard-upper.....		
	82	1	1	1136-0276-01	Skydd-nedre.....	Guard-lower.....		
	83	2	2	9847-8038-16	Skruv.....	Screw.....		
	84	2	2	9699-0024-02	Planbricka.....	Flat washer.....		
	85	2	2	1136-0010-01	Låsplatta.....	Lock plate.....		
	91	1	1	1136-0318-01	Bränsletank.....	Fuel tank.....		
	92	1	1	1136-0344-01	Tanklock.....	Tank cap.....		
	93	1	1	1136-0327-01	Tankfäste.....	Tank support.....		
	94	1	1	9848-8013-16	Skruv.....	Screw.....		
X	101	1	1	1136-2190-01	Ljuddämparskydd.....	Muffler protection.....		Inkl. pos 102
X	102	2	2	1136-2063-01	• Plugg.....	• Cap.....		



Utgåva Issue 2006-13		Bildnr Picture No 2075		ESTATE TORNADO ESTATE TORNADO HST KAROSS		ESTATE TORNADO ESTATE TORNADO HST BODY WORK		Sida Page 64	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2546	2547							
X 103	4	4		9847-8216-16	Skruv	Screw			
104	2	2		1136-2130-01	Huvfäste	Hood plate			
105	4	4		9847-8009-16	Skruv	Screw			
X 106	1	1		1136-2142-01	Huvstöd	Hood support			
107	5	5		1136-0816-01	Skruv	Screw			
X 108	2	2		1136-2127-01	Axel	Pin			
109	2	2		9739-0831-22	Mutter	Nut			
110	2	2		9598-0002-02	Låsnål	Pin lock			




Utgåva Issue 2006-13		Bildnr Picture No 1562A		ESTATE BASIC ESTATE TORNADO ESTATE TORNADO HST DEKALER		ESTATE BASIC ESTATE TORNADO ESTATE TORNADO HST LABELS		Sida Page 66	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2572 2546	2547							
1	1	1		1136-0832-01	Dekal	Label			
2	1	1		1136-0026-01	Dekal	Label			
3	1	1		1136-0020-01	Dekal	Label			
5	1	1		1136-0031-01	Dekal	Label			
6	1			1136-0027-01	Dekal	Label			
7	1	1		1136-0028-01	Dekal	Label			
8	1	1		1136-0029-01	Dekal	Label			
9	1	1		1136-0021-01	Dekal	Label			
11	1	1		1136-1217-01	Dekal	Label			
12	1	1		1136-1635-01	Dekal	Label			
99	1	1		1136-1451-01	Dekal "STIGA"	Label "STIGA"		Ø 55 mm 140 x 33 mm Ej ill/not ill. Ej ill/not ill. Ej ill/not ill.	
X	99	3	3	1136-1453-01	Dekal "STIGA"	Label "STIGA"			
X	99		2	1136-2197-01	Dekal "Tornado HST K"	Label "Tornado HST K"			
X	99	2		1136-2202-01	Dekal "Tornado"	Label "Tornado"			
X	99	2		1136-2204-01	Dekal "Basic"	Label "Basic"			



Utgåva Issue		Bildnr Picture No		ESTATE BASIC ESTATE TORNADO ESTATE TORNADO HST CHASSI		ESTATE BASIC ESTATE TORNADO ESTATE TORNADO HST CHASSIS		Sida Page	
2006- 13		1563B						68	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2572 2546	2547							
1	1	1		1136-1499-01	Ram.....	Frame.....			
3	1	1		1136-0548-01	Fotstegsstöd- hö.....	Footboard support- RH.....			
4	1	1		1136-0549-01	Fotstegsstöd- vä.....	Footboard support- LH.....			
5	4	4		9898-0645-12	Skruv.....	Screw.....			
6	4	4		9699-0060-02	Planbricka.....	Flat washer.....			
7	4	4		9747-0631-02	Låsmutter.....	Lock nut.....			
21		1		1136-0267-01	Remstyrning.....	Belt guide.....			
22		2		9739-0631-22	Mutter.....	Nut.....			
23		2		1136-0261-01	Platta.....	Plate.....			
24		2		9997-0820-16	Skruv.....	Screw.....			
25		2		9747-0831-02	Mutter.....	Lock nut.....			
26	2			1136-0907-01	Remstyrning.....	Belt guide.....			
27	2			1136-0004-01	Fyrkantmutter.....	Square nut.....			
28	1	1		1136-0881-01	Remstyrning.....	Belt guide.....			
29	1	1		1136-0896-01	Fjäder.....	Spring.....			
30	2	2		1136-1247-01	Platta.....	Plate.....			
31	2	2		9847-8216-16	Skruv.....	Screw.....			
41	1	1		1136-0906-01	Plåt- bak.....	Plate- rear.....			
42	2	2		9997-0825-16	Skruv.....	Screw.....			
43	1	1		1136-1051-01	Förstärkning.....	Reinforcement.....			
45	1	1		9997-0816-16	Skruv.....	Screw.....			
46	1	1		9739-0831-22	Mutter.....	Nut.....			
48	2	2		9699-0056-02	Planbricka.....	Flat washer.....			
49	2	2		9747-0831-02	Mutter.....	Lock nut.....			
50	1	1		9997-0840-16	Skruv.....	Screw.....			
51	1	1		9699-0090-02	Planbricka.....	Flat washer.....			
52	1	1		9747-0831-02	Mutter.....	Lock nut.....			
53	2	2		9739-0831-22	Mutter.....	Nut.....			
61	1	1		1136-0337-01	Sitsfäste.....	Seat support.....			
62	2	2		1136-0301-01	Förstärkningsstag.....	Reinforcement plate.....			
63	4	4		9997-0614-16	Skruv.....	Screw.....			
64	4	4		9739-0631-22	Mutter.....	Nut.....			
65	4	4		9997-0620-16	Skruv.....	Screw.....			
66	4	4		9699-0060-02	Planbricka.....	Flat washer.....			
67	4	4		9747-0631-02	Låsmutter.....	Lock nut.....			
68	1	1		1136-0302-01	Förstärkningsstag.....	Reinforcement plate.....			
69	2	2		9699-0056-02	Planbricka.....	Flat washer.....			
70	2	2		1136-0202-02	Fjäder.....	Spring.....			
71	2	2		9699-0090-02	Planbricka.....	Flat washer.....			
72	2	2		9739-0831-22	Mutter.....	Nut.....			
73	2	2		1136-0358-01	Skruv.....	Screw.....			
74	2	2		1136-0003-01	Fyrkantmutter.....	Square nut.....			
76	2	2		1136-0321-01	Vinkelfäste.....	Bracket.....			
77	2	2		9997-0816-16	Skruv.....	Screw.....			
78	2	2		9739-0831-22	Mutter.....	Nut.....			
79	2	2		1136-0086-01	Bult.....	Bolt.....			
80	2	2		9712-0831-02	Låsmutter.....	Lock nut.....			
81	2	2		9997-0512-16	Skruv.....	Screw.....			
82	1	1		1136-0322-01	Vinkelfäste.....	Bracket.....			
83	2	2		9747-0531-02	Mutter.....	Nut.....			
84	1	1		1136-0925-01	Vinkelfäste.....	Angle bracket.....			
85	2	2		9847-8009-16	Skruv.....	Screw.....			
91	1	1		1136-0333-01	Stöd.....	Support.....			
92	2	2		9997-0614-16	Skruv.....	Screw.....			
93	2	2		9739-0631-22	Mutter.....	Nut.....			
94	2	2		9997-0614-16	Skruv.....	Screw.....			
95	2	2		9739-0631-22	Mutter.....	Nut.....			

X




Utgåva Issue 2006-13	Bildnr Picture No 1213C	ESTATE BASIC ESTATE TORNADO ESTATE TORNADO HST STYRNING	ESTATE BASIC ESTATE TORNADO ESTATE TORNADO HST STEERING	Sida Page 70
----------------------------	-------------------------------	--	--	--------------------

Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2546	2547	2572					
1	1	1	1	1136-0466-01	Framaxel kpl	Front wheel axle assy		Inkl. pos 2, 3
2	4	4	4	1136-0121-01	• Bussning	• Bushing		
3	2	2	2	9501-0500-00	• Smörjnippel	• Grease joint		
4	1	1	1	1136-0485-01	Hjulspindel- hö	Stub axle- RH		
5	1	1	1	9652-0015-04	Låsring	Retaining ring		
6	1	1	1	1136-0486-01	Hjulspindel- vä	Stub axle- LH		
7	1	1	1	1136-0349-01	Parallellstag	Tie rod		
8	2	2	2	1136-0092-01	Kulled	Ball joint		
9	2	2	2	9747-1031-02	Låsmutter	Lock nut		
11	1	1	1	1136-0188-01	Styrmutter	Steering arm		
12	1	1	1	9997-1055-12	Skruv	Screw		
13	1	1	1	9747-1031-02	Låsmutter	Lock nut		
14	1	1	1	1136-0165-01	Distans	Spacer		
15	1	1	1	9997-1260-02	Skruv	Screw		
16	2	2	2	1136-0016-01	Bricka	Washer		
17	1	1	1	9683-0055-02	Låsbricka	Lock washer		
18	1	1	1	9799-1231-02	Mutter	Nut		
31	1	1	1	1136-0335-01	Stöd	Support		
32	4	4	4	9997-0816-16	Skruv	Screw		
33	4	4	4	9747-0831-02	Mutter	Lock nut		
34	1	1	1	1136-1496-01	Fäste	Support		
35	4	4	4	9847-8216-16	Skruv	Screw		
36	1	1	1	1136-1469-01	Bussning	Bushing		
37	1	1	1	1136-1471-01	Rattstång	Steering column		
38	1	1	1	1136-0263-02	Styrdrev	Steering pinion		
39	1	1	1	9595-0262-00	Spännstift	Locating pin		
40	1	1	1	9699-0037-02	Bricka	Washer		
41	1	1	1	1136-0008-01	Låsplatta	Lock plate		
42	1	1	1	1136-0128-01	Bussning	Bushing		
43	1	1	1	1136-0246-01	Pinnbult	Stud bolt		
44	1	1	1	9799-1031-02	Mutter	Nut		
45	2	2	2	1136-0310-01	Bricka	Washer		
46	1	1	1	1136-0320-01	Styrsektor	Steering sector		
47	1	1	1	1136-0311-01	Bricka	Washer		
48	1	1	1	1136-0083-01	Fjäderbricka	Elastic washer		
49	1	1	1	9699-0035-02	Planbricka	Flat washer		
50	2	2	2	9799-1031-02	Mutter	Nut		
51	3	3	3	1136-0087-01	Bricka	Washer		
52	1	1	1	1136-0015-01	Bricka	Washer		
53	1	1	1	9599-0070-02	Saxsprint	Split pin		
54	1	1	1	9747-1031-02	Låsmutter	Lock nut		
55	1	1	1	1136-0111-01	Styrstag	Steering rod		
56	2	2	2	1136-0092-01	Kulled	Ball joint		
58	2	2	2	9747-1031-02	Låsmutter	Lock nut		
59	1	1	1	1136-0279-01	Brytarskydd	Micro protection		
60	2	2	2	9847-7813-16	Skruv	Screw		
61	2	2	2	9699-0035-02	Planbricka	Flat washer		
62	1	1	1	1136-1477-01	Stöd	Support		
63	2	2	2	9847-8116-16	Skruv	Screw		
64	1	1	1	1136-1473-01	Länk	Joint		
72	2	2	2	1136-0454-01	Fälg	Rim		
73	4	4	4	1136-0157-01	Lager	Bearing		
74	2	2	2	1136-0269-01	Däck (Turf Saver)	Tire (Turf Saver)		
74	2	2	2	1136-0271-01	Däck (Deli)	Tire (Deli)		
74	2	2	2	1136-2133-01	Däck (Kenda)	Tire (Kenda)		
75	2	2	2	1136-0305-01	Bricka	Washer		
76	2	2	2	9652-0015-04	Låsring	Retaining ring		
77	2	2	2	1136-0081-01	Navkapsel	Hub cap		
78	2	2	2	9545-0500-00	Ventil	Valve		


X

X




Utgåva Issue 2006- 13	Bildnr Picture No 1214A	ESTATE BASIC ESTATE TORNADO BROMSREGLAGE VÄXELREGLAGE	ESTATE BASIC ESTATE TORNADO BRAKE CONTROL GEAR SHIFTER CONTROL	Sida Page 72
-----------------------------	-------------------------------	--	---	--------------------

Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2572							
	2546							
1	1			1136-0506-01	Bromspedal	Brake pedal		
2	1			1136-0152-01	Pedalskydd	Pedal cover		
3	1			1136-0254-01	Bygel	Clamp		
4	1			1136-0255-01	Bygel	Clamp		
5	6			9847-8016-16	Skruv	Screw		
6	1			1136-0116-01	Bromsstång	Brake rod		
7	1			1136-0244-01	Ledbult	Pivot bolt		
8	1			1136-0218-01	Fjäder	Spring		
9	2			9699-0035-02	Planbricka	Flat washer		
10	1			9799-1031-02	Mutter	Nut		
11	1			1136-0172-01	Distans	Spacer		
12	1			1136-0329-01	Bygel	Clamp		
13	1			9699-0060-02	Planbricka	Flat washer		
14	1			9747-0631-02	Låsmutter	Lock nut		
15	1			9699-0090-02	Planbricka	Flat washer		
16	1			1136-0009-01	Låsplatta	Lock plate		
17	1			1136-0441-01	Spärraxel	Axle		
18	1			1136-0217-01	Fjäder	Spring		
19	2			1136-0256-01	Bygel	Plate		
20	4			9847-8016-16	Skruv	Screw		
21	1			1136-0119-01	P- bromsarm	P- brake lever		
22	1			9675-0011-00	Starlock	Starlock		
23	1			1136-0392-01	Knopp	Knob		
24	1			9747-1031-02	Låsmutter	Lock nut		
31	1			1136-0233-01	Pinnbult	Stud bolt		
32	1			9712-0831-02	Låsmutter	Lock nut		
33	1			1136-0088-01	Bricka	Washer		
34	1			1136-0529-01	Spakhållare	Gear lever bracket		
35	1			1136-0490-01	Växelspak	Gear lever		
36	1			1136-0212-01	Fjäder	Spring		
37	1			9997-0880-16	Skruv	Screw		
38	1			9747-0831-02	Mutter	Lock nut		
39	1			9699-0056-02	Planbricka	Flat washer		
40	1			9712-0831-02	Låsmutter	Lock nut		
41	1			1136-0197-01	Handtag	Knob		
42	1			1136-0107-01	Växlestag	Shifter rod		
43	1			1136-0093-01	Kulled	Ball joint		
44	1			9683-0030-02	Låsbricka	Lock washer		
45	1			9799-0831-02	Mutter	Nut		
46	1			1136-0187-01	Växelarm	Gearshift arm		
47	1			9997-0640-12	Skruv	Screw		
48	2			9699-0035-02	Planbricka	Flat washer		
49	1			9747-0631-02	Låsmutter	Lock nut		
50	1			9599-0070-02	Saxsprint	Split pin		




Utgåva Issue 2006- 13	Bildnr Picture No 1215B	ESTATE TORNADO HST BROMSREGLAGE DRIVREGLAGE	ESTATE TORNADO HST BRAKE CONTROL DRIVE CONTROL	Sida Page 74
-----------------------------	-------------------------------	---	--	--------------------


Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2547								
1	1				1136-0510-01	Pedal	Pedal		
2	1				1136-0151-01	Pedalskydd	Pedal cover		
3	1				1136-0254-01	Bygel	Clamp		
4	4				9847-8016-16	Skruv	Screw		
5	1				1136-0117-01	Bromsstång	Brake rod		
6	1				9699-0090-02	Planbricka	Flat washer		
7	1				9675-0012-02	Starlock	Locking washer		
8	1				1136-0248-01	Ledbult	Pivot bolt		
9	1				1136-0218-01	Fjäder	Spring		
10	2				9699-0035-02	Planbricka	Flat washer		
11	1				1136-0329-01	Bygel	Clamp		
12	1				9799-1031-02	Mutter	Nut		
13	1				9747-1031-02	Låsmutter	Lock nut		
14	1				9699-0090-02	Planbricka	Flat washer		
15	1				9747-0831-02	Mutter	Lock nut		
31	1				1136-0441-01	Spärraxel	Axle		
32	1				1136-0217-01	Fjäder	Spring		
33	2				1136-0256-01	Bygel	Plate		
34	4				9847-8016-16	Skruv	Screw		
35	1				1136-0119-01	P- bromsarm	P- brake lever		
36	1				9675-0011-00	Starlock	Starlock		
37	1				1136-0392-01	Knopp	Knob		
51	1				1136-0507-01	Drivpedal	Drive pedal		
52	1				1136-0149-01	Pedalskydd- fram	Pedal cover- front		
53	1				1136-0150-01	Pedalskydd- bak	Pedal cover- rear		
54	1				1136-1495-01	Fäste kpl	Support assy		Inkl. pos 55 - 56
55	2				1136-0121-01	• Bussning	• Bushing		
56	1				9501-0500-00	• Smörjnippel	• Grease joint		
57	2				9997-0616-16	Skruv	Screw		
58	2				9739-0631-22	Mutter	Nut		
59	1				1136-0500-01	Pedalaxel	Pedal axle		
60	2				9650-0020-04	Spärring	Circlip		
61	1				1136-0090-01	Bricka	Washer		
62	1				9997-0816-16	Skruv	Screw		
63	1				9683-0030-02	Låsbricka	Lock washer		
64	1				1136-0118-01	Stag	Drive rod		
65	1				1136-0241-01	Ledbult	Pivot bolt		
66	1				1136-0247-01	Ledbult	Pivot bolt		
67	2				9799-0831-02	Mutter	Nut		
68	2				9747-0831-02	Mutter	Lock nut		
69	1				9699-0035-02	Planbricka	Flat washer		
70	1				9699-0060-02	Planbricka	Flat washer		
71	1				9747-0631-02	Låsmutter	Lock nut		
72	1				1136-0533-01	Fäste	Support		
73	1				9699-0060-02	Planbricka	Flat washer		
74	1				9747-0631-02	Låsmutter	Lock nut		
75	1				9997-0620-16	Skruv	Screw		
76	1				9747-0631-02	Låsmutter	Lock nut		
77	1				1136-0330-01	Bygel	Clamp		
78	2				9848-8013-16	Skruv	Screw		
80	1				1136-0407-01	Plåt	Plate		
81	2				1136-1214-01	Skruv	Screw		
82	2				1136-0610-01	Bricka	Washer		



Utgåva Issue		Bildnr Picture No		ESTATE BASIC ESTATE TORNADO ESTATE TORNADO HST ELUTRUSTNING		ESTATE BASIC ESTATE TORNADO ESTATE TORNADO HST EL. EQUIPMENT		Sida Page	
2006- 13		2076						76	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2546	2547	2572						
X	1	1	1	1136-2170-01	Kabelhärva.....	Cable harness			
	2	1	1	1136-0919-01	Elektronikkort	Electronic card			
	3	2	2	9847-7813-16	Skruv	Screw			
	4	1	1	1136-0428-01	Säkring	Fuse		6.3 A	
	5	1	1	786194	Brytare.....	Neutral start switch		Neutral	
	6	3	3	1136-0073-01	Mikrobrytare.....	Micro switch			
X	10	1	1	1136-2169-01	Kabelhärva.....	Cable harness		Inkl. pos 11	
	11	1	1	1136-0056-01	• Tändningslås	• Ignition switch		Inkl. pos 12 - 13	
	12	1	1	1136-0049-01	•• Mutter	•• Nut			
	13	1	1	1134-4097-01	•• Täckkåpa.....	•• Cap			
X	14	1	1	1136-2028-01	Tändningsnyckel.....	Ignition key			
	15	1	1	1136-0065-01	Startrelä.....	Solenoid			
	16	2	2	9997-0620-16	Skruv	Screw			
	17	2	2	9794-5131-02	Mutter.....	Nut			
	18	1	1	1136-0055-01	Brytare.....	Switch		Strålkastare/light	
X	19	1	1	1136-2166-01	Kabel.....	Cable		Inkl. pos 20	
	20	2	2	1136-0429-01	• Lamphållare.....	• Lamp holder			
	21	2	2	1136-0058-01	Glödlampa	Bulb			
	22	1	1	1136-0135-01	Kabel	Cable			
	24	1	1	1136-0136-01	Kabel	Cable			
	25	1	1	1134-4804-01	Batteri.....	Battery			
	26	1	1	1136-0215-01	Fjäder.....	Spring			
	27	1	1	1136-0059-01	Polskydd.....	Protection			
	28	1	1	9795-3531-02	Mutter.....	Nut			
	29	4	4	1136-0427-01	Kabelhållare	Cable holder			
	30	1	1	1136-0426-01	Kabelhållare	Cable holder			
	31	1	1	1136-0076-01	Mikrobrytare.....	Micro switch			
	32	1	1	1136-0865-01	Kabel.....	Cable			
	33	2	2	9739-0631-22	Mutter.....	Nut			
	34	1	1	1136-0060-01	Polskydd.....	Protection			
X	35	1	1	1136-2161-01	Säkring.....	Fuse		25 A	




Utgåva Issue		Bildnr Picture No		ESTATE BASIC ESTATE TORNADO MOTOR (B&S 21A907)		ESTATE BASIC ESTATE TORNADO ENGINE (B&S 21A907)		Sida Page	
2006-13		1701A						78	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2572	2546							
2	1			1136-1790-01	Bränsleslang	Fuel hose			
3	4			1136-0045-01	Slangklämma	Hose clamp			
4	1			1136-1467-01	Avgasrör	Exhaust tube			
5	2			9683-0030-02	Låsbricka	Lock washer			
6	2			9988-3619-16	Skruv	Screw			
7	1			9997-0840-16	Skruv	Screw		L = 40 mm	
8	1			9677-0009-02	Låsbricka	Lock washer			
9	1			9739-0831-22	Mutter	Nut			
10	1			1136-0273-01	Oljeavtappningsrör	Oil drain tube			
11	1			1136-0066-01	Oljeavtappningsplugg	Oil drain plug			
12	1			1136-0054-01	Tätningring	Oil seal			
13	1			1136-0353-01	Bränsleslang	Fuel hose			
14	2			9997-0820-16	Skruv	Screw			
15	2			9677-0009-02	Låsbricka	Lock washer			
16	1			1136-1054-01	Ljuddämpare	Muffler			
17	2			1136-0004-01	Fyrkantmutter	Square nut			
18	1			1136-1048-01	Skydd	Guard			
19	2			9997-0816-16	Skruv	Screw			
20	2			9683-0030-02	Låsbricka	Lock washer			
24	3			9739-0831-22	Mutter	Nut			
25	3			9997-0835-12	Skruv	Screw		L = 35 mm	



Utgåva Issue 2006-13	Bildnr Picture No 1863A	ESTATE TORNADO HST MOTOR (Kohler)	ESTATE TORNADO HST ENGINE (Kohler)	Sida Page 80
----------------------------	-------------------------------	---	--	--------------------

Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2547								
	2	1			1136-0354-01	Bränsleslang	Fuel hose		
	3	2			1136-0045-01	Stangklämma	Hose clamp		
X	4	3			1136-2051-01	Skruv	Screw		
	5	1			9739-0831-22	Mutter	Nut		
	6	1			9997-0840-16	Skruv	Screw		
	7	1			9677-0009-02	Låsbricka	Lock washer		
	8	1			1136-0413-01	Oljeavtappningsrör	Oil drain pipe		
	9	1			1136-0066-01	Oljeavtappningsplugg	Oil drain plug		
	10	1			1136-0054-01	Tätningring	Oil seal		
	11	1			1136-1780-01	Avgasrör	Exhaust tube		
	12	2			9988-3619-16	Skruv	Screw		
X	13	2			9683-0030-02	Låsbricka	Lock washer		
	14	3			1136-2097-01	Distans	Spacer		
	31	1			1136-1054-01	Ljuddämpare	Muffler		
	32	2			9997-0820-16	Skruv	Screw		
	33	2			9677-0009-02	Låsbricka	Lock washer		
	34	2			1136-0004-01	Fyrkantmutter	Square nut		
	35	1			1136-1812-01	Skydd	Guard		
	36	2			9997-0816-16	Skruv	Screw		
	37	2			9683-0030-02	Låsbricka	Lock washer		




Spareparts Joist

Utgåva Issue 2006- 13	Bildnr Picture No 1217	ESTATE BASIC ESTATE TORNADO TRANSMISSION	ESTATE BASIC ESTATE TORNADO TRANSMISSION	Sida Page 82
-----------------------------	------------------------------	--	--	--------------------


Pos. Fig.	Antal/Quantity		Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2546	2572					
1	1	1	1136-0286-01	Motorremskiva	Engine belt pulley		
2	1	1	9987-5351-12	Skruv	Screw		
3	1	1	9683-0045-02	Bricka	Washer		
5	1	1	1136-0433-01	Kilrem	V-belt		
6	1	1	1136-0489-01	Spännarm	Tension arm		
7	1	1	9997-0630-12	Skruv	Screw		
8	2	2	1136-0123-01	Bussning	Bushing		
9	1	1	9747-0831-02	Mutter	Lock nut		
10	1	1	1136-0166-01	Distans	Spacer		
11	1	1	1136-0289-01	Spännrulle	Idler pulley		
12	1	1	9699-0056-02	Planbricka	Flat washer		
13	1	1	9747-0831-02	Mutter	Lock nut		
14	1	1	1136-0235-01	Ledbult	Pivot bolt		
15	2	2	1136-0309-01	Bricka	Washer		
16	1	1	9747-0831-02	Mutter	Lock nut		
17	1	1	1136-0348-01	Spännstång	Tie rod		
18	2	2	9799-0831-02	Mutter	Nut		
19	1	1	1136-0208-01	Fjäder	Spring		
20	1	1	1136-0162-01	Distans	Spacer		
21	1	1	9997-0880-16	Skruv	Screw		
22	1	1	9739-0831-22	Mutter	Nut		
23	1	1	9747-0831-02	Mutter	Lock nut		
24	1	1	1136-0346-01	Spännstång	Tie rod		
25	1	1	1136-0093-01	Kulled	Ball joint		
26	1	1	9683-0030-02	Låsbricka	Lock washer		
27	1	1	9799-0831-02	Mutter	Nut		
28	1	1	9699-0090-02	Planbricka	Flat washer		
29	1	1	9675-0012-02	Starlock	Locking washer		
30	1	1	1136-0290-01	Remrulle	Belt roller		
31	1	1	1136-0234-01	Pinnbult	Stud bolt		
32	1	1	9699-0056-02	Planbricka	Flat washer		
33	2	2	9747-0831-02	Mutter	Lock nut		
34	2	2	1136-0915-01	Remrulle	Belt roller		
35	1	1	1136-0167-01	Distans- vä	Spacer- LH		
36	1	1	1136-0164-01	Distans- hö	Spacer- RH		
37	1	1	9997-0835-12	Skruv	Screw		
38	1	1	9997-0845-12	Skruv	Screw		
39	2	2	9699-0056-02	Planbricka	Flat washer		
40	2	2	9747-0831-02	Mutter	Lock nut		
41	1	1	1136-0520-01	Remskiva	Belt pulley		
42	1	1	9600-0050-00	Woodruffkil	Key		
43	1	1	9650-0016-04	Spårring	Lock ring		
44	1	1	1136-0050-01	Transaxel	Transaxle		Peerless MST 205-535
45	4	4	9997-0860-16	Skruv	Screw		
47	4	4	9739-0831-22	Mutter	Nut		
48	2	2	1136-0325-01	Momentstag	Stay		
49	2	2	1136-0017-01	Skruv	Screw		
50	2	2	9997-0816-16	Skruv	Screw		
51	2	2	9739-0831-22	Mutter	Nut		
52	1	1	1136-0181-01	Remstyrning	Belt guide		
53	4	4	9699-0035-02	Planbricka	Flat washer		
54	2	2	9747-0831-02	Mutter	Lock nut		
55	2	2	1136-0868-01	Lock	Cover		
72	2	2	1136-0455-01	Fälg	Rim		
73		2	1136-0270-01	Däck (Turf Saver)	Tire (Turf Saver)		
73		2	1136-0272-01	Däck (Deli)	Tire (Deli)		
73	2		1136-2132-01	Däck (Kenda)	Tire (Kenda)		
74	2-4	2-4	9699-0119-02	Bricka	Washer		
75	2	2	1136-0305-01	Bricka	Washer		
76	2	2	9652-0015-04	Låsring	Retaining ring		
77	2	2	1136-0081-01	Navkapsel	Hub cap		
78	2	2	9545-0500-00	Ventil	Valve		

X




Utgåva Issue		Bildnr Picture No		ESTATE TORNADO HST TRANSMISSION		ESTATE TORNADO HST TRANSMISSION		Sida Page	
2006-13		1564						84	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2547								
1	1			1136-0287-01	Motorremskiva	Engine belt pulley			
2	1			9987-5351-12	Skruv	Screw			
3	1			9683-0045-02	Bricka	Washer			
5	1			1136-0432-01	Kilrem	V-belt			
6	1			1136-0489-01	Spännarm	Tension arm			
7	1			9997-0630-12	Skruv	Screw			
8	2			1136-0123-01	Bussning	Bushing			
9	1			9747-0831-02	Mutter	Lock nut			
10	1			1136-0166-01	Distans	Spacer			
11	1			1136-0289-01	Spännrulle	Idler pulley			
12	1			9699-0056-02	Planbricka	Flat washer			
13	1			9747-0831-02	Mutter	Lock nut			
14	1			1136-0235-01	Ledbult	Pivot bolt			
15	2			1136-0309-01	Bricka	Washer			
16	1			9747-0831-02	Mutter	Lock nut			
17	1			1136-0348-01	Spännstång	Tie rod			
18	2			9799-0831-02	Mutter	Nut			
19	1			1136-0208-01	Fjäder	Spring			
20	1			1136-0162-01	Distans	Spacer			
21	1			9997-0880-16	Skruv	Screw			
22	1			9739-0831-22	Mutter	Nut			
23	1			9747-0831-02	Mutter	Lock nut			
24	1			1136-0290-01	Remrulle	Belt roller			
25	1			1136-0234-01	Pinnbult	Stud bolt			
26	1			9699-0056-02	Planbricka	Flat washer			
27	2			9747-0831-02	Mutter	Lock nut			
28	2			1136-0915-01	Remrulle	Belt roller			
29	1			1136-0174-01	Distans-vä	Spacer-LH			
30	1			1136-0170-01	Distans-hö	Spacer-RH			
31	1			9997-0840-16	Skruv	Screw			
32	1			9997-0850-16	Skruv	Screw			
33	2			9699-0056-02	Planbricka	Flat washer			
34	2			9747-0831-02	Mutter	Lock nut			
35	2			1136-0868-01	Lock	Cover			
41	1			1136-0053-01	Transaxel	Transaxle			
42	4			9997-0860-16	Skruv	Screw		Kanzaki K46S	
44	4			9739-0831-22	Mutter	Nut			
45	1			1136-1056-01	Stöd	Support			
46	1			9997-0845-12	Skruv	Screw			
47	2			9699-0090-02	Planbricka	Flat washer			
48	1			9747-0831-02	Mutter	Lock nut			
50	1			9997-0816-16	Skruv	Screw			
52	1			1136-0190-01	Arm	Lever			
53	1			9997-0820-16	Skruv	Screw			
54	1			1136-0006-01	Fjäderbricka	Elastic washer			
55	1			1136-0309-01	Bricka	Washer			
56	1			9747-0831-02	Mutter	Lock nut			
57	1			1136-0114-01	Stag	Rod			
58	1			9675-0009-02	Starlock	Starlock			
61	1			1136-0918-01	Förstärkning	Reinforcement			
62	2			1136-0821-01	Skruv	Screw			
63	2			9699-0090-02	Planbricka	Flat washer			
64	4			9739-0831-22	Mutter	Nut			
65	1			1136-0822-01	Skruv	Screw			
72	2			1136-0455-01	Fälg	Rim			
73	2			1136-2132-01	Däck (Kenda)	Tire (Kenda)			
74	2			9545-0500-00	Ventil	Valve			
75	4			9699-0119-02	Bricka	Washer			
76	2			1136-0175-01	Distans	Spacer			
77	2			1136-0312-01	Bricka	Washer			
78	2			9652-0015-04	Låsring	Retaining ring			
79	2			1136-0081-01	Navkapsel	Hub cap			




X




Utgåva Issue		Bildnr Picture No		ESTATE BASIC ESTATE TORNADO ESTATE TORNADO HST AGGREGATSLYFT		ESTATE BASIC ESTATE TORNADO ESTATE TORNADO HST MOWER DECK LIFT		Sida Page	
2006-13		1702						86	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2572	2546	2547						
1	1			1136-0487-01	Lyftspak kpl	Lift lever assy		Inkl. pos 2 - 9	
2	1			1136-0493-01	• Lyftspak	• Lift lever			
3	1			1136-0298-01	• Tryckknapp	• Button			
4	1			1136-0222-01	• Spärrhake	• Dog			
5	1			1136-0227-01	• Sprint	• Pin			
6	1			1136-0105-01	• Tryckstång	• Push rod			
7	1			1136-0193-01	• Handtag	• Handle			
8	1			1136-0203-01	• Fjäder	• Spring			
9	1			9675-0012-02	• Starlock	• Locking washer			
10	1			1136-0444-01	Lyftaxel	Axle			
11	2			1136-0078-01	Bussning	Bushing			
12	1			1136-0163-01	Distans	Spacer			
13	1			9699-0119-02	Bricka	Washer			
14	2			9595-0235-00	Spännstift	Locating pin			
15	1			1136-0319-01	Höjdställn.segment	Height adjust sector			
16	2			9997-0816-16	Skruv	Screw			
17	2			9739-0831-22	Mutter	Nut			
18	1			1136-0460-01	Lyftwire	Lift wire			
19	1			1136-0291-01	Wirerulle	Cable pulley			
20	1			1136-0232-01	Distans	Spacer			
21	1			9997-0850-16	Skruv	Screw			
22	1			9699-0056-02	Planbricka	Flat washer			
23	1			9739-0831-22	Mutter	Nut			
24	1			1136-0443-01	Lyftaxel	Lift axle			
25	2			1136-0253-01	Bygel	Clamp			
26	4			9997-0616-16	Skruv	Screw			
27	4			9739-0631-22	Mutter	Nut			
28	1			1136-0492-01	Lyftarm	Lift arm			
29	2			1136-0255-01	Bygel	Clamp			
30	4			9847-8016-16	Skruv	Screw			
31	1			1136-0108-01	Lyftstag	Lift rod			
32	1			1136-0235-01	Ledbult	Pivot bolt			
33	1			9799-0831-02	Mutter	Nut			
34	1			9747-0831-02	Mutter	Lock nut			
35	2			1136-0309-01	Bricka	Washer			
36	1			9747-0831-02	Mutter	Lock nut			
37	1			9699-0090-02	Planbricka	Flat washer			
38	1			1136-0095-01	Låsnål	Hair pin			
51	1			1136-0347-01	Lyftlänk	Lift tie rod			
52	1			1136-0231-01	Ledbult	Pivot bolt			
53	1			9699-0035-02	Planbricka	Flat washer			
54	1			1136-0308-01	Bricka	Washer			
55	1			1136-0095-01	Låsnål	Hair pin			
56	2			1136-0308-01	Bricka	Washer			
57	2			9747-1031-02	Låsmutter	Lock nut			
58	1			9799-1031-02	Mutter	Nut			
61	1			1136-0347-01	Lyftlänk	Lift tie rod			
62	1			1136-0231-01	Ledbult	Pivot bolt			
63	1			9699-0035-02	Planbricka	Flat washer			
64	1			1136-0308-01	Bricka	Washer			
65	1			1136-0095-01	Låsnål	Hair pin			
66	2			1136-0308-01	Bricka	Washer			
67	2			9747-1031-02	Låsmutter	Lock nut			
68	1			9799-1031-02	Mutter	Nut			
71	1			1136-0928-01	Spännlänk	Tie rod			
72	1			1136-0231-01	Ledbult	Pivot bolt			
73	2			1136-0308-01	Bricka	Washer			
74	2			9747-1031-02	Låsmutter	Lock nut			
75	1			9699-0035-02	Planbricka	Flat washer			
76	1			1136-0308-01	Bricka	Washer			
77	1			1136-0095-01	Låsnål	Hair pin			
78	1			9799-1031-02	Mutter	Nut			



Utgåva Issue 2006-13		Bildnr Picture No 1448B		ESTATE BASIC ESTATE TORNADO ESTATE TORNADO HST AGGREGATSINKOPPLING		ESTATE BASIC ESTATE TORNADO ESTATE TORNADO HST MOWER DECK ENGAGEMENT		Sida Page 88	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2572	2546	2547						
1	1			1136-0494-01	Spännarm.....	Tension arm.....			
2	1			1136-0917-01	Remskiva.....	Pulley.....			
3	1			1136-0070-01	Kullager.....	Ball bearing.....			
4	1			9651-0035-04	Låsring.....	Lock ring.....			
5	1			9650-0015-04	Låsring.....	Lock ring.....			
6	1			9997-0890-12	Skruv.....	Screw.....			
7	2			1136-0014-01	Bricka.....	Washer.....			
8	1			1136-0089-01	Bricka.....	Washer.....			
9	1			9747-0831-02	Mutter.....	Lock nut.....			
10	1			1136-0859-01	Fjäder.....	Spring.....			
11	1			1136-0348-01	Spännstång.....	Tie rod.....			
12	2			9799-0831-02	Mutter.....	Nut.....			
13	1			1136-1797-01	Stag.....	Rod.....			
14	1			1136-0836-01	Gaffel.....	Fork.....			
15	1			9799-0831-02	Mutter.....	Nut.....			
16	1			1136-0835-01	Låsbult.....	Clip.....			
17	1			1136-0009-01	Låsplatta.....	Lock plate.....			
18	1			1136-0886-01	Arm- hö.....	Lever- RH.....			
19	1			1136-0885-01	Arm- vä.....	Lever- LH.....			
20	2			1136-0089-01	Bricka.....	Washer.....			
21	2			9997-0816-16	Skruv.....	Screw.....			
22	2			1136-0079-01	Bussning.....	Bushing.....			
23	2			9739-0831-22	Mutter.....	Nut.....			
24	1			1136-0904-01	Sprint.....	Pin.....			
25	2			1136-0309-01	Bricka.....	Washer.....			
26	1			9747-0831-02	Mutter.....	Lock nut.....			
27	1			1136-0862-01	Stång.....	Rod.....			
28	2			9699-0090-02	Planbricka.....	Flat washer.....			
29	1			1136-0895-01	Fjäder.....	Spring.....			
31	1			9739-0831-22	Mutter.....	Nut.....			
32	1			1136-0095-01	Låsnål.....	Hair pin.....			
33	1			1136-1022-01	Drivrem.....	Drive belt.....			
34	1			1136-0878-01	Remstyrning.....	Belt guide.....			
35	2			9847-8116-16	Skruv.....	Screw.....			
36	1			1136-0880-01	Remstyrning.....	Belt guide.....			
37	2			9739-0831-22	Mutter.....	Nut.....			
38	2			9747-0831-02	Mutter.....	Lock nut.....			
39	1			1136-0879-01	Remstyrning.....	Belt guide.....			
40	1			9739-0831-22	Mutter.....	Nut.....			
41	1			9747-0831-02	Mutter.....	Lock nut.....			
42	1			9699-0035-02	Planbricka.....	Flat washer.....			
43	1			9747-0631-02	Låsmutter.....	Lock nut.....			
44	2			1136-0864-01	Remkåpa.....	Belt cover.....			
45	4			9848-8013-16	Skruv.....	Screw.....			
71	1			1136-0537-01	Fäste.....	Support.....			
72	2			9997-0816-16	Skruv.....	Screw.....			
73	2			9739-0831-22	Mutter.....	Nut.....			
74	1			1136-0088-01	Bricka.....	Washer.....			
75	1			1136-0528-01	Spakhållare.....	Lever holder.....			
76	1			1136-0491-01	Inkopplingspak.....	Engagement lever.....			
77	1			1136-0213-01	Fjäder.....	Spring.....			
78	1			9997-0880-16	Skruv.....	Screw.....			
79	1			9747-0831-02	Mutter.....	Lock nut.....			
83	1			9699-0056-02	Planbricka.....	Flat washer.....			
84	1			9712-0831-02	Låsmutter.....	Lock nut.....			
85	1			1136-1075-01	Inkopplingswire.....	Cable.....			
86	1			9699-0056-02	Planbricka.....	Flat washer.....			
87	1			1136-0197-01	Handtag.....	Knob.....			
88	1			1136-0957-01	Fjäder.....	Spring.....			



5
6 - 10



Utgåva Issue		Bildnr Picture No		ESTATE BASIC ESTATE TORNADO ESTATE TORNADO HST KLIPPAGGREGAT		ESTATE BASIC ESTATE TORNADO ESTATE TORNADO HST MOWER DECK		Sida Page
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2546 2547	2572						
1	1	1		1136-1044-01	Klippaggregatskåpa	Mower deck casing		Inkl. pos 2 - 4
2	2	2		1136-0120-01	• Vattenslangnippel	• Water hose connection.....		
3	2	2		1136-0068-01	• O-ring	• O-ring		
4	2	2		1136-0012-01	• Nit	• Rivet		
5	2	2		1136-0481-01	Lagerbox kpl	Bearing box assy		Inkl. pos 6 - 10
6	2	2		1136-0099-01	• Knivaxel	• Blade shaft		
8	4	4		1136-0069-01	• Kullager	• Ball bearing		
9	2	2		1136-0176-01	• Dammskydd	• Dust cover		
10	2	2		9650-0020-04	• Spårning	• Circlip		
11	6	6		9898-0825-16	Skruv	Screw		
12	6	6		9739-0831-22	Mutter	Nut		
13	2	2		1136-0221-01	Knivfäste	Blade hub		
14	2	2		9600-0014-00	Kil	Key		
15	2	2		1136-1029-01	Kniv	Blade		
16	2	2		1136-0083-01	Fjäderbricka	Elastic washer		
17	2	2		1136-0015-01	Bricka	Washer		
18	2	2		9987-5238-12	Knivbult	Blade bolt		
19	2	2		1136-0916-01	Remskiva	Pulley		
20	2	2		1136-0001-01	Kil	Key		
21	2	2		9997-0820-16	Skruv	Screw		
22	2	2		1136-0307-01	Bricka	Washer		
23	2	2		9683-0030-02	Låsbricka	Lock washer		
31	2	2		1136-1052-01	Stödhjul	Anti scalp wheel		
32	2	2		1136-0901-01	Distans	Spacer		
33	2	2		9997-0880-16	Skruv	Screw		
34	2	2		9699-0056-02	Planbricka	Flat washer		
35	2	2		9739-0831-22	Mutter	Nut		
51	2	2		1136-0448-01	Stång	Equalizer rod		
52	4	4		9699-0035-02	Planbricka	Flat washer		
53	4	4		9747-1031-02	Låsmutter	Lock nut		
54	8	8		1136-0308-01	Bricka	Washer		
72	1			1136-1107-01	Deflektor	Deflector		
73	1			1136-0229-01	Sprint	Pin		
74	1			9598-0002-02	Låsnål	Pin lock		
81	1	1		1136-0910-01	Utkastskydd	Discharge protection		
82	1	1		1136-0902-01	Axel	Pivot		
83	1	1		1136-0894-01	Fjäder	Spring		
84	1	1		9599-0070-02	Saxsprint	Split pin		