


# Genuine Spare Parts


---




Joist  
Spareparts  
Joist




Utgåva Issue		Bildnr Picture No		ESTATE MASTER KAROSS		ESTATE MASTER BODY WORK		Sida Page
2003- 11		1227A						26
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2511	2512						
1	1	1		1136-0585-01	Kåpa- främre .....	Cover-front .....		Inkl. pos 29, 30
2	1	1		1136-0415-01	Kåpa- bakre .....	Cover- rear .....		
3	1	1		1136-0571-01	Fotstegskåpa .....	Footboard cover .....		
4	1	1		1136-0382-01	Uppsammlarlock- fast .....	Grass bag cover- fixed .....		
5	1	1		1136-0383-01	Uppsammlarlock- rörligt .....	Grass bag cover- mobil .....		
6	1	1		1136-0381-01	Motorlucka .....	Engine cover .....		
7	1	1		1136-0378-01	Frontlucka .....	Front cover .....		
8	1			1136-0572-01	Hjulåpa .....	Wheel cover .....		
8		1		1136-1069-01	Hjulåpa .....	Wheel cover .....		
9	10	10		9836-9618-12	Skruv .....	Screw .....		
10	8	8		9836-9635-12	Skruv .....	Screw .....		
11	2	2		9699-0060-02	Planbricka .....	Flat washer .....		
12	2	2		9941-0512-16	Skruv .....	Screw .....		
13	2	2		1136-0011-01	Låsplatta .....	Lock plate .....		
15	2	2		9997-0616-16	Skruv .....	Screw .....		
16	4	4		9699-0060-02	Planbricka .....	Flat washer .....		
17	2	2		9747-0631-02	Låsmutter .....	Lock nut .....		
18	2	2		1136-0375-01	Bussning .....	Bushing .....		
19	2	2		1136-0393-01	Fjäder .....	Spring .....		
20	2	2		9997-0845-12	Skruv .....	Screw .....		
21	2	2		1136-0014-01	Bricka .....	Washer .....		
22	2	2		9747-0831-02	Mutter .....	Lock nut .....		
23	2	2		1136-0404-01	Platta .....	Plate .....		
24	4	4		9836-9618-12	Skruv .....	Screw .....		
25	2	2		1136-0405-01	Plåt .....	Plate .....		
26	2	2		9836-9618-12	Skruv .....	Screw .....		
27	4	4		9847-8116-16	Skruv .....	Screw .....		
28	4	4		9699-0035-02	Planbricka .....	Flat washer .....		
29	1	1		1136-0379-01	• Fotstegsskydd- hö .....	• Footboard cover- RH .....		
30	1	1		1136-0380-01	• Fotstegsskydd- vä .....	• Footboard cover- LH .....		
41	1	1		1136-0556-01	Gasreglage .....	Throttle control .....		
42	2	2		9997-0412-16	Skruv .....	Screw .....		
43	2	2		9683-0010-02	Bricka .....	Washer .....		
44	1	1		1136-0192-01	Knopp .....	Handle .....		
45	1	1		9865-0412-16	Skruv .....	Screw .....		
46	1	1		9799-0431-02	Mutter .....	Nut .....		
51	1	1		1136-0315-01	Sits .....	Seat .....		
53	1	1		1136-0252-01	Sitsplatta .....	Seat plate .....		
54	4	4		9997-0820-16	• Skruv .....	• Screw .....		
55	4	4		9683-0030-02	• Låsbricka .....	• Lock washer .....		
56	4	4		9699-0056-02	• Planbricka .....	• Flat washer .....		
57	1	1		1136-1017-01	Axel .....	Pin .....		
58	1	1		1136-0095-01	Låsnål .....	Hair pin .....		
61	1	1		1136-0360-01	Ratt .....	Steering wheel .....		
62	1	1		9595-0272-00	• Stift .....	• Pin .....		
64	1	1		1136-0942-01	Kam .....	Cam .....		
65	2	2		1136-0820-01	Skruv .....	Screw .....		
66	2	2		9699-0018-02	Bricka .....	Washer .....		
67	3	3		9747-0531-02	Mutter .....	Nut .....		
68	1	1		1136-0891-01	Fjäder .....	Spring .....		
69	1	1		9997-0512-16	Skruv .....	Screw .....		
71	1	1		1136-0275-01	Skydd- övre .....	Guard- upper .....		
72	1	1		1136-0276-01	Skydd- nedre .....	Guard- lower .....		
73	2	2		9847-8038-16	Skruv .....	Screw .....		
74	2	2		9699-0024-02	Planbricka .....	Flat washer .....		
75	2	2		1136-0010-01	Låsplatta .....	Lock plate .....		
81	1	1		1136-0419-01	Bränsletank .....	Fuel tank .....		
82	1	1		1136-0344-01	Tanklock .....	Tank cap .....		
83	1	1		1136-0591-01	Tankstöd .....	Tank support .....		
84	6	6		9739-0831-22	Mutter .....	Nut .....		
85	1	1		1136-0368-01	Tankbygel .....	Tank clamp .....		
86	2	2		9747-0631-02	Låsmutter .....	Lock nut .....		
99	1	1		1136-1238-01	Tillbehörspåse .....	Key outfit .....		



Utgåva Issue		Bildnr Picture No		ESTATE MASTER DEKALER		ESTATE MASTER LABELS		Sida Page	
2003-11		1209A						28	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2511	2512							
1	1	1		1136-0035-01	Dekal .....	Label .....			
2	1	1		1136-0037-01	Dekal .....	Label .....			
3	1	1		1136-0032-01	Dekal .....	Label .....			
4	1	1		1136-0036-01	Dekal .....	Label .....			
5	1	1		1136-0038-01	Dekal .....	Label .....			
6	1	1		1136-0034-01	Dekal .....	Label .....			
7	1			1136-0033-01	Dekal .....	Label .....			
8		1		1136-0826-01	Dekal .....	Label .....			
9		1		1136-0030-01	Dekal .....	Label .....			
10	2	2		1136-0021-01	Dekal .....	Label .....			




Utgåva Issue		Bildnr Picture No		ESTATE MASTER CHASSI		ESTATE MASTER CHASSIS		Sida Page
2003-11		1226B						30
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2511	2512						
X	1	1	1	1136-1299-01	Ram.....	Frame.....		Inkl. pos 2, 26, 27
	2	2	2	1136-0121-01	• Bussning.....	• Bushing.....		
	3	1	1	1136-0582-01	Plåt- bak.....	Plate- rear.....		
	4	1	1	1136-0371-01	Pivotstång.....	Pivot.....		
	5	2	2	1136-0251-01	Bygel.....	Clamp.....		
	6	8	8	9997-0616-16	Skruv.....	Screw.....		
	7	8	8	9739-0631-22	Mutter.....	Nut.....		
X	8	1	1	1136-1288-01	Ram- övre.....	Frame- top.....		
	9	4	4	9997-0816-16	Skruv.....	Screw.....		
	10	4	4	9739-0831-22	Mutter.....	Nut.....		
	11	1	1	1136-0592-01	Stöd.....	Support.....		
	12	4	4	9997-0816-16	Skruv.....	Screw.....		
	13	4	4	9739-0831-22	Mutter.....	Nut.....		
	14	1	1	1136-0595-01	Fotstegshållare.....	Footboard holder.....		
	15	2	2	1136-0423-01	Stöd.....	Support.....		
	16	4	4	9997-0816-16	Skruv.....	Screw.....		
	17	4	4	9739-0831-22	Mutter.....	Nut.....		
	18	2	2	9847-8216-16	Skruv.....	Screw.....		
	19	2	2	9699-0035-02	Planbricka.....	Flat washer.....		
	20	1	1	1136-0566-01	Lina.....	Cord.....		
	23	1	1	9699-0056-02	Planbricka.....	Flat washer.....		
	24	1	1	9747-0831-02	Mutter.....	Lock nut.....		
	25	1	1	1136-0013-01	Mutter.....	Nut.....		
X	26	1	1	9501-0500-00	• Smörjnippel.....	• Grease joint.....		
X	27	1	1	1136-1226-01	• Bussning.....	• Bushing.....		
X	33	2	2	1136-1240-01	Fjäder.....	Spring.....		
X	34	2	2	1136-1250-01	Skruv.....	Screw.....		
	35	2	2	9699-0090-02	Planbricka.....	Flat washer.....		
	36	4	4	9739-0831-22	Mutter.....	Nut.....		
	37	2	2	1136-0156-01	Lock.....	Cap.....		
	39	1	1	1136-0395-01	Fjäder.....	Spring.....		
	40	1	1	9848-8013-16	Skruv.....	Screw.....		
	41	1	1	1136-0387-01	Styrning.....	Guide.....		
	42	1	1	9847-8216-16	Skruv.....	Screw.....		
	43	1	1	9699-0060-02	Planbricka.....	Flat washer.....		
	45	1		1136-0388-01	Remstyrning.....	Belt guide.....		
	46	2		9848-8013-16	Skruv.....	Screw.....		
	47	1	1	1136-0421-01	Fäste.....	Clamp.....		
	48	2	2	9847-7809-16	Skruv.....	Screw.....		
X	51	2	2	1136-1254-01	Bussning.....	Bushing.....		
X	52	2	2	1136-1266-01	Fjäder.....	Spring.....		
	53	4	4	1136-0308-01	Bricka.....	Washer.....		
X	54	2	2	1136-1211-01	Låsring.....	Snap ring.....		







Utgåva Issue		Bildnr Picture No		ESTATE MASTER STYRNING		ESTATE MASTER STEERING		Sida Page	
2003-11		1228						32	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2511	2512							
1	1			1136-0403-01	Rattstång .....	Steering column.....			
2	1			1136-0124-01	Bussning .....	Bushing.....			
3	1			9595-0262-00	Spännstift .....	Locating pin .....			
4	1			1136-0408-01	Styrdrev .....	Steering pinion.....			
5	1			9699-0037-02	Bricka .....	Washer.....			
6	1			1136-0008-01	Låsplatta .....	Lock plate .....			
7	1			1136-0588-01	Styrsektor .....	Steering sector.....			
8	1			1136-0557-01	Styraxel .....	Steering shaft.....			
9	2			9652-0015-04	Låsring .....	Retaining ring .....			
10	0-2			9695-0014-00	Bricka .....	Washer.....			
11	1			9997-0820-16	Skruv .....	Screw.....			
12	1			9683-0030-02	Låsbricka .....	Lock washer.....			
16	2			1136-0424-01	Styrstag .....	Tie rod.....			
17	4			1136-0092-01	Kulled .....	Ball joint.....			
19	4			9747-1031-02	Låsmutter .....	Lock nut.....			
20	1			1136-0564-01	Framaxel kpl .....	Front wheel axle assy.....		Inkl. pos 21, 22	
21	4			1136-0121-01	• Bussning.....	• Bushing.....			
22	2			9501-0500-00	• Smörjnippel .....	• Grease joint.....			
23	1			1136-0575-01	Hjulspindel- hö.....	Stub axle- RH.....			
24	1			1136-0576-01	Hjulspindel- vä.....	Stub axle- LH.....			
25	2			9652-0015-04	Låsring .....	Retaining ring .....			
26	1			1136-0165-01	Distans .....	Spacer.....			
27	1			9997-1260-02	Skruv .....	Screw.....			
28	2			1136-0016-01	Bricka .....	Washer.....			
29	1			9683-0055-02	Låsbricka .....	Lock washer.....			
30	1			9799-1231-02	Mutter.....	Nut.....			
31	1			9699-0090-02	Planbricka.....	Flat washer.....			
52	2			1136-0567-01	Fälg.....	Rim.....			
53	4			1136-0157-01	Lager .....	Bearing.....			
54	2			1136-0409-01	Däck (Turf Saver).....	Tire (Turf Saver).....			
54	2			1136-0411-01	Däck (Deli).....	Tire (Deli).....			
55	2			1136-0305-01	Bricka .....	Washer.....			
56	2			9652-0015-04	Låsring .....	Retaining ring .....			
57	2			1136-0081-01	Navkapsel .....	Hub cap.....			
58	2			1136-0359-01	Ventil .....	Valve.....			





Utgåva Issue 2003-11		Bildnr Picture No 1229A		ESTATE MASTER BROMSREGLAGE VÅXELREGLAGE		ESTATE MASTER BRAKE CONTROL GEAR SHIFTER CONTROL		Sida Page 34	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2511								
1	1				1136-0581-01	Bromspedal .....	Brake pedal .....		
2	1				1136-0152-01	Pedalskydd .....	Pedal cover .....		
3	1				1136-0562-01	Pedalaxel .....	Pedal shaft .....		
4	2				9997-0825-16	Skruv .....	Screw .....		
5	2				9747-0831-02	Mutter .....	Lock nut .....		
6	2				1136-0406-01	Bygel .....	Clamp .....		
7	4				9847-8119-16	Skruv .....	Screw .....		
8	1				1136-0561-01	P- bromsaxel .....	Parking brake shaft .....		
9	2				1136-0256-01	Bygel .....	Plate .....		
10	4				9847-8016-16	Skruv .....	Screw .....		
11	1				1136-0394-01	Fjäder .....	Spring .....		
12	1				1136-0392-01	Knopp .....	Knob .....		
13	1				1136-0369-01	Bromsstång .....	Brake rod .....		
14	1				9799-0831-02	Mutter .....	Nut .....		
15	1				1136-0402-01	Ledbult .....	Pivot bolt .....		
16	1				1136-0218-01	Fjäder .....	Spring .....		
17	2				9699-0090-02	Planbricka .....	Flat washer .....		
18	1				1136-0084-01	Distans .....	Spacer .....		
19	1				1136-0329-01	Bygel .....	Clamp .....		
20	1				9699-0085-02	Planbricka .....	Flat washer .....		
21	1				9747-0631-02	Låsmutter .....	Lock nut .....		
22	1				1136-0095-01	Låsnål .....	Hair pin .....		
23	1				1136-0209-01	Fjäder .....	Spring .....		
24	1				1136-0094-01	Skruv .....	Screw .....		
25	2				9799-0831-02	Mutter .....	Nut .....		
26	1				9747-0831-02	Mutter .....	Lock nut .....		
31	1				1136-0589-01	Fäste .....	Support .....		
32	1				9997-0820-16	Skruv .....	Screw .....		
33	1				9739-0831-22	Mutter .....	Nut .....		
34	2				1136-0374-01	Bussning .....	Bushing .....		
35	2				9699-0037-02	Bricka .....	Washer .....		
36	1				9650-0012-04	Seegersäkring .....	Circlip .....		
37	1				1136-0577-01	Växelspak .....	Gearshift lever .....		
38	1				1136-0590-01	Bygel .....	Clamp .....		
39	1				1136-0212-01	Fjäder .....	Spring .....		
40	1				9997-0880-16	Skruv .....	Screw .....		
41	1				9747-0831-02	Mutter .....	Lock nut .....		
42	1				1136-0503-01	Knopp .....	Knob .....		
43	1				1136-0366-01	Växlestång .....	Shifter rod .....		
44	1				1136-0093-01	Kulled .....	Ball joint .....		
45	1				1136-0390-01	Växelarm .....	Gearshift arm .....		
46	1				1136-0235-01	Ledbult .....	Pivot bolt .....		
47	2				1136-0309-01	Bricka .....	Washer .....		
48	1				9747-0831-02	Mutter .....	Lock nut .....		
49	1				1136-0095-01	Låsnål .....	Hair pin .....		
50	1				9683-0030-02	Låsbricka .....	Lock washer .....		
51	1				9799-0831-02	Mutter .....	Nut .....		
52	1				9987-5016-16	Skruv .....	Screw .....		
53	1				9678-0008-02	Låsbricka .....	Lock washer .....		
54	1				1136-0091-01	Bricka .....	Washer .....		



Utgåva Issue		Bildnr Picture No		ESTATE MASTER HST BROMSREGLAGE DRIVREGLAGE		ESTATE MASTER HST BRAKE CONTROL DRIVE CONTROL		Sida Page	
2003-11		1445A						36	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2512								
1	1			1136-0581-01	Bromspedal .....	Brake pedal .....			
2	1			1136-0151-01	Pedalskydd .....	Pedal cover .....			
3	1			1136-0562-01	Pedalaxel .....	Pedal shaft .....			
4	2			9997-0825-16	Skruv .....	Screw .....			
5	2			9747-0831-02	Mutter .....	Lock nut .....			
6	2			1136-0406-01	Bygel .....	Clamp .....			
7	4			9847-8119-16	Skruv .....	Screw .....			
8	1			1136-0561-01	P-bromsaxel .....	Parking brake shaft .....			
9	2			1136-0256-01	Bygel .....	Plate .....			
10	4			9847-8016-16	Skruv .....	Screw .....			
11	1			1136-0394-01	Fjäder .....	Spring .....			
12	1			1136-0392-01	Knopp .....	Knob .....			
13	1			1136-0930-01	Stång .....	Rod .....			
14	1			9799-0831-02	Mutter .....	Nut .....			
15	1			1136-0402-01	Ledbult .....	Pivot bolt .....			
16	1			1136-0218-01	Fjäder .....	Spring .....			
17	2			9699-0090-02	Planbricka .....	Flat washer .....			
18	1			1136-0084-01	Distans .....	Spacer .....			
19	1			1136-0329-01	Bygel .....	Clamp .....			
20	1			9699-0085-02	Planbricka .....	Flat washer .....			
21	1			9747-0631-02	Låsmutter .....	Lock nut .....			
22	1			1136-0095-01	Låsnål .....	Hair pin .....			
23	1			1136-0204-01	Fjäder .....	Spring .....			
24	1			1136-0094-01	Skruv .....	Screw .....			
25	2			9799-0831-02	Mutter .....	Nut .....			
26	1			1136-0386-01	Gummiplugg .....	Grommet .....			
27	1			9747-0831-02	Mutter .....	Lock nut .....			
32	1			1136-1099-01	Fäste m.lager .....	Bracket w.bush .....		Inkl. pos 33	
33	2			1136-0937-01	• Bussning .....	• Bush .....			
34	1			1136-1096-01	Arm .....	Lever .....			
35	2			1136-0088-01	Bricka .....	Washer .....			
36	1			1136-1000-01	Bygel .....	Clamp .....			
37	1			1136-1001-01	Bygel .....	Clamp .....			
38	1			1136-0089-01	Bricka .....	Washer .....			
39	1			9699-0056-02	Planbricka .....	Flat washer .....			
40	1			9712-0831-02	Låsmutter .....	Lock nut .....			
41	1			1136-0996-01	Sektor .....	Sector .....			
42	1			1136-0824-01	Skruv .....	Screw .....			
43	1			1136-0806-01	Mutter .....	Nut .....			
44	2			1136-0950-01	Platta .....	Plate .....			
45	2			1136-0992-01	Bricka .....	Washer .....			
46	1			1136-1098-01	Bygel .....	Clamp .....			
47	2			1136-0941-01	Kam .....	Cam .....			
48	2			9848-8013-16	Skruv .....	Screw .....			
49	1			1136-1097-01	Arm .....	Lever .....			
50	1			1136-0958-01	Fjäder .....	Spring .....			
51	1			1136-0308-01	Bricka .....	Washer .....			
52	1			1136-0806-01	Mutter .....	Nut .....			
53	1			9501-0500-00	Smörjnippl .....	Grease joint .....			
54	1			9699-0035-02	Planbricka .....	Flat washer .....			
55	1			1136-0577-01	Växelspak .....	Gearshift lever .....			
56	1			1136-0212-01	Fjäder .....	Spring .....			
57	1			9997-0880-16	Skruv .....	Screw .....			
58	1			9747-0831-02	Mutter .....	Lock nut .....			
59	1			1136-0503-01	Knopp .....	Knob .....			
60	1			9997-0825-16	Skruv .....	Screw .....			
61	1			9739-0831-22	Mutter .....	Nut .....			
71	1			1136-0931-01	Stång .....	Rod .....			
72	1			1136-0235-01	Ledbult .....	Pivot bolt .....			
73	1			9799-0831-02	Mutter .....	Nut .....			
74	2			1136-0309-01	Bricka .....	Washer .....			
75	1			9712-0831-02	Låsmutter .....	Lock nut .....			
77	1			1136-0095-01	Låsnål .....	Hair pin .....			




Utgåva Issue 2003-11		Bildnr Picture No 1445A		ESTATE MASTER HST BROMSREGLAGE DRIVREGLAGE		ESTATE MASTER HST BRAKE CONTROL DRIVE CONTROL		Sida Page 38	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2512								
80	1				1136-1072-01	Wire.....	Wire.....		
81	1				1136-1002-01	Bygel.....	Clamp.....		
82	2				9997-0620-16	Skruv.....	Screw.....		
83	2				9699-0035-02	Planbricka.....	Flat washer.....		
84	2				9739-0631-22	Mutter.....	Nut.....		
85	1				1136-0929-01	Stång.....	Rod.....		
86	1				1136-0235-01	Ledbult.....	Pivot bolt.....		
87	2				9799-0831-02	Mutter.....	Nut.....		
88	2				1136-0309-01	Bricka.....	Washer.....		
89	1				9712-0831-02	Låsmutter.....	Lock nut.....		
91	1				1136-0095-01	Låsnål.....	Hair pin.....		
92	1				9747-0831-02	Mutter.....	Lock nut.....		







Utgåva Issue		Bildnr Picture No		ESTATE MASTER ELUTRUSTNING		ESTATE MASTER EL. EQUIPMENT		Sida Page	
2003- 11		1236A						40	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2511	2512							
X	1	1		1136-1293-01	Kabelhärva.....	Harness.....		Inkl. pos 5	
	2	1		1136-0314-01	Elektronikkort.....	Electronic card.....			
	3	2		9847-7813-16	Skruv.....	Screw.....			
	4	1		1136-0428-01	• Säkring.....	• Fuse.....		6.3 A	
	5	1		1136-0056-01	• Tändningslås.....	• Ignition switch.....		Inkl. pos 6 - 8	
	6	1		1136-0049-01	•• Mutter.....	•• Nut.....			
	7	1		1134-4097-01	•• Täckåpa.....	•• Cap.....			
	8	1		1134-2848-01	•• Tändningsnyckel.....	•• Ignition key.....			
	9	1		1136-0064-01	Startrelä.....	Solenoid.....			
	10	2		9848-8013-16	Skruv.....	Screw.....			
	11	2		9794-5131-02	Mutter.....	Nut.....			
	12	1		786201	Brytare.....	Neutral start switch.....		Växellåda/gearbox	
	13	4		1136-0073-01	Mikrobrytare.....	Micro switch.....			
	14	1		1136-0072-01	Mikrobrytare.....	Micro switch.....		Full upps./grass bag	
	17	1		1136-0135-01	Kabel.....	Cable.....			
	18	1		1136-0376-01	Kabel.....	Cable.....			
	19	1		1134-4804-01	Batteri.....	Battery.....			
	20	1		1136-0422-01	Batterihållare.....	Battery holder.....			
	21	1		9747-0831-02	Mutter.....	Lock nut.....			
	22	1		1136-0059-01	Polskydd.....	Protection.....			
	23	1		9795-3531-02	Mutter.....	Nut.....			
	24	3		1136-0427-01	Kabelhållare.....	Cable holder.....			
	25	1		1136-0426-01	Kabelhållare.....	Cable holder.....			
X	99	1		1136-1238-01	Tillbehörspåse.....	Key outfit.....		Inkl. pos 4, 8	




Utgåva Issue		Bildnr Picture No		ESTATE MASTER MOTOR		ESTATE MASTER ENGINE		Sida Page	
2003- 11		1230						42	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2511	2512							
2	3			9997- 0830- 16	Skruv .....	Screw .....			
3	1			9997- 0835- 12	Skruv .....	Screw .....			
4	3			9739- 0831- 22	Mutter .....	Nut .....			
5	1			9799- 0831- 02	Mutter .....	Nut .....			
6	2			9677- 0009- 02	Låsbricka .....	Lock washer .....			
7	1			1136- 0586- 01	Avgasrör .....	Exhaust tube .....			
8	1			1136- 0518- 01	Ljuddämparskydd .....	Muffler protection .....			
9	1			9988- 3513- 16	Skruv .....	Screw .....			
10	1			9677- 0009- 02	Låsbricka .....	Lock washer .....			
11	1			9847- 8113- 16	Skruv .....	Screw .....			
12	1			1136- 0413- 01	Oljeavtappningsrör .....	Oil drain pipe .....			
13	1			1136- 0066- 01	Oljeavtappningsplugg .....	Oil drain plug .....			
14	2			1136- 0054- 01	Tätningring .....	Oil seal .....			
15	1			1136- 0352- 01	Bränsleslang .....	Fuel hose .....			
17	1			1136- 0046- 01	Slangklämma .....	Hose clamp .....			
18	3			1136- 0045- 01	Slangklämma .....	Hose clamp .....			
19	1			1136- 0414- 01	Utblåsskydd .....	Exhaust protection .....			
20	2			9848- 8013- 16	Skruv .....	Screw .....			
21	1			1136- 0397- 01	Fjäder .....	Spring .....			



Utgåva Issue 2003-11		Bildnr Picture No 1231		ESTATE MASTER TRANSMISSION		ESTATE MASTER TRANSMISSION		Sida Page 44	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2511								
1	1			1136-0418-01	Motorremskiva .....	Engine belt pulley .....			
2	1			9987-5351-12	Skruv .....	Screw .....			
3	1			9683-0045-02	Bricka .....	Washer .....			
5	1			1136-0430-01	Kilrem .....	V-belt .....			
6	1			1136-0578-01	Spännarm .....	Tension arm .....			
7	1			1136-0400-01	Pinnbult .....	Stud bolt .....			
8	1			9677-0009-02	Låsbricka .....	Lock washer .....			
9	1			1136-0088-01	Bricka .....	Washer .....			
10	1			1136-0309-01	Bricka .....	Washer .....			
11	1			9712-0831-02	Låsmutter .....	Lock nut .....			
12	1			1136-0289-01	Spännrulle .....	Idler pulley .....			
13	1			9699-0056-02	Planbricka .....	Flat washer .....			
14	1			9747-0831-02	Mutter .....	Lock nut .....			
15	1			1136-0367-01	Spännstång .....	Tie rod .....			
16	1			1136-0235-01	Ledbult .....	Pivot bolt .....			
17	2			9799-0831-02	Mutter .....	Nut .....			
18	1			9747-0831-02	Mutter .....	Lock nut .....			
19	2			1136-0309-01	Bricka .....	Washer .....			
20	1			9747-0831-02	Mutter .....	Lock nut .....			
21	1			1136-0520-01	Remskiva .....	Belt pulley .....			
22	1			9600-0050-00	Woodruffkil .....	Key .....			
23	1			9650-0016-04	Spärring .....	Lock ring .....			
24	1			1136-0051-01	Transaxel .....	Transaxle .....		Peerless MST 205-541	
25	4			9997-0860-16	Skruv .....	Screw .....			
27	4			9739-0831-22	Mutter .....	Nut .....			
28	2			1136-0420-01	Momentstag .....	Stay .....			
29	2			1136-0017-01	Skruv .....	Screw .....			
30	1			9997-0820-16	Skruv .....	Screw .....			
31	1			9997-0825-16	Skruv .....	Screw .....			
32	1			9699-0056-02	Planbricka .....	Flat washer .....			
33	1			9739-0831-22	Mutter .....	Nut .....			
34	1			9699-0090-02	Planbricka .....	Flat washer .....			
35	1			9747-0831-02	Mutter .....	Lock nut .....			
52	2			1136-0568-01	Fälg .....	Rim .....			
53	2			1136-0410-01	Däck (Turf Saver) .....	Tire (Turf Saver) .....			
53	2			1136-0412-01	Däck (Deli) .....	Tire (Deli) .....			
54	2			9699-0119-02	Bricka .....	Washer .....			
55	2			1136-0305-01	Bricka .....	Washer .....			
56	2			9652-0015-04	Låsring .....	Retaining ring .....			
57	2-4			9695-0015-00	Bricka .....	Washer .....			
58	2			1136-0081-01	Navkapsel .....	Hub cap .....			
59	2			9545-0500-00	Ventil .....	Valve .....			




Utgåva Issue		Bildnr Picture No		ESTATE MASTER HST TRANSMISSION		ESTATE MASTER HST TRANSMISSION		Sida Page	
2003-11		1446A						46	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2512								
	1	1			1136-0418-01	Motorremskiva .....	Engine belt pulley .....		
	2	1			9987-5351-12	Skruv .....	Screw .....		
	3	1			9683-0045-02	Bricka .....	Washer .....		
	5	1			1136-1020-01	Drivrem .....	Drive belt .....		
	6	1			1136-1079-01	Spännarm .....	Tension lever .....		
	7	1			1136-0400-01	Pinnbult .....	Stud bolt .....		
	8	1			9677-0009-02	Låsbricka .....	Lock washer .....		
	9	1			1136-0088-01	Bricka .....	Washer .....		
	10	1			1136-0309-01	Bricka .....	Washer .....		
	11	1			9712-0831-02	Låsmutter .....	Lock nut .....		
	12	1			1136-0289-01	Spännrulle .....	Idler pulley .....		
	13	1			9699-0056-02	Planbricka .....	Flat washer .....		
	14	1			9747-0831-02	Mutter .....	Lock nut .....		
	15	1			1136-0860-01	Fjäder .....	Spring .....		
X	21	1			1136-1222-01	Transmission .....	Transmission .....		Peerless LTH 2000
	22	4			9997-0860-16	Skruv .....	Screw .....		
	24	4			9739-0831-22	Mutter .....	Nut .....		
	25	1			1136-1003-01	Bygel .....	Clamp .....		
	26	1			1136-0017-01	Skruv .....	Screw .....		
	27	1			9997-0825-16	Skruv .....	Screw .....		
	28	1			9699-0090-02	Planbricka .....	Flat washer .....		
	29	1			9747-0831-02	Mutter .....	Lock nut .....		
X	30	1			1136-1260-01	Arm .....	Lever .....		
	31	1			9699-0037-02	Bricka .....	Washer .....		
	32	1			9699-0085-02	Planbricka .....	Flat washer .....		
	33	1			9987-5016-16	Skruv .....	Screw .....		
	34	1			9683-0025-02	Låsbricka .....	Lock washer .....		
X	39	1			1136-1294-01	Urkopplingsreglage .....	Disengage control .....		
	40	1			1136-0858-01	Handtag .....	Handle .....		
	41	1			9865-0412-16	Skruv .....	Screw .....		
	42	1			9799-0431-02	Mutter .....	Nut .....		
	43	2			1136-0876-01	Distans .....	Spacer .....		
	44	2			1136-0812-01	Skruv .....	Screw .....		
	45	2			9747-0631-02	Låsmutter .....	Lock nut .....		
X	46	1			1136-1270-01	Wireklämna .....	Wire clamp .....		
	47	1			1136-0820-01	Skruv .....	Screw .....		
	48	1			9699-0018-02	Bricka .....	Washer .....		
	49	1			1136-0604-01	Mutter .....	Nut .....		
X	50	1			1136-1223-01	Distans .....	Spacer .....		
	51	1			9699-0018-02	Bricka .....	Washer .....		
	52	1			9747-0531-02	Mutter .....	Nut .....		
	62	2			1136-0568-01	Fälg .....	Rim .....		
	63	2			1136-0410-01	Däck (Turf Saver) .....	Tire (Turf Saver) .....		
	63	2			1136-0412-01	Däck (Deli) .....	Tire (Deli) .....		
	64	2			9699-0119-02	Bricka .....	Washer .....		
	65	2			1136-0305-01	Bricka .....	Washer .....		
	66	2			9652-0015-04	Låsring .....	Retaining ring .....		
	67	0-4			9695-0015-00	Bricka .....	Washer .....		
	68	2			1136-0081-01	Navkapsel .....	Hub cap .....		
	69	2			9545-0500-00	Ventil .....	Valve .....		







Utgåva Issue		Bildnr Picture No		ESTATE MASTER AGGREGATSLYFT		ESTATE MASTER MOWER DECK LIFT		Sida Page	
2003- 11		1232A						48	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2511	2512							
X 1	1			1136-1291-01	Lyftaxel .....	Lift axle .....			
2	2			1136-0406-01	Bygel .....	Clamp .....			
3	4			9847-8119-16	Skruv .....	Screw .....			
4	1			1136-0095-01	Låsnål .....	Hair pin .....			
5	1			1136-0308-01	Bricka .....	Washer .....			
6	1			9747-1031-02	Låsmutter .....	Lock nut .....			
7	2			1136-0308-01	Bricka .....	Washer .....			
8	1			1136-0559-01	Lyftaxel .....	Lift axle .....			
9	2			1136-0406-01	Bygel .....	Clamp .....			
10	4			9847-8119-16	Skruv .....	Screw .....			
11	1			1136-0226-01	Ledbult .....	Pivot bolt .....			
12	2			1136-0308-01	Bricka .....	Washer .....			
13	1			9747-1031-02	Låsmutter .....	Lock nut .....			
14	1			1136-0347-01	Lyftlänk .....	Lift tie rod .....			
15	1			9799-1031-02	Mutter .....	Nut .....			
16	1			9747-1031-02	Låsmutter .....	Lock nut .....			
17	2			1136-0308-01	Bricka .....	Washer .....			
18	1			1136-0095-01	Låsnål .....	Hair pin .....			
19	1			1136-0563-01	Lyftstång .....	Lift rod .....			
20	1			1136-0235-01	Ledbult .....	Pivot bolt .....			
21	1			9799-0831-02	Mutter .....	Nut .....			
22	1			9747-0831-02	Mutter .....	Lock nut .....			
23	1			1136-0009-01	Låsplatta .....	Lock plate .....			
24	1			1136-0309-01	Bricka .....	Washer .....			
25	2			1136-0309-01	Bricka .....	Washer .....			
26	1			9747-0831-02	Mutter .....	Lock nut .....			
27	1			1136-0579-01	Lyftspak .....	Lift lever .....			
28	1			1136-0197-01	Handtag .....	Knob .....			
29	1			9997-0635-12	Skruv .....	Screw .....			
30	1			9747-0631-02	Låsmutter .....	Lock nut .....			
31	1			1136-0396-01	Fjäder .....	Spring .....			
X 32	1			1136-1268-01	Sprint .....	Pin .....			



Utgåva Issue		Bildnr Picture No		ESTATE MASTER AGGREGATSINKOPPLING		ESTATE MASTER MOWER DECK ENGAGEMENT		Sida Page	
2003-11		1233B						50	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2511	2512							
	1	1		1136-0580-01	Inkopplingsspak .....	PTO lever .....			
	2	1		1136-0197-01	Handtag .....	Knob .....			
	3	1		1136-0560-01	Axel .....	Axle .....			
	4	1		1136-0212-01	Fjäder .....	Spring .....			
	5	1		9997-0880-16	Skruv .....	Screw .....			
	6	1		9747-0831-02	Mutter .....	Lock nut .....			
	7	2		1136-0256-01	Bygel .....	Plate .....			
	8	4		9847-8016-16	Skruv .....	Screw .....			
	9	1		1136-0964-01	Fjäder .....	Spring .....			
	10	1		1136-0398-01	Glidblock .....	Shoe .....			
	11	2		9997-0616-16	Skruv .....	Screw .....			
	12	2		9747-0631-02	Låsmutter .....	Lock nut .....			
X	13	1		1136-1252-01	Stång .....	Rod .....			
	14	1		1136-0093-01	Kulled .....	Ball joint .....			
X	15	1		1136-1275-01	Bygel .....	Clamp .....			
X	16	1		1136-1265-01	Fjäder .....	Spring .....			
	17	1		9699-0090-02	Planbricka .....	Flat washer .....			
X	18	1		1136-1267-01	Ledbult .....	Pivot pin .....			
	19	1		9799-0831-02	Mutter .....	Nut .....			
	20	1		9747-0831-02	Mutter .....	Lock nut .....			
	21	1		9683-0030-02	Låsbricka .....	Lock washer .....			
	22	1		9799-0831-02	Mutter .....	Nut .....			
	23	1		1136-0308-01	Bricka .....	Washer .....			
	24	1		1136-0095-01	Låsnål .....	Hair pin .....			
	25	1		1136-0306-01	Bricka .....	Washer .....			
X	31	1		1136-1253-01	Arm .....	Lever .....			
	32	1		1136-0373-01	Bussning .....	Bushing .....			
	33	1		9997-0845-12	Skruv .....	Screw .....			
	34	1		9699-0056-02	Planbricka .....	Flat washer .....			
	35	1		1136-0089-01	Bricka .....	Washer .....			
	36	1		1136-0014-01	Bricka .....	Washer .....			
	37	1		9747-0831-02	Mutter .....	Lock nut .....			
X	38	1		1136-1271-01	Spännrulle .....	Idler pulley .....			
X	39	1		1136-1213-01	Skruv .....	Screw .....			
	40	1		9699-0056-02	Planbricka .....	Flat washer .....			
	41	1		9739-0831-22	Mutter .....	Nut .....			
	42	1		1136-0431-01	Kilrem .....	V-belt .....			
	61	1		1136-0574-01	Knivbroms .....	Blade brake .....			
	62	1		1136-0079-01	Bussning .....	Bushing .....			
	63	1		1136-0089-01	Bricka .....	Washer .....			
	64	1		9997-0820-16	Skruv .....	Screw .....			
	65	1		9712-0831-02	Låsmutter .....	Lock nut .....			
X	66	1		1136-1251-01	Stång .....	Rod .....			
	67	1		1136-0235-01	Ledbult .....	Pivot bolt .....			
	68	1		9799-0831-02	Mutter .....	Nut .....			
	69	1		9747-0831-02	Mutter .....	Lock nut .....			
	70	2		1136-0309-01	Bricka .....	Washer .....			
	71	1		9747-0831-02	Mutter .....	Lock nut .....			
	72	1		1136-0095-01	Låsnål .....	Hair pin .....			




Utgåva Issue		Bildnr Picture No		ESTATE MASTER KLIPPAGGREGAT		ESTATE MASTER MOWER DECK		Sida Page	
2003-11		1234A						52	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2511	2512							
X	1	1			1136-1261-01	Klippaggregatskåpa .....	Mower deck casing .....		Inkl. pos 2 - 4
	2	1			1136-0120-01	• Vattenslangnippel .....	• Water hose connection.....		
	3	1			1136-0068-01	• O-ring.....	• O-ring .....		
	4	1			1136-0012-01	• Nit.....	• Rivet.....		
	5	1			1136-0372-01	Utkasträtt.....	Conveyor inlet .....		
	6	6			9898-0620-16	Skruv .....	Screw .....		
	7	6			9699-0060-02	Planbricka .....	Flat washer .....		
	8	6			9747-0631-02	Låsmutter .....	Lock nut .....		
	9	1			1136-0573-01	Lagerbox kpl.....	Bearing box assy.....		Inkl. pos 10 - 14
	10	1			1136-0364-01	• Knivaxel .....	• Blade shaft .....		
	12	2			1136-0069-01	• Kullager .....	• Ball bearing .....		
	13	1			1136-0176-01	• Dammskydd .....	• Dust cover .....		
	14	1			9650-0020-04	• Spårning.....	• Circlip .....		
	15	4			9898-0825-16	Skruv .....	Screw .....		
	17	4			9739-0831-22	Mutter .....	Nut .....		
	18	1			1136-0221-01	Knivfäste.....	Blade hub .....		
	19	1			9600-0014-00	Kil .....	Key .....		
X	20	1			1136-1295-01	Kniv .....	Blade .....		
	21	1			1136-0083-01	Fjäderbricka .....	Elastic washer .....		
	22	1			1136-0015-01	Bricka .....	Washer .....		
	23	1			9987-5238-12	Knivbult .....	Blade bolt .....		
X	24	1			1136-1272-01	Remskiva.....	Belt pulley .....		
	25	1			1136-0001-01	Kil .....	Key .....		
	26	1			9997-0820-16	Skruv .....	Screw .....		
	27	1			1136-0307-01	Bricka .....	Washer .....		
	28	1			9683-0030-02	Låsbricka .....	Lock washer .....		
	29	1			1136-0399-01	Luftintag .....	Air intake grill.....		
	30	4			9898-0616-16	Skruv .....	Screw .....		
	31	4			9699-0028-02	Planbricka .....	Flat washer .....		
	32	4			9747-0631-02	Låsmutter .....	Lock nut .....		
	33	1			9997-1090-12	Skruv .....	Screw .....		
	34	2			1136-0015-01	Bricka .....	Washer .....		
	35	1			1136-0002-01	Mutter.....	Nut .....		
	36	1			1136-0226-01	Ledbult .....	Pivot bolt.....		
	37	1			9799-1031-02	Mutter.....	Nut .....		
	38	1			9747-1031-02	Låsmutter .....	Lock nut .....		
	39	1			9683-0040-02	Låsbricka .....	Lock washer .....		
	51	1			1136-0377-01	Utkaströr .....	Conveyor .....		
	52	1			1136-0384-01	Deflektor .....	Deflector .....		
	53	8			9836-9618-12	Skruv .....	Screw .....		
	54	1			1136-0401-01	Axel .....	Pin .....		
	55	2			1136-0095-01	Låsnål .....	Hair pin .....		



Utgåva Issue 2003-11		Bildnr Picture No 1235A		ESTATE MASTER UPPSAMLARE		ESTATE MASTER GRASS CATCHER		Sida Page 54
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2511 2512							
1	1			1136-0593-01	Ram- nedre .....	Frame- lower .....		
2	1			1136-0594-01	Ram- övre .....	Frame- upper .....		
3	1			1136-0569-01	Uppsamlings säck .....	Grass bag .....		
4	1			1136-0362-01	Vinkelstöd- hö .....	Angle support- RH .....		
5	1			1136-0363-01	Vinkelstöd- vä .....	Angle support- LH .....		
6	1			1136-0264-01	Stag .....	Rod .....		
7	1			1136-0587-01	Förstärkningsstag .....	Reinforcement rod .....		
8	4			9847-8116-16	• Skruv .....	• Screw .....		
9	4			9997-0630-12	• Skruv .....	• Screw .....		
10	4			9683-0010-02	• Bricka .....	• Washer .....		
11	4			9799-0631-02	• Mutter .....	• Nut .....		
12	2			9997-0635-12	• Skruv .....	• Screw .....		
13	2			9699-0035-02	• Planbricka .....	• Flat washer .....		
14	2			9747-0631-02	• Låsmutter .....	• Lock nut .....		
15	1			9997-0612-16	• Skruv .....	• Screw .....		
16	1			9678-0008-02	• Låsbricka .....	• Lock washer .....		
17	1			9739-0631-22	• Mutter .....	• Nut .....		
18	1			1136-1216-01	Skruvsats .....	Screw set .....		Inkl. pos 8 - 17
31	1			1136-0280-01	Brytarskydd .....	Micro protection .....		
32	1			1136-0281-01	Skyddslock .....	Protection cover .....		
33	1			1136-0186-01	Brytarm .....	Switch lever .....		
34	1			1136-0007-01	Axel .....	Pin .....		
35	3			9847-8013-16	Skruv .....	Screw .....		
36	1			1136-0282-01	Brytarskydd .....	Micro protection .....		
37	1			1136-0283-01	Skyddslock .....	Protection cover .....		
38	4			9847-8013-16	Skruv .....	Screw .....		


X






Utgåva Issue		Bildnr Picture No		MULCHINGSATS ART.NR 13- 0934- 11		MULCHING KIT ART.NO 13- 0934- 11		Sida Page	
2003- 11		1558						152	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	0934								
X	42	1			1136- 1259- 01	Deflektor- bakre .....	Deflector- rear .....		
X	43	1			1136- 1258- 01	Deflektor- fram.....	Deflector- front.....		
X	44	1			9898- 0825- 16	Skruv.....	Screw.....		
X	45	1			1136- 1255- 01	Bussning .....	Bushing.....		
X	46	1			1136- 0089- 01	Bricka .....	Washer.....		
X	47	1			9747- 0831- 02	Mutter.....	Lock nut.....		
X	48	1			1136- 1263- 01	Handtagsrör.....	Handle tube.....		
X	49	2			1136- 1269- 01	Sprint.....	Pin .....		
X	50	1			1136- 0214- 01	Fjäder.....	Spring .....		
X	51	1			1136- 0882- 01	Handtag .....	Handgrip .....		
X	52	1			1136- 0927- 01	Elastiskt band .....	Elastic tie.....		
X	53	3			1136- 0877- 01	Krok.....	Hook .....		


Estate Master



Estate Senator - President - Royal - Pro 20




Utgåva Issue 2003-11		Bildnr Picture No 1253A		FRONTVIKT ART.NR 13-0912-11		FRONT WEIGHT ART.NO 13-0912-11		Sida Page 142	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	0912								
23	3				9939-0850-12 Skruv .....	Screw .....			
24	3				9747-0831-02 Mutter .....	Lock nut .....			




Utgåva Issue		Bildnr Picture No		DEFLEKTOR ART.NR 13- 0916- 11		DEFLECTOR ART.NR 13- 0916- 11		Sida Page	
2003- 11		1248						144	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	0916								
2	1			1136- 0584- 01	Utkastskydd .....	Ejection guard .....			
3	1			1136- 0425- 01	Stödrör .....	Support .....			
4	2			1136- 0062- 01	Plugg .....	Cap .....			
5	2			9997- 0635- 12	Skruv .....	Screw .....			
6	2			9747- 0631- 02	Låsmutter .....	Lock nut .....			
7	1			1136- 0257- 01	Bygel .....	Plate .....			
8	1			9997- 0625- 16	Skruv .....	Screw .....			
9	1			9747- 0631- 02	Låsmutter .....	Lock nut .....			
10	2			1136- 0256- 01	Bygel .....	Plate .....			
11	4			9997- 0516- 16	Skruv .....	Screw .....			
12	4			9699- 0018- 02	Bricka .....	Washer .....			
13	4			9747- 0531- 02	Mutter .....	Nut .....			
14	2			1136- 0229- 01	Sprint .....	Pin .....			
15	2			9598- 0002- 02	Låsnål .....	Pin lock .....			

A




Utgåva Issue		Bildnr Picture No		BRIGGS & STRATTON 286707, 28M707 CYLINDER (A) VEVHUS (A)		BRIGGS & STRATTON 286707, 28M707 CYLINDER (A) CRANKCASE (A)		Sida Page	
2003- 11		1182A						206	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	286 707- 1185	28M 707- 1194							
A01	3	3		691655	Skruv .....	Screw .....			
A02		1		690492	Skyddsnet .....	Rotating screen .....			
A02	1			691748	Skyddsnet .....	Rotating screen .....			
A03	2	2		691058	Skruv .....	Screw .....			
A04	1			690452	Fläkthållare .....	Fan retainer .....			
A05	1			691905	Fläkt .....	Flywheel fan .....			
A05		1		695056	Fläkt .....	Flywheel fan .....			
A06	1	1		691323	Distans .....	Spacer .....			
A07	1	1		690582	Bricka .....	Washer .....			
A08	1	1		691173	Svänghjuls kopp .....	Flywheel cup .....			
A09	1	1		19203	Avdragare .....	Puller .....			
A10	1	1		693556	Svänghjul .....	Flywheel .....			
A11	1	1		691265	• Låsring .....	• Retaining ring .....			
A12	1	1		693713	• Drev .....	• Pinion gear .....			
A13	1	1		496413	Cylinder .....	Cylinder .....			
A14	1	1		399265	• Bussning .....	• Bushing .....			
A15	1	1		391086	• • Tätningsring .....	• • Seal .....			
A16	1	1		691003	• Skruv .....	• Screw .....			
A17	1	1		690459	Cylinderskydd .....	Cylinder shield .....			
A18	1	1		231218	• Ventilstyrning- insug .....	• Valve guide- intake .....			
A18	1	1		261961	• Ventilstyrning- utblås .....	• Valve guide- exhaust .....			
A19	1	1		691802	• Ventilsåte- insug .....	• Valve seat- intake .....			
A20	1	1		691844	• Ventilsåte- utblås .....	• Valve seat- exhaust .....			
A21	1	1		491986	• Bussning .....	• Bushing .....			
A22	1	1		692407	• • Tätning .....	• • Seal .....			
A23	1	1		89838	Tändstiftsnyckel .....	Spark plug wrench .....			
A24	1	1		66538	Tändstiftsskydd .....	Spark plug elbow .....			
A25	1	1		9400- 0225- 00	Tändstift .....	Spark plug .....			
A26	1	1		491490	Skydd .....	Cover .....			
A27		2		690960	Skruv .....	Screw .....			
A27	2			692198	Skruv .....	Screw .....			
A28	1	1		690510	• Distans .....	• Spacer .....			
A29	1	1		691681	• Skruv .....	• Screw .....			
A30	1	1		271866	Packning .....	Gasket .....			
A31	1	1		494240	Topplöck .....	Cylinder head .....			
A32	8	8		690904	Skruv .....	Screw .....			
A33	1	1		490666	Bussning .....	Bushing .....			
A34	1	1		291675	• Tätningsring .....	• Oil seal .....			
A35	1	1		690946	Avtappningsplugg .....	Oil drain plug .....			
A36	1	1		494238	Vevhus .....	Oil sump .....			
A37	1	1		692405	Packning .....	Gasket .....			
A37	1	1		692406	Packning .....	Gasket .....		.009"	
A37	1	1		692226	• Packning .....	• Gasket .....		.005"	
A38		1		691328	Ventilationsrör .....	Breather tube .....		.015" Standard	
A38	1			692253	Ventilationsrör .....	Breather tube .....			
A39	1	1		495735	Vevhusventilation .....	Breather .....			
A40	1	1		27803	• Packning .....	• Gasket .....			
A41	2	2		691666	Skruv .....	Screw .....			
A42	10	10		692125	Skruv .....	Screw .....			
A50		1		691658	Skruv .....	Screw .....			

A




B






Utgåva Issue		Bildnr Picture No		BRIGGS & STRATTON 286707, 28M707 INSUGNINGSRÖR (A) VEVAXEL (B)		BRIGGS & STRATTON 286707, 28M707 INTAKE TUBE (A) CRANKSHAFT (B)		Sida Page 208	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	286 707- 1185	28M 707- 1194							
A30	1	1		272554	Packning.....	Gasket.....			
A31	1	1		691711	Insugningsrör.....	Intake manifold.....			
A32	2	2		690953	Skruv.....	Screw.....			
A33	2	2		691098	Pinnbult.....	Stud.....			
A34	2	2		690958	Mutter.....	Nut.....			
B01	1	1		262247	Insugningsventil.....	Intake valve.....			
B02	1	1		691605	Ventilfjäder-insug.....	Valve spring-intake.....			
B03	1	1		690656	Ventilhållare.....	Valve retainer.....			
B04	2	2		691811	Ventillyftare.....	Valve tappet.....			
B05	1	1		262246	Utblåsningsventil.....	Exhaust valve.....			
B06	1	1		691597	Ventilfjäder-utblås.....	Valve spring-exhaust.....			
B07	1	1		691939	Ventilhållare.....	Valve retainer.....			
B08	1	1		494553	Hållare.....	Retainer.....			
B09	1			499284	Kolv kpl.....	Piston assy.....		Standard	
B09	1			499288	Kolv kpl.....	Piston assy.....		.010" O.S.	
B09	1			499292	Kolv kpl.....	Piston assy.....		.020" O.S.	
B09	1			499296	Kolv kpl.....	Piston assy.....		.030" O.S.	
B09		1		696397	Kolv kpl.....	Piston assy.....		Standard	
B09		1		696398	Kolv kpl.....	Piston assy.....		.010" O.S.	
B09		1		696399	Kolv kpl.....	Piston assy.....		.020" O.S.	
B09		1		696400	Kolv kpl.....	Piston assy.....		.030" O.S.	
B10	2	2		691299	• Låsring.....	• Piston pin lock.....			
B11	1			392331	• Kolvringsatts.....	• Ring set.....		Chrome standard	
B11	1			499996	• Kolvringsatts.....	• Ring set.....		Standard	
B11	1			499997	• Kolvringsatts.....	• Ring set.....		.010" O.S.	
B11	1			499998	• Kolvringsatts.....	• Ring set.....		.020" O.S.	
B11	1			499999	• Kolvringsatts.....	• Ring set.....		.030" O.S.	
B11		1		696403	• Kolvringsatts.....	• Ring set.....		Standard	
B11		1		696404	• Kolvringsatts.....	• Ring set.....		.010" O.S.	
B11		1		696405	• Kolvringsatts.....	• Ring set.....		.020" O.S.	
B11		1		696406	• Kolvringsatts.....	• Ring set.....		.030" O.S.	
B12	1	1		498319	Kolvbult.....	Piston pin.....		Standard	
B12	1	1		498320	Kolvbult.....	Piston pin.....		.005" O.S.	
B13	1	1		494504	Vevstake.....	Connecting rod.....		Standard	
B13	1	1		495490	Vevstake.....	Connecting rod.....		.020" U.S.	
B14	1	1		690348	• Skruv.....	• Screw.....			
B15	1	1		690356	• Skruv.....	• Screw.....			
B16	1	1		222698	Kil.....	Key.....			
B17	1	1		693944	Vevaxel.....	Crankshaft.....			
B18	1	1		691658	• Skruv.....	• Screw.....			
B19	1	1		691779	• Vevaxelförlängning.....	• Crankshaft extension.....			
B20	1	1		691639	• Kil.....	• Timing key.....			
B21	1	1		691284	• Drev.....	• Timing gear.....			
B22	1	1		692423	Motvikt.....	Counter weight.....			
B23	1	1		691239	• Axel.....	• Pin.....			
B24	1	1		691714	Länk.....	Link.....			
B25	1	1		691096	Skruv.....	Screw.....			
B26	1	1		692123	Kamaxel.....	Camshaft.....			
B27	1	1		691968	Oljekastardrev.....	Oil slinger.....			
B28	1	1		496415	Oljesticka kpl.....	Oil filler group.....			
B29	1	1		692014	• Oljesticka.....	• Oil dipstick.....			
B30	1	1		691002	• Skruv.....	• Screw.....			
B31	1	1		691398	• Påfyllningsrör.....	• Dipstick tube.....			
B32	1	1		691870	• Tätning.....	• Seal.....			
B33	1	1		281370	• Tätning.....	• Seal.....			
B34	1			691874	Ljuddämpare.....	Muffler.....			
B35	1			692236	• Packning.....	• Gasket.....			
B36	1			692198	• Skruv.....	• Screw.....			
B37	1			691416	• Skruv.....	• Screw.....			
B38	1			690420	• Värmskydd.....	• Heat shield.....			
B39	2			690661	Skruv.....	Screw.....		Deflector	

A





B



Utgåva Issue		Bildnr Picture No		BRIGGS & STRATTON 286707, 28M707 REGULATOR (A) LUFTFILTER (B)		BRIGGS & STRATTON 286707, 28M707 GOVERNOR (A) AIR CLEANER (B)		Sida Page
2003- 11		1184A						210
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	286 707- 1185	28M 707- 1194						
A01	1	1		490324	Skyddskåpa .....	Cover .....		
A02	2	2		691002	• Skruv .....	• Screw .....		
A03	1			690485	Fläkthus .....	Blower housing .....		
A03		1		691399	Fläkthus .....	Blower housing .....		
A04		1		690960	Skruv .....	Screw .....		
A04	1			692198	Skruv .....	Screw .....		
A05	2	2		690661	Skruv .....	Screw .....		
A06	1	1		690456	Svänghjulsskydd .....	Flywheel guard .....		
A07	2	2		692127	Skruv .....	Screw .....		
A08	1	1		694042	Reglageplåt .....	Control bracket .....		
A09	1	1		691795	Regulatorfjäder .....	Governor spring .....		
A10	2	2		691693	Skruv .....	Screw .....		
A11	1	1		691972	Isolator .....	Insulator .....		
A12	1	1		691084	Anslutningsbleck .....	Ground terminal .....		
A13	1	1		691077	Bricka .....	Washer .....		
A14	1	1		691612	Mutter .....	Nut .....		
A15	1	1		691024	Klämma .....	Clamp .....		
A16	1	1		690804	Skruv .....	Screw .....		
A17	1	1		691840	Chokelänk .....	Choke link .....		
A18	2	2		691183	Skruv .....	Screw .....		
A19	1			691065	Generator .....	Alternator .....		
A19		1		696457	Generator .....	Alternator .....		
A20		1		691842	Fjäder .....	Spring .....		
A21	1	1		398808	Kortslutningskabel .....	Ground wire .....		
A22	1	1		492341	Tändsystem .....	Armature magneto .....		
A23	2	2		691061	Skruv .....	Screw .....		
A24	1	1		493880	• Anslutningshylsa .....	• Terminal .....		
A25	1	1		691691	Bricka .....	Washer .....		
A26	1	1		692012	Regulatoraxel .....	Governor crank .....		
A27	1	1		691620	Låsnål .....	Cotter pin .....		
A28	1	1		394358	Bränslefilter .....	Fuel filter .....		
A29	1	1		691050	Bränsleslang .....	Fuel line .....		
A30	2	2		95162	• Slangklämma .....	• Hose clamp .....		
A31	1	1		691374	Regulatorarm .....	Governor lever .....		
A32	1	1		691119	• Bult .....	• Bolt .....		
A33	1	1		691251	• Mutter .....	• Nut .....		
A34		1		691841	Regulatorlänk .....	Governor link .....		
A35		1		692236	Packning .....	Gasket .....		
A37		1		691188	Regulator .....	Regulator .....		
A38		1		694475	Fäste .....	Mounting bracket .....		
A39		2		694476	Skruv .....	Screw .....		
B25	1	1		691668	Låsrott .....	Air cleaner knob .....		
B26		1		691332	Lock .....	Cover .....		
B26	1			691916	Lock .....	Cover .....		
B27	1	1		272403	Filterelement .....	Air cleaner element .....		
B28	1	1		692297	Tätning .....	Seal .....		
B29	1	1		496894	Pappersfilter .....	Cartridge .....		
B30	2	2		692126	Skruv .....	Screw .....		
B31	1	1		696129	Luftrenarfäste .....	Air cleaner base .....		
B32	1	1		691328	• Ventilationsrör .....	• Breather tube .....		
B33	1	1		691917	• O- ring .....	• O- ring .....		
B34	1	1		693675	• Skruv .....	• Screw .....		
B35	2	2		690958	Mutter .....	Nut .....		

A


WALBRO



B




NIKKI





Utgåva Issue		Bildnr Picture No		BRIGGS & STRATTON 286707, 28M707 FÖRGASARE WALBRO (A) FÖRGASARE NIKKI (B)		BRIGGS & STRATTON 286707, 28M707 CARBURETOR WALBRO (A) CARBURETOR NIKKI (B)		Sida Page
2003-11		1185A						212
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	286 707- 1185	28M 707- 1194						
A01	1	1		495931	Chokeaxel .....	Choke shaft .....		Choke A Matic
A02	1	1		692344	• Chokespjäll .....	• Choke valve .....		
A03	1	1		690802	• Fjäder o tätning .....	• Spring and seal .....		
A04	1			498027	Förgasare kpl .....	Carburettor assy .....		Walbro
A04		1		697594	Förgasare kpl .....	Carburettor assy .....		
A05	1	1		494379	• Spjällaxel .....	• Shaft .....		
A06	1	1		691750	•• Spjäll .....	•• Throttle valve .....		
A07	1	1		691636	•• Skruv .....	•• Screw .....		
A08	1	1		691326	•• Axeltätning .....	•• Shaft seal .....		
A09	1	1		690602	•• Axelbussning .....	•• Shaft bushing .....		
A10	1	1		690572	• Fjäder .....	• Spring .....		
A11	1	1		495097	• Chokeaxel .....	• Choke shaft .....		Manual Choke
A12	1	1		690464	•• Chokespjäll .....	•• Choke valve .....		
A13	1	1		691636	•• Skruv .....	•• Screw .....		
A14	1	1		690801	•• Fjäder o tätning .....	•• Spring and seal .....		
A15		1		694524	• Plugg .....	• Welch plug .....		
A15	1			695005	• Expansionsplugg .....	• Welch plug .....		
A16	1	1		692284	• Packning .....	• Gasket .....		
A17	1			497737	• Munstycke .....	• Nozzle .....		High Altitude Standard Standard
A17	1			691434	• Munstycke .....	• Nozzle .....		
A17		1		697592	• Munstycke .....	• Nozzle .....		
A18	1	1		495800	• Justerskruv .....	• Idle adjust screw .....		
A19	1	1		498030	• Nålventil .....	• Needle valve .....		
A20	1	1		691333	•• Begränsningshuv .....	•• Limiter cap .....		
A21	1	1		690577	• Säte .....	• Inlet seat .....		
A22	1	1		231855	• Nålventil .....	• Inlet needle valve .....		
A23	1	1		494381	• Flottör .....	• Float .....		
A24	1	1		690525	•• Flottöraxel .....	•• Float hinge pin .....		
A25	1	1		495933	• Flottörhus .....	• Bowl .....		
A26	1	1		281165	•• Packning .....	•• Gasket .....		
A27	1	1		692255	•• Tätningsbricka .....	•• Sealing washer .....		
A28	1	1		691657	•• Skruv .....	•• Float bowl screw .....		
A29	1			692317	• Nippel .....	• Hose connector .....		
A39		1		494768	Bränslekran .....	Shut-off valve .....		
B01	1			694941	Förgasare kpl .....	Carburettor assy .....		Nikki
B02	1			694909	• Spjällaxel .....	• Throttle shaft .....		
B03	1			694917	•• Spjäll .....	•• Throttle valve .....		
B04	1			690718	•• Skruv .....	•• Screw .....		
B05	1			690998	•• Tätning .....	•• Shaft seal .....		
B06	1			694913	• Chokeaxel .....	• Choke shaft .....		
B07	1			694923	•• Chokespjäll .....	•• Choke valve .....		
B08	1			690718	•• Skruv .....	•• Screw .....		
B09	1			694912	•• Fjäder o tätning .....	•• Spring and seal .....		
B10	1			692284	• Packning .....	• Gasket .....		
B11	1			694921	• Plugg .....	• Carburettor plug .....		
B12	1			694927	• Munstycke .....	• Pilot jet .....		
B13	1			694907	• Justerskruv .....	• Idle speed kit .....		
B14	1			694914	• Flottör .....	• Float .....		
B15	1			694918	•• Flottöraxel .....	•• Float hinge pin .....		
B16	1			694916	• Expansionsplugg .....	• Welch plug .....		
B17	1			694908	• Flottörhus .....	• Float bowl .....		
B18	1			690880	• Huvudmunstycke .....	• Main jet .....		Standard High Altitude
B18	1			694925	• Huvudmunstycke .....	• Main jet .....		
B19	1			694920	•• Packning .....	•• Gasket .....		
B20	1			694924	• Förgasarpplugg .....	• Carburettor plug .....		
B21	1			694922	• Nålventil .....	• Float needle valve .....		
B22	1			694926	• Tomgångsventil .....	• Idle mixture valve .....		
B23	1			690997	•• Tätningsbricka .....	•• Sealing washer .....		
B24	1			694919	•• Skruv .....	•• Float bowl screw .....		

A







Utgåva Issue		Bildnr Picture No		BRIGGS & STRATTON 286707, 28M707 STARTMOTOR (A)		BRIGGS & STRATTON 286707, 28M707 STARTER MOTOR (A)		Sida Page	
2003- 11		1186						214	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	286 707- 1185	28M 707- 1194							
A01	1	1		693551	Startmotor kpl .....	Starter motor assy .....			
A02	1	1		693699	• Startdrev .....	• Starter drive .....			
A03	1	1		691265	• • Låsring .....	• • Retaining ring .....			
A04	1	1		693713	• • Drev .....	• • Pinion gear .....			
A05	1	1		692024	• • Koppling .....	• • Drive clutch .....			
A06	1	1		692034	• Rotor .....	• Armature .....			
A07	1	1		693757	• Startmotorhus .....	• Starter housing .....			
A08	1	1		691283	• Lock .....	• Drive cap .....			
A08	1	1		691429	• Lock .....	• Drive cap .....			
A09	1	1		691293	• Borsthållare .....	• Brush retainer .....			
A10	1	1		497608	• • Släpkolssats .....	• • Brush set .....			
A11	1	1		693167	• • Mutter .....	• • Nut .....			
A12	1	1		691286	• Botten .....	• End cap .....			
A13	1	1		691029	• Mutter .....	• Nut .....			
A14	2	2		690323	• Bult .....	• Bolt .....			
A15	2	2		690372	Skruv .....	Screw .....			

A



B





Utgåva Issue		Bildnr Picture No		BRIGGS & STRATTON 286707, 28M707 PACKN.SATS MOTOR (A) PACKN.SATS FÖRG. (B)		BRIGGS & STRATTON 286707, 28M707 GASKET SET ENGINE (A) GASKET SET CARB. (B)		Sida Page 216
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	286 707- 1185	28M 707- 1194						
A01	1	1		494241	Packnings-sats- motor.....	Gasket set- engine.....		
A02	1	1		391086	• Tätningssring .....	• Seal .....		
A03	1	1		291675	• Tätningssring .....	• Oil seal .....		
A04	1	1		281370	• Tätning .....	• Seal .....		
A05	1	1		691917	• O- ring.....	• O- ring .....		
A06	1	1		691870	• Tätningssring .....	• Seal .....		
A07	1	1		692407	• Tätning .....	• Seal .....		
A08	1	1		692226	• Packning .....	• Gasket .....		.015" Standard
A08	1	1		692405	• Packning .....	• Gasket .....		.009"
A08	1	1		692406	• Packning .....	• Gasket .....		.005"
A09	1	1		271866	• Packning .....	• Gasket .....		
A10	1	1		27803	• Packning .....	• Gasket .....		
A11	1	1		692236	• Packning .....	• Gasket .....		
A12	1	1		498539	Packnings-sats- ventil.....	Gasket set- valve .....		
B01	1			499220	Reparationssats- förg. ....	Overhaul kit- carb. ....		Walbro
B01		1		697884	Rep.sats- förgas. ....	Carb. overhaul kit.....		
B02		1		694524	• Plugg .....	• Welch plug .....		
B02	1			695005	• Expansionsplugg .....	• Welch plug .....		
B03	1	1		281165	• Packning .....	• Gasket .....		
B04	1	1		692255	• Tätningssbricka .....	• Sealing washer .....		
B05	1	1		690577	• Säte .....	• Inlet seat .....		
B06	1	1		690525	• Flottöraxel.....	• Float hinge pin.....		
B07	1			691434	• Munstycke .....	• Nozzle .....		Standard
B07		1		697592	• Munstycke .....	• Nozzle .....		
B08	1	1		691636	• Skruv .....	• Screw .....		
B09	1	1		691326	• Axeltätning.....	• Shaft seal .....		
B10	1	1		231855	• Nålventil.....	• Inlet needle valve.....		
B11	1	1		691636	• Skruv .....	• Screw .....		
B12	1	1		692284	• Packning .....	• Gasket .....		
B13	1	1		690802	• Fjäder o tätning.....	• Spring and seal .....		Choke A Matic
B14	1	1		494385	Packningssats- förg. ....	Gasket set- carb. ....		Walbro
B15	1	1		690602	• Axelbussning .....	• Shaft bushing .....		
B16	1	1		690801	• Fjäder o tätning.....	• Spring and seal .....		Manual Choke
B17	1			694930	Reparationssats- förg. ....	Overhaul kit- carb. ....		Nikki
B18	1			690718	• Skruv .....	• Screw .....		
B19	1			690880	• Huvudmunstycke.....	• Main jet .....		Standard
B19	1			694925	• Huvudmunstycke.....	• Main jet .....		High Altitude
B20	1			690997	• Tätningssbricka .....	• Sealing washer .....		
B21	1			694918	• Flottöraxel.....	• Float hinge pin.....		
B22	1			694916	• Expansionsplugg .....	• Welch plug .....		
B23	1			694912	• Fjäder o tätning.....	• Spring and seal .....		
B24	1			694922	• Nålventil.....	• Float needle valve.....		
B25	1			694927	• Munstycke .....	• Pilot jet .....		
B26	1			690998	• Tätning .....	• Shaft seal .....		
B27	1			694920	• Packning .....	• Gasket .....		
B28	1			690718	• Skruv .....	• Screw .....		
B29	1			694924	• Förgasarplugg.....	• Carburettor plug.....		
B30	1			694931	Packningssats- förg. ....	Gasket set- carb. ....		Nikki