


# Genuine Spare Parts

---



Joist  
Spareparts  
Joist



Utgåva Issue		Bildnr Picture No		DINO 47 DINO 45	DINO 47 DINO 45	Sida Page	
2006- 12		1899A				46	
Pos. Fig.	Antal/Quantity		Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	1134 -20	1181 -59					
1	1	1	1111-3061-01	Kåpa- gul .....	Chassis- yellow .....		
2	3	3	9955-3732-12	Skruv .....	Screw .....		
3	3	3	9699-0029-02	Planbricka .....	Flat washer .....		
4	2	2	9747-0631-02	Låsmutter .....	Lock nut .....		
5	2	2	9699-0035-02	Planbricka .....	Flat washer .....		
6	1	1	1111-1129-02	Utkastskärm- gul .....	Ejection shield- yello .....		
7	2	2	9997-0614-16	Skruv .....	Screw .....		
8	4	4	1111-2987-01	Isoleringshylsa .....	Isolation collar .....		
9	4	4	9997-0830-16	Skruv .....	Screw .....		
10	4	4	9699-0062-02	Planbricka .....	Flat washer .....		
11	2	2	1111-2986-01	Isoleringsplatta .....	Isolation plate .....		
12	4	4	9747-0831-02	Mutter .....	Lock nut .....		
13	1	1	1111-3014-01	Styre- underdel .....	Handle- lower part .....		
14	2	2	9795-3531-02	Mutter .....	Nut .....		
15	2	2	1111-3023-01	Låsrratt .....	Locking knob .....		
16	2	2	9699-0090-02	Planbricka .....	Flat washer .....		
17	1	1	1111-3062-01	Ögla .....	Eyelink .....		
18	2	2	9899-3557-12	Skruv .....	Screw .....		
19	2	2	1111-0178-00	Förstärkning .....	Reinforcement .....		
51	1	1	1136-1848-01	Styre- överdel .....	Handle- upper .....		
52	1	1	1111-2953-01	Manöverbygel .....	Control handle .....		
53	1	1	1111-2968-01	Motorbromswire .....	Engine brake cable .....		
53	1	1	1111-2968-05	Motorbromswire .....	Engine brake cable .....		
54	1	1	1111-2969-01	Wirefäste .....	Cable attachment .....		
55	1	1	9948-0640-16	Skruv .....	Screw .....		
56	1	1	9747-0631-02	Låsmutter .....	Lock nut .....		
151	1	1	1136-0604-01	Mutter .....	Nut .....		
152	1	1	1136-0611-01	Låsbricka .....	Grower .....		
153	1	1	1136-0659-01	Distans .....	Spacer .....		
154	1	1	9699-0035-02	Planbricka .....	Flat washer .....		
155	1	1	1136-0606-01	Fjäderbricka .....	Spring washer .....		
156	1	1	1136-0766-01	Gasreglagearm .....	Throttle lever .....		
157	1	1	1136-0764-01	Gasreglagekabel .....	Throttle cable .....		
158	1	1	1136-0618-01	Skruv .....	Screw .....		
159	1	1	1136-1857-01	Dekal .....	Label .....		
X 301	2	2	1136-2262-01	Hjulaxel .....	Wheel axle .....		
302	1	1	1111-9035-01	Höjdinställning sats .....	Height adjust kit .....		Inkl. pos 302- 303
302	2	2	1111-1589-02	• Fjäder- hö .....	• Height adj.spring- RH .....		
303	2	2	1111-1589-01	• Fjäder- vä .....	• Height adj.spring- LH .....		
304	4	4	1111-1593-01	Bricka .....	Washer .....		
305	4	4	9699-0037-02	Bricka .....	Washer .....		
306	4	4	1117-1161-01	Hjulsköld .....	Wheel protection .....		
307A	8	8	1136-0655-01	Kullager .....	Ball bearing .....		
307B	8	8	1136-0634-01	Bussning .....	Bush .....		
X 308	4	4	1136-2014-01	Hjul .....	Wheel .....		
310	4	4	1117-1356-01	Låsbricka .....	Lock washer .....		
311	4	4	1136-1894-01	Navkapsel- gul .....	Hub cap- yellow .....		
312	4	4	1111-3060-01	Fjäder .....	Spring .....		
501	1	1	1111-9066-01	Knivfäste .....	Blade holder .....		
502	1	1	1111-9502-01	Kniv .....	Blade .....		
503	1	1	9696-0011-01	Bricka .....	Washer .....		
504	1	1	9987-5238-12	Knivbult .....	Blade bolt .....		
505	1	1	9600-0014-00	Kil .....	Key .....		