

STIGA


TRAC 1236G (1989)

13-8111-12

Spare parts list **Reservdelar** **Repuestos** **Ersatzteile** **Pièces détachées** **Reserve onderdelen** **Catalogo ricambi**


- Use ST. S.p.A. Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative And might Not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair And/Or replacement, make sure that the illustrated parts list Is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

All rights reserved. No part Of this material may be reproduced Or transmitted, in any form Or by any means, electronic Or mechanical, including photocopying, recording Or by any information storage And retrieval system, without permission in writing from ST. S.p.A.




Chassie

Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
23	1	1132-0870-01	Fußplatte-rechts			
24	1	1132-0872-01	Fußplatte-links			
26	1	1132-0871-01	Fußplatte			
41	1	1132-0189-01	Frontgitter			
42	4	1132-0214-01	Befestigungswinkel			
43	8	1132-0035-01	Popniet			
45	2	1132-0248-01	Dichtung			
58	2	1132-0863-01	Stopfen			




Lenkung Geräteheber

Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
1	4	1811-0754-01	Schraube			
2	1	1132-0337-01	Lenkrad			
2	1	1132-0867-01	Lenkrad	1236G		
3	1	1132-0018-01	Stift			
4	1	1132-0027-01	Flanschlager			
5	1	1132-0537-01	Achsstütze			
6	13	9727-3541-22	Mutter			
7	17	1132-0690-01	Schraube			
8	1	1132-0548-01	Konsole			
9	4	1132-0023-01	Mutter			
10	1	1132-0828-01	Batterie Halter			
11	2	1132-0883-01	Riemenführung			
12	1	1132-0145-01	Handgriff			
13	4	1811-0182-01	Scheibe			
14	33	1132-0691-01	Schraube			
15	2	1132-0487-01	Mutter			
16	1	1132-0466-01	Lenkarm			
17	1	1132-0617-01	Scheibe			
18	2	1132-0022-01	Schließring			
19	1	1132-0300-01	Bolzen			
20	1	1132-0886-01	Hebegelenk	Inkl.pos. 21		
22	2	9699-0038-02	Scheibe			
23	42	9727-3641-22	Mutter			
24	2	1811-0122-01	Split			
25	1	1132-0494-01	Auftriebsstange			
26	1	1811-0176-01	Grease Fitting			
27	1	1132-0761-01	Hebeachse			
28	1	1132-0757-01	Halter			
29	1	1132-0447-01	Bodenstück			
30	2	1132-0158-01	Achstütze			
31	1	1132-0898-01	Hebel			
32	2	1132-0021-01	Schließring			
33	1	9652-0015-04	Circlip			
34	1	1132-0804-01	Rahmen-hintere			
35	4	1132-0199-01	Winkel			
36	1	1132-0498-01	Lenkachse			
37	1	1132-0125-01	Scheibe			
38	1	1132-0302-01	Flanschlager			
39	1	1132-0471-01	Lenkplatte			
40	1	1132-0058-01	Scheibe			
41	1	1132-0468-01	Lenkwelle			
42	2	1132-0020-01	Flange Bearing			
43	1	9650-0019-04	Sprengring			
44	1	1132-0303-01	Steigbügel			
45	1	1132-0470-01	Lenkarm			
46	2	9988-3757-12	Schraube			
47	4	9743-3721-32	Mutter			
48	4	1811-0204-01	Planscheibe			




Lenkung Geräteheber

Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
49	2	9743-5221-32	Mutter			
50	2	1132-0063-01	Gelenk			
51	2	9743-5421-32	Mutter			
52	1	1132-0467-01	Lenkungsstab			
53	1	1132-0304-01	Steigbügel			
54	1	1132-0481-01	Geräthalter			
55	4	9954-3719-16	Schraube			
56	4	1132-0695-01	Mutter			
57	1	1132-0893-01	Mutter			
58	1	1132-0894-01	Schraube			
59	1	1132-0463-01	Schenkel-links			
60	1	1132-0464-01	Schenkel-rechts			
61	4	1132-0453-01	Büchse			
62	2	9545-0500-00	Ventil Kompl.			
63	4	1811-0190-01	Grease Fitting			
64	2	1132-0573-01	Rad			
65	2	1132-0454-01	Reifen	15 x 6.00-6		
66	4	1132-0181-01	Flange Bearing			
67	4	1132-0021-01	Schließring			
68	1	1811-0200-01	Scheibe			
69	1	1132-0465-01	Vorderachse			
70	1	1132-0483-01	Spannstange			
71	1	1132-0185-01	Rahmen-vorne			
72	1	1132-0259-01	Riemenführung			
73	2	1132-0264-01	Radkappe			
74	1	1811-0182-01	Scheibe			
75	2	1132-0305-01	Drahtführung			
76	2	9988-3732-12	Schraube			
77	2	1132-0837-01	Riemenscheibe			
78	2	1132-0307-01	Entfernungsstück			
79	2	1132-0510-01	Steigbügel			
80	1	1132-0538-01	Push Link			




Motor

Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
1	1	1132-0262-01	Tankpolster			
2	1	1132-0825-01	Kraftstoffmesser			
3	1	1132-0850-01	Treibstofftank			
4	1	1132-0542-01	Kraftstoffleitung			
5	2	1132-0475-01	Schlauchklemme			
6	1	1132-0503-01	Brennstoffhahn			
7	1	1132-0151-01	Büchse			
8	2	1132-0139-01	Knopf			
9	1	1132-0251-01	Gasregulierung			
10	1	1132-0252-01	Starter Betaetigung			
11	8	1811-0138-01	Schraube			
12	4	1811-0191-01	Mutter			
13	1	1132-0358-01	Hülse			
14	1	1132-0111-01	Treibstofffilter			
15	1	1132-0691-01	Schraube			
16	4	1132-0488-01	Schraube			
17	4	9795-3631-02	Mutter			
18	4	9683-0030-02	Scheibe			
20	5	1811-0350-01	Cableholder			
21	1	1132-0642-01	Wärmeschutz			
22	3	1132-0336-01	Klammer			
23	3	1132-0690-01	Schraube			
24	5	1811-0192-01	Schraube			
25	1	1132-0643-01	Wärmeschutz			
26	1	1132-0646-01	Winkelrohr			
27	2	1132-0016-01	Scheibe			
28	1	1132-0645-01	Wärmeschutz			
29	1	1132-0684-01	Schalldämpfer			
30	8	1132-0033-01	Mutter			
31	1	1132-0644-01	Wärmeschutz			
32	2	1132-0354-01	Schraube			
33	1	9988-3651-12	Schraube	51 mm		
34	3	9988-3638-12	Schraube	38 mm		
35	1	1132-0360-01	Schlüssel			
36	1	1132-0296-01	Riemenscheibe			
37	1	1132-0685-01	El-Kupplung			
38	1	1132-0267-01	Scheibe			
39	1	9683-0045-02	Scheibe			
40	1	1132-0266-01	Schraube			
41	1	9678-0009-02	Scheibe			
42	1	9699-0028-02	Scheibe			
43	1	1132-0679-01	Anschlagswinkel			
44	1	1132-0777-01	Entfernungsstück			
45	1	9683-0025-02	Scheibe			
46	1	9988-3525-16	Schraube			





Getriebe

Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
1	1	1132-0257-01	Knopf			
3	2	1132-0064-01	Nylonbuchse			
4	4	9988-3670-12	Schraube			
5	11	9699-0029-02	Scheibe			
6	1	1132-0299-01	Knopf			
7	1	1132-0717-01	Riemen			
8	2	1132-0543-01	Riemenführung			
8	1	1132-0715-01	Riemenführung			
10	2	1132-0025-01	Satz, Schrauben			
11	1	1132-0219-01	Riemenscheibe			
12	1	1132-0001-02	Getriebe kompl			
13	2	1132-0005-01	Schlüssel			
15	4	9743-3621-32	Mutter			
16	1	1132-0180-01	Gehäuse Getriebeplattform.			
17	3	1132-0691-01	Schraube			
18	3	9727-3641-22	Mutter			
19	2	1811-0754-01	Schraube			
20	1	1132-0291-01	Bremsgestänge			
21	1	1132-0215-01	Splint			
23	1	1132-0216-01	Getriebearm			
24	1	9699-0026-02	Scheibe			
25	1	9683-0025-02	Scheibe			
26	1	9987-5013-16	Schraube			
27	1	1132-0256-01	Schaltgelenk			
28	2	9743-5321-32	Mutter			
29	1	1132-0255-01	Schaltstange			
30	1	9600-0050-00	Schlüssel			
31	1	1132-0516-01	Spannarmsbefestigung			
32	1	1132-0224-01	Feder			
34	3	1811-0142-01	Stift			
38	3	9743-3721-32	Mutter			
39	1	1132-0416-01	Lenkhülse			
40	2	1132-0519-01	Hebel			
43	1	9699-0038-02	Scheibe			
44	1	1132-0121-01	Feder			
46	2	1132-0059-01	Nylonbuchse			
47	1	1132-0517-01	Torsion Spring			
48	1	1132-0289-01	Spannarm			
49	1	1132-0104-01	Idler Pulley			
50	2	1132-0906-01	Riemenführung			
51	1	9988-3757-12	Schraube			
52	1	9683-0035-02	Scheibe			
53	1	1132-0446-01	Idler Pulley			
54	2	1132-0179-01	Entfernungsstück			
55	2	1132-0580-01	Reifen	20 x 10.00-8		
56	2	9545-0500-00	Ventil Kompl.			
57	2	1132-0561-01	Felge			
58	1	1132-0355-01	Federscheibe			




Getriebe

Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
59	2	1132-0021-01	Schließring			
60	1	1132-0119-01	Pedalgummi			
61	1	1132-0826-01	Bremspedal			
64	1	1132-0546-01	Schaltstange			
65	1	1132-0491-01	Bremsstange			
66	9	9599-0070-02	Split Pin			
67	1	1132-0290-01	Kupplungsstange			
69	1	9988-3745-12	Schraube			
71	1	1132-0055-01	Entfernungsstück			
72	1	1132-0545-01	Schalthebel			
73	1	1132-0448-01	Augbolzen			
83	2	1132-0047-01	Planscheibe			
84	8	1132-0567-01	Radbolzen			
85	2	1132-0901-01	Felge			
86	8	1132-0566-01	Mutter			




Elektrisches System

Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
2	1	1132-0829-01	Batterie Kabel (+)			
3	4	9727-3541-22	Mutter			
4	1	1132-0237-01	Lampenhalter			
5	2	1132-0103-01	Headlight			
6	1	1132-0681-01	Diode			
8	3	1811-0350-01	Cableholder			
9	1	1132-0830-01	Batterie Kabel (-)			
10	1	1132-0868-01	Linse			
11	1	1132-0876-01	Stundenmesser			
12	2	9795-3531-02	Mutter			
13	2	9699-0026-02	Scheibe			
14	3	9743-3521-32	Mutter			
15	2	1132-0727-01	Bolzen			
16	4	1811-0138-01	Schraube			
17	4	1811-0191-01	Mutter			
18	1	1132-0729-01	Batterie			
19	1	1132-0532-01	Solenoid			
20	5	1132-0489-01	Schraube			
21	2	1132-0238-01	Halter			
22	1	9795-3631-02	Mutter			
23	1	1132-0358-01	Hülse			
24	1	1132-0078-01	Anlasserkabel			
25	1	1132-0529-01	Kabelbündel			
26	3	1132-0336-01	Klammer			
27	1	1132-0859-01	Gummimatte			
28	2	9683-0025-02	Scheibe			
29	2	9988-3516-16	Schraube			
30	1	1132-0831-01	Kabelbündel			
31	1	1132-0749-01	Pto Switch			
32	1	1132-0753-01	Schalter			
33	1	1132-0653-01	Ignition Switch			
34	2	1134-2848-01	Zündschlüssel			
35	1	1132-0550-01	Kabelbündel			
36	1	1132-0801-01	Deckel			
37	3	1132-0899-01	Lampe			
38	1	1132-0034-01	Schraube			
39	1	1132-0211-01	Sicherung			
40	1	1132-0544-01	Hülse			
41	1	1132-0720-01	Switch, Interlock			
43	2	9863-3516-16	Schraube			
44	1	1132-0725-01	Schalter			
45	1	1132-0784-01	Hülse			
46	1	1132-0756-01	Hülse			




Mähwerk 36"

Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
1	1	1132-0332-01	Schraube	70 mm		
1	1	1132-0333-01	Schraube	76 mm		
2	2	9683-0045-02	Scheibe			
3	2	1132-0142-01	Planscheibe			
4	1	1132-0670-01	Rimenscheibe			
4	1	1132-0671-01	Riemenscheibe			
5	2	1132-0323-01	Bearing Shield			
6	2	1132-0325-01	Top Arbor Housing			
7	4	1811-0167-01	Kugellager			
8	2	1132-0877-01	Arbor Shaft			
9	2	1132-0326-01	Lagerbuchse			
10	2	1132-0535-01	Splint			
11	1	9598-0003-02	Schliessnadel			
12	2	9699-0038-02	Scheibe			
13	2	1132-0627-01	Entfernungsstück			
14	1	1132-0226-01	Montageplatte			
15	1	1132-0669-01	Verstellungstange			
16	3	1811-0123-01	Split			
17	1	1132-0080-01	Splint			
18	2	9743-3921-32	Mutter			
19	2	9988-3932-16	Schraube			
20	1	1132-0311-01	Halter Platte			
20	1	1132-0583-01	Halter Platte			
21	8	9899-3622-16	Schraube			
22	22	9743-3621-32	Mutter			
23	13	9988-3619-16	Schraube			
24	9	9743-3721-32	Mutter			
24	7	9743-3721-32	Mutter			
25	1	9988-3751-12	Schraube			
26	2	1132-0446-01	Idler Pulley			
27	1	1132-0313-01	Riemenführung			
28	1	1132-0677-01	Spannarm			
29	2	1132-0079-01	Flanschlager			
30	1	1132-0751-01	Drehblech			
31	1	9683-0035-02	Scheibe			
32	1	9988-3719-16	Schraube			
33	1	1132-0310-01	Deckel			
34	1	1132-0540-01	Haubenanschlag			
35	1	1132-0314-01	Federhalter			
36	3	9988-3757-12	Schraube			
37	1	1132-0104-01	Idler Pulley			
38	1	1132-0065-01	Entfernungsstück			
39	1	1132-0346-01	Halter			
40	4	1132-0049-01	Scheibe			
41	1	1132-0559-01	Welle			
42	1	1132-0347-01	Winkelbefestigung			
43	1	1132-0316-01	Leitblech			
44	1	1132-0317-01	Befestigungswinkel			




Mähwerk 36"

Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
45	8	1811-0182-01	Scheibe			
45	8	9699-0042-02	Scheibe			
46	2	1132-0233-01	Stützrad			
47	1	1132-0582-01	Stützradswelle			
47	1	1132-0614-01	Stützradsachse			
48	1	1132-0306-01	Lift Cable			
48	1	1132-0584-01	Draht			
49	1	1132-0297-01	Justiergabel			
50	1	1132-0091-01	Splint			
51	2	1132-0524-01	Schließring			
52	1	1132-0006-01	Clevis Pin			
53	1	1132-0541-01	Höhenverst.segment			
54	2	9699-0038-02	Scheibe			
55	1	1811-0169-01	Retainer			
57	1	1132-0135-01	Handgriff			
58	1	1132-0590-01	Riemen			
58	1	1132-0673-01	Riemen			
59	4	9699-0029-02	Scheibe			
60	1	1132-0497-01	Splint			
61	1	1132-0678-01	Riemenschutz			
62	2	9795-4131-02	Mutter			
63	1	1132-0228-01	Justiernippel			
64	2	1132-0331-01	Schraube			
65	2	9683-0045-02	Scheibe			
66	2	1132-0319-01	Scheibe			
67	2	1132-0321-01	Mower Blade			
68	2	1132-0410-01	Wellenhose			
69	2	1132-0320-01	Blade Adapter			
70	2	1132-0322-01	Grass Shield			
71	2	1132-0324-01	Scheibe			
72	12	1811-0754-01	Schraube			
73	2	9899-3725-16	Schraube			
74	1	1132-0318-01	Prallblech			
75	1	1132-0881-01	Feder			
76	1	9988-3625-16	Schraube			
77	1	1132-0330-01	Etikett			
78	1	1132-0132-01	Entfernungsstück			
79	3	9988-3757-12	Schraube			
80	6	1811-0120-01	Vorstrechstift			
81	1	1132-0674-01	Hebeachse			
82	1	1132-0553-01	Schutzrahmen			
83	3	1811-0122-01	Split			
85	5	9699-0104-02	Scheibe			
86	2	1132-0880-01	Rollen			
87	2	1132-0525-01	Schließring			
88	1	1132-0509-01	Achse			
89	1	1132-0558-01	Hebestange			
90	1	1132-0554-01	Hebegelenk			




Mähwerk 36"

Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
91	1	1132-0675-01	Hebestange			
92	2	1132-0098-01	Scheibe			
93	1	1132-0676-01	Riemenführung			
94	1	1132-0625-01	Feder			
95	1	9988-3764-12	Schraube			
95	1	9988-3776-12	Schraube			
96	1	1132-0672-01	Feder			
97	2	1132-0042-01	Scheibe			




Getriebe

Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
0	1	1132-0001-02	Getriebe kompl	Trac 12-TRM107		
0	1	1134-2469-01	Getriebe assy	Park 2002		
1	1	P007-7007-1A	Case			
2	1	P000-7781-36	Gear	15T		
2	1	P000-7781-45	Gear	12T		
3	1	P007-7812-6A	Gear	20T		
4	1	P007-7812-7A	Gear	25T		
5	1	P000-7781-63	Gear	31T		
5	1	P007-7812-9A	Gear	30T		
6	1	P000-7781-62	Gear	19T		
6	1	P007-7812-1A	Gear	20T		
7	1	P007-7812-3A	Gear	25T		
8	1	P007-7812-4A	Gear	30T		
9	1	P007-7812-2A	Gear	22T		
10	1	P007-7812-8A	Gear	28T		
11	1	P007-7814-6A	Gear	37T		
12	1	P000-7781-54	Gear	42T		
12	1	P007-7813-7A	Gear	42T		
13	1	P000-7842-66	Collar			
14	1	P000-7860-60	Zahnkettenrad	14T		
14	1	P000-7860-83	Zahnkettenrad	18T		
15	1	P000-7860-61	Zahnkettenrad	10T		
15	1	P000-7860-82	Zahnkettenrad	9T		
16	1	P000-7761-81	Welle			
16	1	P000-7762-04	Welle			
17	1	P000-7781-53	Bevel pinion			
17	1	P007-7811-3A	Bevel pinion			
18	1	P000-7860-74	Entfernungsstück			
19	1	P000-7781-38	Ritzel			
20	1	P000-7781-39	Gear			
21	1	P000-7900-03	Bremsscheibe			
22	2	P007-9208-9A	Schlüssel			
23	1	P000-7860-75	Sleeve			
25	1	P000-7880-40	Reataining ring			
26	3	P007-8010-5A	Büchse			
27	2	P007-8011-8A	Büchse			
27	1	P007-8011-8A	Büchse			
28	1	P000-7860-81	Kette			
28	1	P007-8606-2A	Kette			
29	4	P000-7800-72	Scheibe			
30	2	P000-7800-86	Walzenrohr			
30	2	P000-7801-22	Walzenrohr			
31	1	P000-7920-77	Kugel			
32	1	P000-7801-09	Scheibe			
33	1	P000-7920-78	Schraube			
34	1	P000-7920-79	Feder			
35	17	P000-7920-73	Schraube			
36	5	P000-7801-08	Scheibe			






Getriebe


Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
37	1	P000-7801-11	Walzenrohr			
37	1	P000-7801-21	Walzenrohr			
38	1	P000-7801-13	Scheibe			
39	2	P000-7801-19	Kugellager			
41	2	P000-7880-51	Seal			
42	1	P000-7880-57	Ring			
42	1	P000-7920-01	O-ring			
43	2	P000-7801-12	Walzenrohr			
44	1	P000-7801-14	Scheibe			
46	2	P000-7880-53	Ring			
47	1	P000-7720-82	Cover			
47	1	P007-7207-8A	Cover			
48	1	P000-7842-90	Shift rod			
49	1	P000-7761-35	Welle			
49	1	P000-7762-26	Welle			
50	1	P007-7618-3A	Welle			
50	1	P007-7618-4A	Welle			
51	1	P000-7900-07	Brake plate			
52	2	P000-7900-06	Brake pad			
53	2	P000-7860-26	Dowel pin			
54	1	P000-7920-75	Mutter			
55	1	P000-7920-76	Scheibe			
56	1	P000-7900-08	Bremshebel			
56	1	P000-7900-31	Bremshebel			
57	2	P000-7920-73	Schraube			
58	1	P000-7900-25	Holder			
59	1	P007-7805-3A	Gear assy			
60	2	P000-7800-64	Büchse			
60	1	P000-7801-20	Büchse			
61	2	P000-7781-66	Bevel gear			
61	2	P000-7782-21	Bevel gear			
62	2	P000-7780-68	Gear			
62	2	P000-7781-31	Gear			
63	1	P000-7860-34	Treibbolzen			
64	2	P000-7800-65	Scheibe			
65	2	P000-7921-25	Snap ring			
66	1	P000-7920-40	Bolzen			
67	2	P000-7800-01	Scheibe			
68	1	P000-7746-70	Achse	382 mm		
68	1	P007-7467-3A	Achse	368 mm		
69	1	P000-7746-69	Achse	335 mm		
69	1	P007-7467-4A	Achse	320 mm		
70	1	P000-7920-35	Schließring			
71	1	P000-7920-74	Plug			
72	1	P000-7860-86	Steigbügel			
77	2	P000-7800-14	Scheibe			
77	2	P000-7921-25	Snap ring			



121 CARBURETOR OVERHAUL KIT




861 PUMP REPAIR KIT





Carburettor


Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
52	1	270872	Dichtung			
94	1	292681	Ventil			
95	2	93499	Schraube			
98	1	91920	Schraube			
99	1	26157	Feder			
101	1	93043	Bolzen			
104	1	230896	Welle			
108	1	222010	Choke valve			
118	1	396568	Needle valve			
121	1	394698	Overhaul kit	Delarna märkta F		
123	2	93357	Schraube			
125	1	490518	Vergaser kpl			
125	1	490518	Vergaser kpl	281707-0127		
125	1	491031	Vergaser kpl	281707-0142		
125	1	491031	Vergaser kpl			
126	1	490473	Carurettor body			
126	1	490473	Carurettor body	281707-0142		
126	1	490515	Vergaser			
126	1	490515	Vergaser	281707-0127		
127	1	221997	Welch plug			
128	1	211960	Venturi			
130	1	222433	Throttle valve			
131	1	491006	Welle			
132	1	211712	Stop			
133	1	299707	Float			
134	1	394681	Nadelventil			
134	1	394681	Nadelventil	281707-0142 _/ Kit: F		
134	1	394683	Inlet valve	281707-0127 _/ Kit: F		
134	1	394683	Inlet valve			
136	1	221995	Bowl			
137	1	270511	Dichtung			
138	1	222014	Scheibe			
141	1	299647	Choke shaft			
141	1	299647	Choke shaft	281707-0127		
141	1	390684	Welle			
141	1	390684	Welle	281707-0142		
142	1	299740	Nozzle			
147	1	231323	Nozzle			
171	1	231532	Mutter			
186	1	67218	Anschluss	281707-0127		
187	1	393815	Fuel line			
198	1	293934	Shut-off valve	281707-0142		
199	1	399949	Anschlußkontakt	281707-0142		
216	1	261610	Choke link	281707-0142		
224	1	94018	Schraube			
240	1	298090	Treibstofffilter			
240	1	298090	Treibstofffilter	281707-0142		
240	1	394358	Fuelfilter			



121 CARBURETOR OVERHAUL KIT




861 PUMP REPAIR KIT




Carburettor

Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
240	1	394358	Fuelfilter	281707-0127		
257	1	93543	Schraube	281707-0127		
309	1	490420	Starting motor			
310	2	94004	Bolzen			
311	4	395538	Brush			
333	1	398811	Armature group			
334	2	93381	Schraube			
367	1	93380	Schraube	281707-0127		
387	1	390818	Impulse pump	281707-0127		
423	2	93984	Schraube			
445	1	399806	Cartridge			
467	1	212706	Griff			
474	1	392595	Alternator stator			
474	1	392595	Alternator stator	281707-0127		
474	1	393474	Generator			
474	1	393474	Generator	281707-0142		
482	4	93621	Schraube			
510	1	490421	Drive assy			
513	1	398003	Set Kupplung			
528	1	393815	Fuel line	281707-0127		
534	1	94246	Schraube			
534	1	94248	Schraube			
535	1	271962	Element			
537	1	270853	Dichtung			
544	1	391160	Rotor			
549	1	94249	Scheibe			
601	2	93053	Hose clamp			
618	1	261116	Feder	281707-0142		
634	1	270382	Scheibe	281707-0142		
662	1	222311	Steigbügel			
663	2	93572	Schraube			
726	1	392134	Gear ring			
727	1	490324	Deckel			
728	2	93535	Schraube			
783	1	280104	Gear			
801	1	394857	End cap			
802	1	395537	End cap			
803	1	394544	Housing			
851	1	221798	Terminal			
861	1	394462	Reparaturset	281707-0127		
872	1	223700	Deckel			
875	1	490332	Body			
876	1	490467	Drive-Starter kit			
877	1	393456	Anschlußkontakt			
877	1	393456	Anschlußkontakt	281707-0142		
877	1	393537	Anschluss			
877	1	393537	Anschluss	281707-0127		
878	1	393362	Kabelbündel	281707-0142		




121 CARBURETOR OVERHAUL KIT




Carburettor

Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
896	1	94288	Roll pin			
917	1	223271	Handgriff	281707-0142		
987	1	398970	Seal			




Cylinder

Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
1	1	490450	Set Zylinder			
2	1	261623	Lager			
3	1	391086	Seal			
5	1	491491	Zylinderkopf			
7	1	271866	Dichtung			
8	1	391406	Ventil			
8	1	391406	Ventil	281707-0142		
8	1	394217	Ventil			
8	1	394217	Ventil	281707-0127		
9	1	27803	Dichtung			
10	2	93394	Schraube			
11	1	280100	Rohr			
12	1	271916	Dichtung			
13	9	93723	Schraube			
15	1	91084	Oil plug			
16	1	490466	Motorwelle			
18	1	490452	Oil sump			
20	1	291675	Dichtring			
22	8	94305	Schraube			
23	1	399917	Schwungrad			
24	1	222698	Schlüssel			
25	1	394661	Set Kolben			
26	1	394665	Ring set			
27	2	260924	Lock			
28	1	299691	Kolbenbolzen			
29	1	490348	Verbindungsstab			
31	1	222299	Lock			
32	2	92909	Schraube			
33	1	262246	Auslassventil			
34	1	262247	Ansaugventil			
35	1	65906	Valve spring-intake			
36	1	26828	Valve spring-exhaust			
37	1	223752	Deckel			
40	1	221596	Sperrung			
41	1	292260	Rotocoil			
42	2	93630	Retainer			
45	2	262248	Valve tappet			
46	1	212897	Nockenwelle			
75	1	220865	Scheibe			
78	3	93805	Schraube			
188	2	93535	Schraube			
201	1	262348	Governor link			
209	1	260871	Feder			
219	1	490815	Oil slinger gear			
222	1	390746	Governor plate			
222	1	390746	Governor plate	281707-0127		
222	1	491594	Governor plate			
222	1	491594	Governor plate	281707-0142		



Cylinder

Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
225	1	231058	Governor crank			
227	1	490927	Hebel			
230	1	222450	Scheibe			
232	1	260584	Feder			
265	1	221535	Clamp			
284	1	93804	Schraube			
304	1	490689	Blower Housing			
304	1	490689	Blower Housing	281707-0142		
304	1	490733	Blower housing			
304	1	490733	Blower housing	281707-0127		
305	4	93158	Schraube			
306	1	223715	Shield			
307	1	93163	Schraube			
308	1	491490	Deckel			
332	1	92284	Mutter			
337	1	1111-9028-02	Spark Plug (J19Lm)			
346	2	93705	Schraube			
353	2	92791	Scheibe			
354	2	90576	Mutter			
356	1	398808	Ground wire			
358	1	490525	Dichtungssatz	Delarna märkta S		
363	1	19203	Abzieher	Tillbehör/Accessory		
383	1	1111-9029-01	Spark Plug Wrench (19 Mm-21 Mm)	Tillbehör/Accessory		
422	1	223721	Clamp			
455	1	222561	Cup			
468	1	223713	Screen			
520	1	93722	Kupplungstück	281707-0127		
523	1	490327	Oil dipstick			
524	1	68838	Seal			
525	1	280741	Rohr			
552	1	231055	Büchse			
562	1	92613	Schraube			
592	1	231082	Mutter			
614	1	93306	Split			
615	1	93307	Retainer			
621	1	396847	Stoppschalter	281707-0142		
635	1	66538	Spark plug elbow			
657	1	93496	Schraube			
663	2	93572	Schraube			
741	1	262135	Gear			
757	1	212359	Link			
758	1	399891	Counterweight			
759	1	298909	Kolbenbolzen			
761	2	93875	Schraube			
842	1	270920	Seal			
847	1	490474	Oil filler group			
869	1	261463	Valve seat			
870	1	210940	Valve seat			



ATIGA
292
SPARE PARTS

358 GASKET SET

Cylinder

Bild Nr.	Anzahl	Teilenummer	Beschreibung	Hinweis	Von	Bis
871	1	231218	Valve guide-intake			
871	1	261961	Valve guide-exhaust			
883	1	270917	Dichtung	281707-0127		
985	1	398525	Insulator			
1005	1	280687	Lüfter			
1006	1	223726	Fan retainer			
1007	1	231531	Entfernungsstück			
1020	1	262243	Eccentric			
1021	1	94160	Bolzen			