



Section: 1236G-1648H TRM107-TRH107 CHASSIS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	8111	8131				
	8119	8138				
1	1	1	1132-0904-01	Seat		
3		1	1132-0799-01	Plug		
4	2	2	9899-3622-16	Screw		
5	1	1	1132-0851-01	Pivot bracket		
6	2	2	9699-0029-02	Flat washer		
7	2	2	1132-0134-01	Knob		
8	1	1	1132-0789-01	Rod		
9	1	1	1132-0788-01	Seat support		
10	2	2	1132-0742-01	Screw		
11	1	1	1132-0805-01	Rear fender		
12	2	2	1132-0049-01	Nylon washer		
17	15	15	9727-3641-22	Nut		
20	1	1	1132-0235-01	Running board suppo		
21	1	1	1132-0515-01	Running board-R.H.		
22	1	1	1132-0514-01	Running board-L.H.		
23		1	1132-0195-01	Foot pad-R.H.		
23	1		1132-0870-01	Foot pad-R.H.		
24	1		1132-0872-01	Foot pad-L.H.		
24		1	1132-0797-01	Foot pad-L.H.		
25	9	9	1132-0691-01	Screw		
26	1		1132-0871-01	Center foot pad		
26		1	1132-0820-01	Center foot pad		
28	2	2	1811-0202-01	Washer		
29	2	2	1132-0655-01	Spacer plate		
30	4	4	9988-3516-16	Screw		
31	6	6	1132-0339-01	Retaining ring		
32	2	2	1132-0187-01	Hinge link		
33	2	2	1132-0895-01	Hinge strap		
34	2	2	1132-0551-01	Grille support		
35	8	8	9743-3521-32	Nut		
36	2	2	1132-0186-01	Hinge link		
37	12	12	1132-0690-01	Screw		
38	12	12	9727-3541-22	Nut		
39	2	2	1132-0188-01	Grille cap		
40	2	2	9988-3525-16	Screw		
41	1		1132-0189-01	Grille		
41		1	1132-0823-01	Grille		
42		4	1132-0650-01	Side cover guide		
42	4		1132-0214-01	Side cover guide		
43	8		1132-0035-01	Pop rivet		
43		8	1132-0858-01	Pop rivet		
44	1	1	1132-0212-01	Side cover-R.H.		
44	1	1	1132-0213-01	Side cover-L.H.		
45	2		1132-0248-01	Sealing block		
46	4	4	1811-0138-01	Screw		
47	2	2	1132-0109-01	Rubber latch		
48	2	2	1132-0108-01	Clip		
49	2	2	1811-0191-01	Nut		
50	1	1	1132-0250-01	Sealing strip		
51	2	2	1132-0783-01	Spring		
52	1	1	1132-0246-01	Hood		
54	2	2	1132-0624-01	Flat washer		
55	4	4	9699-0026-02	Flat washer		
56	1	1	1132-0574-01	Instrument panel		
58		2	1132-0716-01	Cap		
58	2		1132-0863-01	Cap		
61	4	4	1132-0199-01	Angle bracket		
62	2	2	1132-0661-01	Seal strip		
63	2	2	1132-0695-01	Nut		
64	4	4	1132-0800-01	Flange bearing		
65	2	2	1811-0151-01	Retainer ring		
67	2	2	9899-3622-16	Screw		
68	2	2	1132-0693-01	Screw		