



Section: 1648H-TRM107-TRH107 ELECTRICAL SYSTEM

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	8119					
	8131					
	8138					
2	1	1132-0829-01	Battery cable (+)			
3	4	9727-3541-22	Nut			
4	1	1132-0237-01	Light support			
5	2	1132-0103-01	Headlight			
6	1	1132-0681-01	Diode			
8	3	1811-0350-01	Cableholder			
9	1	1132-0830-01	Battery cable (-)			
10	1	1132-0868-01	Lense			
11	1	1132-0876-01	Hour meter kit			
12	2	9795-3531-02	Nut			
13	2	9699-0026-02	Flat washer			
14	3	9743-3521-32	Nut			
15	2	1132-0727-01	J-bolt			
16	4	1811-0138-01	Screw			
17	4	1811-0191-01	Nut			
18	1	1132-0729-01	Battery			
19	1	1132-0532-01	Solenoid			
20	5	1132-0489-01	Screw			
21	2	1132-0238-01	Retainer			
22	1	9795-3631-02	Nut			
23	1	1132-0358-01	Grommet			
24	1	1132-0078-01	Starter cable			
25	1	1132-0529-01	Console wire harnes			
26	3	1132-0336-01	J-clip			
27	1	1132-0859-01	Rubber pad			
28	2	9683-0025-02	Lock washer			
29	2	9988-3516-16	Screw			
30	1	1132-0831-01	Interlock harness			
31	1	1132-0749-01	Pto switch			
32	1	1132-0753-01	Light switch			
33	1	1132-0653-01	Ignition switch			
34	2	1134-2848-01	Ignition key			
35	1	1132-0550-01	Lights harness			
36	1	1132-0801-01	Cover			
37	3	1132-0899-01	Bulb			
38	1	1132-0034-01	Screw			
39	1	1132-0211-01	Fuse			
40	1	1132-0544-01	Grommet			
41	1	1132-0720-01	Switch			
43	2	9863-3516-16	Screw			
44	1	1132-0725-01	Switch			
45	1	1132-0784-01	Grommet			
46	1	1132-0756-01	Grommet			
99	1	1132-0873-01	Voltage sensor plug		Ej ill/not ill.	