



**STIGA**  
213B  
SPARE PARTS

## Section: TURBO 46-460S WHEEL SUSPENSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
		6425 6516				
	6216	6437 6535				
1	1	1	1	1111-2146-01	Front axle	
2	2	2	2	1111-1067-02	.Bushing	
3	2	2	2	1111-1706-01	Clamp	
4	4	4	4	9943-0510-16	Screw	
5	1	1	1	1111-2148-01	Rear axle	
6	2	2	2	1111-1072-01	Clamp rear	
8	1	1	1	1111-1074-01	Spring-height adjus	
9	1	1	1	1111-1357-02	Lever	
10	1	1	1	9997-0612-16	Screw	
11	1	1	1	9739-0631-22	Nut	
12	1	1	1	1111-1068-01	Tension rod	
13	2	2	2	9675-0008-02	Locking washer	
15	4	4	4	9997-0612-16	Screw	
16	4			1111-1456-01	Washer	
16		4	4	9699-0037-02	Washer	
17	2	4	2	1111-1180-03	Wheel cover	
18	4	4	4	1111-1138-01	Spring	
19	2		2	1111-1180-04	Wheel cover	
20	4	4	4	1111-2665-01	Wheel assy	
21	1	1	1	1111-9047-01	.Ball bearing kit	
21A	2	2	2	1111-1184-01	. .Bearing cone	
22	4	4	4	9699-0100-02	Washer	
23	4	4	4	1111-1181-01	Hub cap	
24	2	2	2	1111-1638-01	Washer	
25	2	2	2	1111-1016-01	Locking handle	
26	2	2	2	9595-0235-00	Locating pin	
27	2	2	2	1111-1087-02	Tensioning rod	
28	2	2	2	9739-0831-22	Nut	
29	4	4	4	9942-0816-16	Screw	
30	2	2	2	1111-1078-01	Handle attachment	
31	2	2	2	1111-1019-01	Adjusting plate	
32	2	2	2	9997-0816-16	Screw	
33	2	2	2	9747-0831-02	Lock nut	
34	2	2	2	1111-0035-01	.Locking knob	
34	1	1	1	1111-9030-02	Handle bolt kit	
35	2	2	2	1111-0178-00	.Reinforcement	
36	2	2	2	9699-0025-02	.Washer	
37	2	2	2	9899-3551-12	.Screw	
38	1	1	1	1111-2018-01	Cable holder	
39	1	1	1	9836-9216-12	Screw	
40	1	1	1	1111-1076-01	Handle-lower part	
41	1	1	1	1111-2003-01	Handlebar	
44	1			1111-1414-01	Side protection-R.H	
44	1			1111-1413-01	Side protection-L.H	
48			1	1111-2367-03	Gas control	6535
48		1		1111-2027-02	Gas control	6437
48	1		1	1111-2365-02	Gas control	6216, 6516
48		1		1111-2365-05	Gas control	6425
71	1		1	1111-9055-01	Gear wheel kit	
72	2		2	9594-0009-00	.Locating pin	
73	2		2	1111-1456-01	Washer	
75	1		1	1111-2010-01	Attachment plate	
76	1		1	9849-7909-16	Screw	
77	1		1	1111-1197-02	Clutch cable	
78	1		1	9739-0631-22	Nut	
79	1		1	1482-0160-01	Spring	
80	1		1	1111-1998-01	Control handle	
81	2	2	2	9948-0645-16	Screw	
82	2	2	2	9799-0631-02	Nut	