



Section: 420T HANDLE CONTROLS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1812					
1	2	1812-0513-01	Retainer			
2	1	1812-0934-01	Clutch handle rod			
3	4	9988-3519-16	Screw			
4	2	1812-0946-01	Cable pivot plate			
5	1	1812-0933-01	Clutch handle-RH			
6	1	1812-0932-01	Clutch handle-LH			
7	4	9743-3521-32	Nut			
8	1	1812-0396-01	Retainer			
9	5	9699-0029-02	Flat washer			
10	1	1812-0832-01	Crank handle			
11	1	1812-0256-02	Chute crank			
12	1	1812-0203-01	Grommet			
13	1	1812-0394-01	Eyebolt			
14	2	9743-3721-32	Nut			
15	2	9988-3670-12	Screw			
16	1	1812-0249-01	Control wire			
17	2	9743-3521-32	Nut			
18	2	1812-0254-01	Spring			
19	5	9795-3631-02	Nut			
20	1	9683-0035-02	Lock washer			
21	1	1812-0844-01	Handle-lower			
22	2	1812-0941-01	Plastic stop			
23	4	9988-3619-16	Screw			
24	1	1812-0646-01	Plastic cap			
25	1	9599-0054-02	Cotter pin			
26	2	9683-0055-02	Lock washer			
27	2	9743-5421-32	Nut			
28	1	1812-0675-01	Rod chute control			
29	9	9683-0030-02	Lock washer			
30	1	1812-0673-01	Bracket chute rotat			
31	2	9899-3622-16	Screw			
32	1	1812-0910-01	Bracket			
33	1	9988-3645-16	Screw			
34	5	9699-0028-02	Flat washer			
35	1	1812-0817-01	Auger cable			
36	1	1812-0879-01	Handle-upper			