



**STIGA**  
316A  
SPARE PARTS

## Section: 420T TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1812					
1	5	1812-1118-01	Screw			
2	1	1812-0350-01	Engine pulley			
3	1	1812-0718-01	Key			
4	2	9988-3745-12	Screw			
5	1	1812-0926-01	Idler pulley			
6	1	9699-0029-02	Flat washer			
7	1	1812-0899-01	Idler arm			
8	4	9743-3721-32	Nut			
9	1	1812-0935-01	Belt-traction drive			
10	1	1812-0954-01	Key			
11	2	9987-5132-16	Screw			
12	7	9683-0030-02	Lock washer			
13	2	9699-0028-02	Flat washer			
14	1	1812-0920-01	Belt guide-L.H.			
15	2	1812-0730-01	Spacer			
16	1	1812-0845-01	Pulley			
17	1	1812-0921-01	Belt guide-R.H.			
18	2	1812-0917-01	Spring			
19	1	1812-1115-01	Belt cover			
20	2	9699-0026-02	Flat washer			
21	2	1812-0384-01	Screw			
22	2	1812-0930-01	Roll pin			
23	1	1812-0880-01	Brake arm			
25	4	9988-3632-12	Screw			
26	1	1812-0931-01	Auger clutch lever			
29	2	1812-0855-01	Needle bearing			
30	1	1812-0854-01	Needle bearing			
31	4	1812-0361-01	Washer			
32	1	1812-0915-01	Bushing			
33	1	1812-0927-01	Motor mount frame			
34	4	9699-0115-02	Washer			
35	1	9599-0054-02	Cotter pin			
36	1	1812-0928-01	Shoulder bolt			
37	1	1812-0936-01	Belt-auger drive			
38	1	1812-0747-01	Thrust washer			
39	1	1812-0307-01	Key			
40	1	1812-0904-01	Auger pulley			
41	9	9988-3516-16	Screw			
42	1	1812-0940-01	Shoulder bolt			
43	1	9652-0015-04	Retaining ring			
44	2	1812-0865-01	Thrust washer			
45	2	1812-0849-01	Retaining ring			
46	1	1812-0859-01	Hand grip			
46	2	9795-3631-02	Nut			
47	1	1812-0902-01	Shift lever			
48	2	1812-0385-01	Screw			
50	1	1812-0900-01	Shift bracket			
52	1	1812-0843-01	Shifter ring			
53	1	1812-0882-01	Shift yoke			
54	4	9988-3519-16	Screw			
55	2	1812-0384-01	Screw			
56	1	1812-0450-01	Bearing			
57	1	1812-0370-01	Hub			
58	1	1812-9002-01	Friction disc			
59	9	9683-0025-02	Lock washer			
60	11	9795-3531-02	Nut			
61	1	1812-0951-01	Disc drive			
62	1	1812-0858-01	Idler pulley			
64	1	1812-0838-01	Clutch lever			
65	2	1812-0848-01	Retaining ring			
66	2	9699-0028-02	Flat washer			
67	1	1812-1113-01	Drive lever			
68	1	1812-0839-01	Linkage			
69	1	9988-3651-12	Screw			
70	1	1812-0929-01	Shoulder bolt			
71	4	1812-0842-01	Bearing			

## Section: 420T TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1812					
72	2	1812-0391-01	Pin			
73	1	1812-0903-01	Hex shaft			
74	1	1812-0914-01	Return spring			
75	1	1812-0918-01	Jackshaft & sprocke			
76	1	1812-0841-01	Sprocket & axle			
77	1	1812-0924-01	Chain			
77A	1	9589-0501-00	Chain fastener		För d:o	
78	2	1812-0846-01	Bearing			
79	1	1812-0923-01	Chain			
79A	1	9589-0501-00	Chain fastener		För d:o	
80	1	1812-0851-01	Bottom panel			
81	4	1812-0959-01	Bolt			
82	2	1812-0402-01	Retaining ring			
83	4	1812-0387-01	Screw			
84	1	1812-0942-01	Spacer			
85	2	9743-3521-32	Nut			

test