



Section: TRANSMISSION TORNADO 535-540-540E

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
0	1	1111-2030-01	Transmission assy			
1	1	1111-2042-01	.Drive shaft			
2	2	9404-0080-00	.Sealing ring			
3	1	1111-1655-01	.Gear cover			
4	3	9943-0516-16	.Screw			
5	1	1111-1692-01	.Cable holder			
13	2	9548-0015-00	.Bronze bearing			
14	1	1111-2029-01	.Spacer			
15	1	1111-2051-01	.Pin			
16	1	1111-1894-01	.Sliding collar			
17	2	9695-0004-00	.Washer			
20	1	1111-1914-01	Worm gear kit			
21	1	9549-0043-00	.Ball bearing			
22	1	9548-0022-00	.Bearing			
23	1	1111-1891-01	.Gear housing			
24	1	1111-1663-01	.Spring holder			
25	2	9937-0510-19	.Screw			
27	1	9404-0021-00	.O-ring			
28	1	1111-2048-01	.Engagement lever			
29	1	1111-1662-01	.Clutch lever			
30	1	9699-0024-02	.Flat washer			
31	1	9747-0531-02	.Nut			
35	1	1111-1843-01	Special grease			
36	1	9600-0007-00	.Key			
37	1	9695-0004-00	.Washer			
38	1	1111-1895-01	.Belt pulley			
39	1	9699-0060-02	.Flat washer			
40	1	9997-0612-16	.Screw			

TEST