



STIGA
136D
SPARE PARTS

Section: 828, 1232 DRIVE TRAIN

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1817	1822				
9	1	1	9699-0038-02		Flat washer	
13	13	13	9795-3631-02		Nut	
14	14	14	9683-0030-02		Lock washer	
15	3	3	9699-0028-02		Flat washer	
27	5	5	9988-3619-16		Screw	
48	1	1	9699-0029-02		Flat washer	
59	1	1	1812-0430-01		Drive disc	
60	2	2	1812-0284-01		Washer	
61	1	1	1812-0285-01		Needle bearing	
62	2	2	1812-0287-01		Bearing	
63	1	1	1812-0288-01		Spindle housing	
64	1	1	1812-0324-01		Grease fitting	
65	1	1	1812-0281-01		Gasket	
66	1	1	1812-0418-01		Spindle assy	
67	2	2	1812-0282-01		Washer	
68	1	1	1812-0286-01		Retainer ring	
69	4	4	9899-3622-16		Screw	
70	6	6	9988-3613-16		Screw	
71	2	2	1812-0241-01		Bearing	
72	2	2	1812-0291-01		Bearing	
73	1	1	1812-0429-01		Plate	
74	1	1	1812-0320-01		Rod	
75	1	1	9599-0054-02		Cotter pin	
76	1	1	1812-0293-01		Retaining ring	
77	1	1	1812-0583-01		Chain	
78	1	1	1812-0586-01		Worm gear	
79	2	2	1812-0719-01		Bearing clutch	
80	2	2	1812-0280-01		Grease fitting	
81	1	1	1812-0625-01		Shaft	
82	1	1	1812-0393-01		Key	
83	1	1	1812-0290-01		Washer	
84	1	1	1812-0582-01		Hub	
85	1	1	1812-9003-01		Friction disc	
86	5	5	9677-0009-02		Lock washer	
87	1	1	9683-0035-02		Lock washer	
88	1	1	9794-5231-02		Nut	
89	1	1	1812-0521-01		Shaft	
90	1	1	1812-0525-01		Retaining ring	
91	1	1	1812-0619-01		Shaft	
92	1	1	1812-0571-01		Chain	
93	2	2	1812-0567-01		Retaining ring	
94	1	1	1812-0408-01		Clik pin	
95	2	2	1812-1127-01		Wheel	4.80 x 4.00
95A	1	1	1812-0636-01		Snow chains	
96	2	2	1812-0407-01		Washer	
97	2	2	1812-0601-01		Axle bracket	
98	4	4	9899-3622-16		Screw	
99	1	1	9988-3538-12		Screw	
100	1	1	9743-3521-32		Nut	
102	1	1	1812-0438-01		Shaft	
103	1	1	1812-0330-01		Spring	
104	2	2	1812-0294-01		Bushing	
105	2	2	1812-0649-01		Cap retainer	
106	1	1	1812-0660-01		Spring washer	
111	4	4	1812-1073-01		Bushing	