



Section: TURBO 420S-420 EL TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2211					
	2511					
	2537	2972				
0	1	1	1111-2387-01		Right angle drive	
1	1	1	1111-2295-01		.Gear house bracket	
2	1	1	1111-2226-01		.Gear housing assy.	
3	1	1	1111-1852-01		.Cover	
4	8	8	9943-0512-16		.Screw	
5	1	1	1111-2067-01		.Cable bracket	
7	1	1	1111-2383-01		Plate	
8	1	1	9747-0531-02		.Nut	
9	1	1	9699-0024-02		.Flat washer	
10	1	1	1111-2066-01		.Clutch lever	
11	1	1	9404-0021-00		.O-ring	
12	1	1	1111-2048-01		.Engagement lever	
15	1	1	9997-0612-16		.Screw	
16	1	1	9699-0060-02		.Flat washer	
17	1	1	1111-1850-01		.Belt pulley	
18	1	1	9600-0117-00		.Key	
19	1	1	9549-0004-00		.Ball bearing	
20	1	1	1111-1847-01		.Shaft & gear, inpu	
23	2	2	9548-0003-00		.Flange bearing	
24	1	1	1111-2249-01		.Washer	
26	1	1	1111-2166-02		.Clutch half, input	
27	1	1	1111-2390-01		.Clutch spring	
28	1	1	1111-2184-01		.Clutch sleeve w.sp	
29	1	1	1111-2218-01		.Clutch half, outpu	
30	1	1	9594-0045-00		.Locating pin	
33	1	1	9404-0081-00		.Seal ring	
34	1	1	1111-2217-01		.Shaft	
35	1	1	9589-0003-04		Chain	
37	1		1111-1992-01		Chain guard	
38	1		9943-0510-16		Screw	
39	1	1	1111-2229-01		Chain tensioner	
40	3	3	9836-9516-12		Screw	
42	1	1	1111-9056-01		V-belt	
43	1		1111-1993-01		Clutch cable	
43		1	1111-2389-01		Clutch cable	
44	1	1	1111-2034-01		Spring	
45	1	1	1111-2224-01		Rear axle	
46	1	1	1111-1759-01		Cover plate	
47	1	1	1111-1966-01		Cover plate	
48	4	4	9943-0510-16		Screw	
49	4	4	9799-0531-02		Nut	
50	2	2	9695-0004-00		Washer	
52	4	4	9652-0010-04		Snap ring	
53	1	1	1111-1755-01		Gear wheel	
54	2	2	1111-1864-01		Key	
55	2	2	1111-2068-01		Spring	
56	1	1	1111-1863-01		Drive shaft	
57	2	2	1111-1756-01		Bushing	
59	1	1	1111-1963-01		Sprocket	
60	1	1	9594-0047-00		Locating pin	
62	1	1	1111-1755-02		Gear wheel	