



Section: LAWN SWEEPER 38" ART.NO 13-1941-11 CHASSIS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1941					
0		..13-1941-11	Lawn sweeper assy			
8	2	9988-3619-16	Screw			
9	30	9743-3621-32	Nut			
30	2	9699-0028-01	Flat washer			
41	4	9988-3625-16	Screw			
42	4	9988-3638-12	Screw			
46	2	1319-0337-01	Rectangle tube plug			
58	2	1319-0352-01	Caster sleeve			
59	2	1319-0324-01	Caster wheel			
60	2	9699-0038-02	Flat washer			
61	1	1319-0320-01	Caster tube-R.H.			
61	1	1319-0321-01	Caster tube-L.H.			
62	2	9743-3921-32	Nut			
63	16	9988-3632-12	Screw			
64	2	1319-0323-01	Caster gusset plate			
65	2	1319-0325-01	Hamper pivot sleeve			
66	1	1319-0319-01	Hamper support u tu			
67	6	9743-3721-32	Nut			
68	2	9988-3932-16	Screw			
69	2	1319-0348-01	Caster yoke assy			
70	2	1319-0280-00	Screw			
71	2	1319-0322-01	Caster tube conn.pl			
72	2	9988-3725-16	Screw			
73	2	9699-0029-02	Flat washer			
74	2	1319-0295-01	Spacer			
75	1	1319-0346-01	Mounting bracket-R.			
75	1	1319-0347-01	Mounting bracket-L.			
76	1	1319-0302-01	Tongue brace			
77	1	9988-3738-12	Screw			
80	1	1319-0351-01	Wind apron assy			
81	2	1319-0335-01	Tube cushion			
82	1	1319-0332-01	Tie rod			
83	1	1319-0326-01	Top-front hamper tu			
84	2	1319-0327-01	Lower-front hamp.tu			
85	2	1319-0123-00	Screw			
86	1	1319-0328-01	Lower-rear hamp.tub			
87	1	1319-0350-01	Hamper assy			
88	2	9988-3738-12	Screw			
89	1	1319-0344-01	Hamper pivot bracke			
89	1	1319-0345-01	Hamper pivot bracke			
90	1	1319-0329-01	Rear-corner hamp.tu			
90	1	1319-0330-01	Rear-corner hamp.tu			
91	1	1319-0331-01	Top-rear hamper u t			