



## Section: DINO

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
		1213					
		1237					
		1413					
1	1	1	1111-9025-01	Blade disc assy			
2	1	1	1111-9022-01	.Dino-blade kit			
4	1	1	1111-0020-00	.Washer			
5			1111-9502-01	Blade			
6	1	1	9696-0011-01	.Washer			
7	1	1	9987-5232-16	.Bolt			
10			1111-9023-02	Blade holder			
10	1	1	1111-9023-01	Blade holder			
11	1	1	9600-0014-00	.Key			
17	4		1111-2656-01	Wheel			
18	2	2	1111-1589-02	.Height adj.spring-			
19	2	2	1111-1589-01	.Height adj.spring-			
20	1	1	1111-9042-01	.Wheel lock kit			
20	4	4	9675-0017-02	..Lock washer			
21	4		9699-0069-02	Flat washer			
22	2	2	1111-1590-01	Wheel axle			
23	4	4	1111-1335-01	Hub cap			
26	3	3	9997-0830-16	Screw		30 mm	
27	3	3	9683-0030-02	Lock washer			
28	3	3	9799-0831-02	Nut			
31	1	1	1111-3017-01	Handlebar clamp			
32	1	1	1111-1532-01	Pivot rod			
33	2	2	9670-0203-00	Lock washer			
34	2	2	1111-0035-01	.Locking knob			
36	2	2	9699-0025-02	.Washer			
37	2	2	9899-3545-12	.Screw			
38	1	1	1111-2018-01	Cable holder			
39	1	1	9836-9216-12	Screw			
40	1	1	1111-1702-01	Handlebar lower par			
41	1	1	1111-2005-01	Handlebar upper par			
44	1	1	1111-1529-02	Side guard-yellow			
45	2	2	1111-1593-01	Washer			
46			1111-1645-02	Chassis-yellow			
46	1	1	1111-1644-02	Chassis-yellow			
48		1	1111-2367-04	Gas control			
48	1		1111-2366-01	Gas control			
50	2	2	9747-0631-02	Lock nut			
51	2	2	9948-0645-16	Screw			
52			1111-1651-01	Ejection shield			
53		2	9403-0040-00	Rubber plug			
54		1	1111-1648-01	Shaft			
55		1	1111-1649-01	Spring			
56		2	9652-0005-04	Circlip			
57		4	1111-2784-01	Wheel assy			
58		1	1111-9047-01	.Ball bearing kit			
59		2	1111-1184-01	..Bearing cone			
60		4	1111-1138-01	Spring			
63			1111-0931-02	Mounting bar			
64			1111-0932-01	Mounting bar			
65			1111-0933-02	Rubber guard			
66			1151-0300-01	Rivet			
67	1	1	1111-2375-01	Spring			
99	1		1111-2233-01	Decal kit			