



Section: PARK 12HST-16HST DRIVE PEDAL CRUISE CONTROL

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1358					
	1458					
1	1	1134-2754-01	Slip protection			
2	1	1134-2739-01	Pedal			
3	1	1134-2849-02	Rubber hose			
4	2	1134-2780-01	Bearing			
5	2	1134-2700-01	Bracket			
6	2	9959-0820-16	Screw			
7	9	9739-0831-22	Nut			
8	1	1134-2703-01	Lever			
12	1	1134-2766-01	Speed control wire			
14	2	9595-0235-00	Locating pin			
17	1	1134-2030-04	Clutch cable			
18	1	1134-2991-01	Eye bolt			
20	1	9747-0531-02	Nut			
23	1	1134-3450-01	Brake pedal (L. H.)			
24	1	1134-0269-00	Pedal rubber			
35	1	1134-0266-00	Attaching clamp			
37	3	9997-0520-16	Screw			
45	1	1134-2721-01	Control rod			
46	1	1134-2786-01	Plastic knob			
47	1	1134-2789-01	Bracket			
48	1	1134-2790-01	Rubber grommet			
50	3	9959-0816-16	Screw			
51	1	9675-0012-02	Locking washer			
52	1	9570-0001-00	Elbow link			
56	1	1134-2758-01	Spacer			
74	1	1134-2707-01	Arm			
79	1	9699-0090-02	Flat washer			
80	1	9959-0830-16	Screw			
81	1	9997-0870-16	Screw			
103	1	9997-0835-12	Screw			
108	6	9739-0531-22	Nut			
113	1	1134-0267-00	Clamp plate			
117	1	1134-2859-01	Magneto assy			
118	1	1134-2858-01	Spring			
119	1	1134-2862-01	Lever			
121	1	1134-2866-02	Plate			
122	1	1134-2857-01	Switch			
123	1	1134-3275-01	Harness			
124	1	1134-2871-01	Relay			
125	1	1134-2902-01	Symbol plate-green			
126	1	1134-2933-01	Switch console			
127	1	1134-2932-01	Switch			
128	2	9849-7819-16	Screw			