



Section: DOZER BLADE ART.NO 25-8983-11 WHEEL WEIGHTS ART.NO 25-8987-

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
		8983	8987			
0		..25-8983-11	Blade assy			
1	2	9988-3745-12	Screw			
2	1	1133-0161-01	Brace-R.H.			
3	1	1133-0162-01	Brace-L.H.			
4	4	9699-0028-02	Flat washer			
5	4	1133-0307-01	Spacer			
6	10	9988-3719-16	Screw			
7	1	1133-0306-01	Bracket-R.H.			
8	1	1133-0305-01	Bracket-L.H.			
9	17	9743-3721-32	Nut			
10	1	1133-0304-01	Rear frame			
11	8	9988-3725-16	Screw			
12	8	1133-0160-01	Spacer			
13	1	1133-0158-01	Parallel bar upper			
14	1	1133-0159-01	Parallel bar lower			
15	1	9988-3764-12	Screw			
16	1	1133-0126-01	Frame			
17	1	1133-0098-01	Index bar			
18	1	1133-0072-01	Tension spring			
19	5	9599-0070-02	Split pin			
20	4	9699-0035-02	Flat washer			
21	1	1133-0157-01	Index link			
22	1	1133-0101-01	Pin			
23	2	1133-0099-01	Spring			
24	1	1133-0156-01	Quadrant			
25	1	1133-0094-01	Blade			
26	4	9899-3625-16	Screw			
27	1	1133-0096-01	Wear strip			
28	2	1133-0050-01	Skid			
29	4	9683-0030-02	Lock washer			
30	4	9795-3631-02	Nut			
31	1	1133-0100-01	Pin			
32	5	1133-0267-01	Carriage bolt			
33	5	9683-0025-02	Lock washer			
34	5	9795-3531-02	Nut			
35	1	1133-0097-01	Pivot link			
36	1	1133-0103-01	Eye bolt			
37	1	9743-3721-32	Nut			
38	1	1133-0095-01	Handle-lower			
39	2	9743-3521-32	Nut			
40	1	1133-0164-01	Strap			
41	1	1133-0163-01	U-bolt			
42	1	1133-0102-01	Extens.handle-upper			
43	1	9988-3638-12	Screw			
44	1	1133-0166-01	Latch			
45	1	1133-0014-01	Grip			
46	1	9743-3621-32	Nut			
A00		..25-8987-11	Wheel weights assy		Ett par/one pair	
A01	2	1133-0113-01	Upstop bolt			
A02	4	9699-0029-02	Flat washer			
A04	2	9683-0035-02	Lock washer			
A05	2	9795-3731-02	Nut			