



Section: PARK SEAT

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
		1258					
	1118	1358	1458				
1	1		1134-2541-01	Seat			
1		1	1134-3286-01	Seat			
1	1		1134-0800-06	Seat			
2	2	2	1134-2961-01	Seat adapter			
3	2	2	9898-0820-16	Screw			
4	4	4	9988-3616-16	Screw			
5	4	4	9675-0017-02	Lock washer			
6	1	1	1134-3618-01	Seat bracket-R.H.			
10	1	1	1134-3618-02	Seat bracket-L.H.			
11	2	2	9699-0062-02	Flat washer			
12	2	2	1134-1711-01	Knob			
13	1	1	1134-1652-01	Spring shackle			
14	1	1	1134-0050-00	Seat rod			
18	2	2	1134-1650-01	Tie bar			
20	1	1	1134-0493-00	Spring nut			
21	1	1	1134-0015-00	Seat spring			
28	1	1	1134-2846-01	Tube			
30	1	1	1134-1883-01	Axle			
31	1	1	1134-0022-00	Control rod			
32	2	2	9672-0004-02	Lock washer			
36	1	1	1134-2163-01	Rod			
37	1	1	1134-2166-01	Spacer			
48	1	1	1134-2454-01	Shaft			
49	2	2	9672-0006-02	Lock washer			
50	1	1	1134-2847-01	Shaft			
98		1	..13-1962-11	Arm rest		Tillbehör/Accessory	
99		4	9988-3713-16	.Screw			

test