



## Section: TORNADO REAR WHEEL SUSPENSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	4215					
	4218 4719					
14	2	1111-2815-06	Hub cap-grey		4215-82	
15	2	9699-0037-02	Washer			
16	2	1111-2183-01	Spring			
17	2	1111-2782-01	Wheel cover			
18	2	1111-2665-01	Wheel assy			
19	1	1111-9047-01	.Ball bearing kit			
20	2	1111-1184-01	..Bearing cone			
21	2	9699-0100-02	Washer			
22	2	9997-0612-16	Screw			
23	2	1111-2664-01	Hub cap		4215-12,4218-12	
24	2	1111-2676-01	Wheel cup		4215-12,4218-12	
25	2	1111-2077-01	Hub cap			
26	2	1111-2247-01	Wheel w/o bearing			
27	4	9549-0001-00	Ball bearing			
28	2	1111-2141-01	Cover plate			
30	2	9943-0610-16	Screw			
31	2	1111-2653-01	Wheel cleaner			
32	10	9836-9516-12	Screw			
33	2	1111-2741-01	Clamp			
34	1	1111-2586-01	Rear axle			
35	1	1111-1074-01	Spring-height adjus			
36	1	9997-0816-16	Screw			
37	2	9675-0011-00	Starlock			
38	1	9739-0831-22	Nut			
39	1	1111-2597-01	Tension rod			
40	1	1111-2593-01	Lever			
43	2	9699-0025-02	Washer			
65	1	1111-2578-01	Height adj. quadrant			
66	2	9848-8013-16	Screw			
67	1	9799-0831-02	Nut			
68	1	9403-0036-70	Lever knob			
69	1	1111-2577-01	Baffle			
70	3	9836-9512-12	Screw			