




13-1916-13



13-1958-12



13-1966-13



## Section: DOZER BLADE-PARK RUBBER BLADE KIT EL.ADJUSTMENT KIT

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
		1916 1958 1966				
0		..13-1916-13	Dozer blade assy		Park 120 cm	
A01	1	1319-1528-01	Blade			
A02	1	1319-1607-01	Frame			
A03	1	1319-1530-01	Lift plate			
A04	1	1319-1527-01	Spring			
A05	1	1319-1531-01	Pin			
A06	2	1319-1526-01	Skid			
A07	2	9997-1220-16	Screw			
A08	1	9747-1631-02	Lock nut			
A09	1	1319-1551-01	Screw			
A10	2	9997-1035-16	Screw			
A11	2	9739-1031-22	Nut			
A12	1	9997-0825-16	Screw			
A13	4	9699-0028-02	Flat washer			
A14	1	9747-0831-02	Lock nut			
A15	1	1319-1613-01	Wing screw			
A16	1	1134-3259-01	Wing nut			
B00		..13-1958-12	Rubber blade kit as			
B01	1	1319-1562-01	Rubber blade			
B02	1	1319-1563-01	Mounting plate			
B03	7	9898-0830-16	Screw			
B04	7	9747-0831-02	Lock nut			
C00		..13-1966-13	El.adjustment kit			
C01	1	1134-3461-01	Attachment			
C02	2	9997-1050-16	Screw			
C03	2	9747-1031-02	Lock nut			
C04	2	9699-0037-02	Washer			
C05	2	9599-0083-02	Split pin			
C06	1	1134-3460-01	Electric adjuster			
C07	1	1134-3445-01	Lead wire			
C08	1	1134-2849-02	Rubber nose			
C09	1	1134-3352-01	Male terminal			