



Section: PARK 11 ENGINE BRAKE SYSTEM

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1118					
	1158					
	1442					
1	4	9739-0831-22	Nut			
2	3	9997-0835-12	Screw		35 mm	
3	1	9997-0865-12	Screw		65 mm	
4	1	1134-2013-01	Exhaust pipe			
5	2	1134-0345-00	Spacer for silencer			
6	1	1134-0433-00	Muffler gasket			
7	1	1134-2462-01	Lock			
8	2	9988-3632-12	Screw			
9	1	1134-3243-01	Silencer			
10	1	9739-0831-22	Nut			
11	1	9959-0816-16	Screw			
12	1	9578-0011-00	Clamp			
13	1	1134-2212-01	Oil drain pipe assy			
14	1	1134-0995-01	.Plug			
15	1	9404-0020-00	.O-ring			
16	1	1134-0997-01	.Fibre gasket			
17	1	9600-0250-00	Key			
18	1	1134-2733-01	Heat protection			
19	2	9942-0612-16	Screw			
27	1	1134-2045-01	Brake stop			
28	1	9959-0816-16	Screw			
29	1	9739-0831-22	Nut			
37	1	1134-2886-01	Fuel tank			
38	1	1134-2877-02	Fuel tank cap			
39	2	1134-2941-01	Protection strip			
40	1	9997-0812-02	Screw			
41	1	9747-0831-02	Lock nut			
42	1	1134-3223-01	Fuel shut-off			
43	1	1134-2975-02	Fuel hose		L = 145 mm	
44	1	1134-2975-03	Fuel hose		L = 40 mm	
45	3	1134-3499-01	Hose clamp			
46	1	1134-2998-01	Hose clamp			
54	1	1134-1184-02	Bracket			
55	1	1134-2151-01	Stop			
56	1	1131-1497-01	Spring			
57	1	1134-0245-00	Shoulder screw			
58	1	9739-0831-22	Nut			
59	1	1134-3410-02	Brake cable			
60	1	1131-1506-00	Spring			
61	1	1134-3280-01	Spring			
62	1	1134-3403-01	Wire holder			
63	1	1134-2170-02	Brake pedal (R. H.)			
64	1	1134-9024-01	.Bearing			
66	1	1134-0269-00	Pedal rubber			
74	1	1134-1975-11	Gas control			
75	1	9579-0008-00	Cable holder			
76	1	9403-0035-10	Handle			
77	2	9849-8013-16	Screw			