



STIGA
28G
SPARE PARTS

Section: PARK SEAT

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
	1118	1158	1441				
	1442	1358	1443	1458			
1	1	1		1134-2541-01	Seat		
1			1	1134-3286-01	Seat		
1	1			1134-0800-06	Seat		
2	2	2	2	1134-2961-01	Seat adapter		
3	2	2	2	9898-0820-16	Screw		
4	4	4	4	9988-3616-16	Screw		
5	4	4	4	9675-0017-02	Lock washer		
6	1	1	1	1134-3618-01	Seat bracket-R.H.		
10	1	1	1	1134-3618-02	Seat bracket-L.H.		
11	2	2	2	9699-0062-02	Flat washer		
12	2	2	2	1134-1711-01	Knob		
13	1	1	1	1134-1652-01	Spring shackle		
14	1	1	1	1134-0050-00	Seat rod		
18	2	2	2	1134-1650-01	Tie bar		
20	1	1	1	1134-0493-00	Spring nut		
21	1	1	1	1134-0015-00	Seat spring		
28	1	1	1	1134-2846-01	Tube		
30	1	1	1	1134-1883-01	Axle		
31	1	1	1	1134-0022-00	Control rod		
32	2	2	2	9672-0004-02	Lock washer		
36	1	1	1	1134-2163-01	Rod		
37	1	1	1	1134-2166-01	Spacer		
48	1	1	1	1134-2454-01	Shaft		
49	2	2	2	9672-0006-02	Lock washer		
50	1	1	1	1134-2847-01	Shaft		
98			1	..13-1962-11	Arm rest	Tillbehör/Accessory	
99			2	9988-3716-16	.Screw	3/8"	
99			2	9988-3616-16	.Screw	5/16"	

test