



Section: TURBO 480S-480SE ALU 48-48S-48SE TRANSMISSION

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
			5212 5213				
	5216 5219		5217 5218				
1	1	1	1	1111-2808-01		Rear axle	
2	2	2	2	1111-2814-01		Bushing	
3	4	4	4	9947-0616-16		Screw	
4	1	1	1	1111-2798-01		Height adj.quadrant	
5	4	4	4	9838-9522-12		Screw	
6	1	1	1	1111-2816-01		Height adj.lever	
7	1	1	1	1111-2817-01		Lever knob	
8	2	2	2	9946-0616-16		Screw	
9	2			9699-0037-02		Washer	
12	2	2	2	1111-2665-01		Wheel assy	
13	1	1	1	1111-9047-01		.Ball bearing kit	
14	2	2	2	1111-1184-01		. .Bearing cone	
15	2	2	2	9699-0100-02		Washer	
16	2	2	2	9946-0616-16		Screw	
17	2	2	2	1111-2664-01		Hub cap	
18	2	2	2	1111-2676-01		Wheel cup	
20	2	2	2	1111-2183-01		Spring	
21	2			1111-2782-01		Wheel cover	
22		2	2	1111-2561-01		Cover plate	
26		1	1	1111-2915-01		Engine belt pulley	
27		1	1	9910-0612-16		Set screw	
28		1	1	1111-9061-01		V-belt	
29		1	1	1111-3046-01		Transmission	
29A		1	1	1111-3047-01		Belt pulley	E1 ill/not ill.
29B		1	1	9594-0055-00		Locating pin	Ej ill/not ill.
30		1	1	1111-2822-01		Tension spring	
31		2	2	1111-2382-01		Pin	
32		2	2	1111-2827-01		Drive key	
33		2	2	9404-0080-00		Sealing ring	
36		4	4	9695-0004-00		Washer	
37		2	2	1111-2829-01		Lock washer	
38		2	2	1111-3075-01		Pinion-plastic whee	
39		2	2	1111-2830-01		Support washer	
41		2	2	9652-0010-04		Snap ring	
44		1		1111-2852-01		Clutch cable	
45			1	1111-2854-01		Clutch cable	
46		1	1	1111-2851-01		Control handle	
47			1	1111-2554-01		Cable attachment	
48			1	1111-2555-01		Washer	
49			1	9948-0655-16		Screw	
50			1	9747-0631-02		Lock nut	
51	1			1111-2924-01		Shaft	
52	2			9675-0017-02		Lock washer	
53	1	1	1	1111-2794-01		Cover-yellow	