



Section: TURBO 510S WHEEL SUSPENSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	7518					
1	1	1111-2254-01	Front axle			
2	2	1111-1067-02	Bushing			
3	2	1111-1706-01	Clamp			
4	4	9943-0512-16	Screw			
5	1	1111-2343-01	Rear axle			
6	2	1111-1072-01	Clamp rear			
7	4	9947-0616-16	Screw			
8	1	1111-1074-01	Spring-height adjus			
9	1	1111-2444-02	Lever			
10	1	9997-0612-16	Screw			
11	1	9739-0631-22	Nut			
12	1	1111-2264-01	Tension rod			
13	2	9675-0011-00	Starlock			
14	1	9836-9520-12	Screw			
15	6	9943-0612-16	Screw			
16	4	9699-0037-02	Washer			
17	2	1111-2141-01	Cover plate			
18	4	1111-2183-01	Spring			
19	2	1111-2108-01	Cover plate			
20B	2	1111-2345-01	Rear wheel			
20F	2	1111-2346-01	Wheel w/o bearing			
21	8	9549-0001-00	Ball bearing			
22	6	9699-0100-02	Washer			
23	4	1111-2077-01	Hub cap			
24	2	1111-1638-01	Washer			
25	2	1111-1016-01	Locking handle			
26	2	9595-0235-00	Locating pin			
27	2	1111-1087-02	Tensioning rod			
28	2	9739-0831-22	Nut			
29	4	9942-0816-16	Screw			
30	2	1111-1078-01	Handle attachment			
31	2	1111-1019-01	Adjusting plate			
32	2	9997-0816-16	Screw			
33	2	9747-0831-02	Lock nut			
34	2	1111-0035-01	.Locking knob			
34	1	1111-9030-02	Handle bolt kit			
35	2	1111-0178-00	.Reinforcement			
36	2	9699-0025-02	.Washer			
37	2	9899-3551-12	.Screw			
38	1	1111-2018-01	Cable holder			
39	1	9836-9216-12	Screw			
40	1	1111-1076-01	Handle-lower part			
41	1	1111-2003-01	Handlebar			
42	8	9841-0410-16	Screw			
45	2	1111-2109-01	Gear ring			
46	2	1111-2250-01	Spacer			
47	1	1111-2445-01	Grip			
48	1	1111-2365-02	Gas control			
71	2	1111-2083-02	Gear wheel			
72	2	1111-2382-01	Pin			
73	2	1111-1456-01	Washer			
75	1	1111-2010-01	Attachment plate			
76	1	9849-7909-16	Screw			
77	1	1111-1197-03	Control cable			
78	1	9739-0631-22	Nut			
79	1	1482-0160-01	Spring			
80	1	1111-1998-01	Control handle			
81	2	9948-0645-16	Screw			
82	2	9799-0631-02	Nut			