



## Section: GARDEN BATTERY ELECTRICAL SYSTEM

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2341					
1	1	1134-3156-01	Switch (black)			
2	1	9400-0105-02	Transmission switch			
3	1	9695-0011-00	Washer			
4	2	1134-3132-01	Cable holder			
5	1	1134-3208-01	Switch			
6	1	9847-8025-16	Screw			
7	4	1134-3203-01	Grommet			
8	1	1134-1814-01	Starter switch assy			
9	1	1134-2853-01	.Washer			
10	1	1134-2852-01	.Nut			
11	1	1134-2848-01	.Ignition key			
15	5	9997-0820-16	Screw			
16	5	9739-0831-22	Nut			
17	1	1134-3477-01	Cover			
18	1	1134-3501-01	Rubber strip			
19	2	9942-0512-16	Screw			
20	1	1134-3476-01	Console			
25	2	1134-2871-02	Relay			
26	8	9849-8009-16	Screw			
27	1	1134-2962-01	Solenoid assy			
28	2	9794-5131-02	Nut			
29	2	1134-3478-01	Relay			
30	1	1134-3487-01	Resistance wire			
31	1	1134-3504-01	Tin plate			
32	1	1134-3503-01	Fuse holder			
33	1	1134-3502-01	Fuse		150A	
34	2	9948-0320-16	Screw			
35	2	9747-0331-02	Nut			
36	1	1134-3488-01	Cable			
37	1	1134-3509-01	Cable			
38	1	1134-3542-01	Cable assy			
39	1	1134-3528-01	Cable harness			
40	3	9579-0003-00	Cable holder			