



Section: JB921 CHAIN CASE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1129					
400	1	1482-0248-01	Plastic plug			
401	1	1482-0554-01	Bushing			
402	1	9997-0620-16	Screw			
403	1	9683-0025-02	Lock washer			
404	1	9997-0620-16	Screw			
405	1	9683-0025-02	Lock washer			
406	1	1482-0308-01	Cover			
407	1	1482-0443-01	Gasket			
408	1	1482-0587-01	Selfadh.clamp			
409	1	1482-0653-01	Chain case assy-yel			
410	1	1482-0485-01	.Needle bearing			
411	1	1482-0214-01	.Oil-seal			
412	1	9699-0028-02	.Flat washer			
413	1	9939-0860-12	.Screw			
414	1	9699-0028-02	.Flat washer			
415	1	9939-0860-12	.Screw			
416	1	1482-0458-01	.Seal			
417	1	1482-0459-01	.Lock ring			
418	1	9549-0017-00	.Ball bearing			
419	1	1482-0481-01	.Spacer			
420	1	1489-0412-01	.Pin			
421	1	9594-0055-00	.Locating pin			
422	1	1482-0486-01	.Shaft w. gear			
423	1	1482-0482-01	.Spacer			
424	1	9549-0017-00	.Ball bearing			
425	1	1482-0459-01	.Lock ring			
426	1	1482-0458-01	.Seal			
427	1	1482-0450-01	.Chain-top			
428	1	1482-0473-01	.Needle bearing			
429	1	1482-0452-01	.Spacer			
430	1	1482-0451-01	.Sprocket			
431	1	9660-0200-00	.Spacer			
432	1	1482-0473-01	.Needle bearing			
433	1	9747-0831-02	.Lock nut			
434	1	9699-0028-02	.Flat washer			
435	1	1482-0454-01	.Chain-middle			
436	1	1482-0480-01	.Oil drain plug			
437	1	1482-0479-01	.Gasket			
438	1	1482-0473-01	.Needle bearing			
439	1	1482-0452-01	.Spacer			
440	1	9589-1002-00	.Sprocket			
441	1	9660-0200-00	.Spacer			
442	1	1482-0473-01	.Needle bearing			
443	1	9699-0025-02	.Washer			
444	1	9747-0831-02	.Lock nut			
445	1	1482-0547-01	.Chain-lower			
446	1	9915-1020-15	.Screw			
447	1	9589-1003-00	.Sprocket			
448	1	1482-0048-01	.Shaft			
449	1	1482-0485-01	.Needle bearing			
450	1	1482-0214-01	.Oil-seal			
999	1	1482-0536-01	Gear case oil (0.5		Texaco Multifak	