



STIGA
617
SPARE PARTS

Section: 522 HANDLE CONTROLS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2823					
1	2	1812-0513-01	Retainer			
2	1	1812-0933-01	Clutch handle-RH			
3	1	1812-0934-01	Clutch handle rod			
4	1	1812-0932-01	Clutch handle-LH			
5	2	1812-0946-01	Cable pivot plate			
6	1	1812-0879-01	Handle-upper			
7	2	1812-0248-01	Control wire			
8	1	1812-1183-01	Retainer cap			
9	3	9699-0029-02	Flat washer			
10	1	1812-1168-01	Handle			
11	1	1812-1339-01	Crank			
12	1	1812-0203-01	Grommet			
13	1	1812-0394-01	Eyebolt			
14	3	9743-3721-32	Nut			
15	1	9988-3651-12	Screw			
16	2	1812-1171-01	Washer			
17	2	9743-3521-32	Nut			
18	1	1812-0254-01	Spring			
19	5	9795-3631-02	Nut			
20	2	9683-0035-02	Lock washer			
21	1	1812-1323-01	Handle-lower			
22	2	9743-3621-32	Nut			
23	4	9988-3619-16	Screw			
24	1	1812-1335-01	Chute rotate worm			
25	1	1812-1316-01	Universal pin			
26	1	1812-1317-01	Universal pivot blo			
27	1	1812-1318-01	Clevis pin			
28	1	9599-0033-00	Split pin			
29	5	9683-0030-02	Lock washer			
30	2	1812-1310-01	Screw			
31	1	1812-1334-01	Bracket chute worm			
32	4	9699-0026-02	Flat washer			
33	1	9988-3645-16	Screw			
34	5	9699-0028-02	Flat washer			
35	1	1812-1322-01	Shifter bracket			
36	1	1812-1324-01	Shifter rod			
37	1	1812-1325-01	Shifter lever sprin			
38	6	9988-3519-16	Screw			
39	4	9727-3541-22	Nut			
40	1	1812-1308-01	Shift knob			
41	1	9743-3921-32	Nut			
42	1	1812-1210-01	Spring			
43	1	9988-3751-12	Screw			
44	1	9743-3721-32	Nut			
45	6	9743-3521-32	Nut			
46	4	9988-3519-16	Screw			
47	1	1812-1331-01	Control panel			