



Section: 320 BELT TRANSMISSION CHASSIS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1211					
11	2	9988-3619-16	Screw			
12	2	9683-0030-02	Lock washer			
20	1	1133-0998-01	Brake pad			
21	1	9988-3619-16	Screw			
22	1	9683-0030-02	Lock washer			
23	1	9988-3516-16	Screw			
24	1	9743-3521-32	Nut			
25	1	1133-0976-01	Belt guide			
26	3	9699-0028-02	Flat washer			
27	1	9683-0030-02	Lock washer			
28	1	9988-3625-16	Screw			
30	1	1133-0979-01	Idler pivot arm			
31	1	9988-3613-16	Screw			
32	1	9743-3621-32	Nut			
33	1	1133-0983-01	Extension spring			
40	1	1133-0991-01	Idler arm			
41	1	9988-3613-16	Screw			
42	1	9743-3621-32	Nut			
45	1	1133-0936-01	Idler pulley			
46	1	9988-3738-12	Screw			
47	1	9743-3721-32	Nut			
50	1	9988-3538-12	Screw			
51	1	9699-0026-02	Flat washer			
52	1	1133-0978-01	Belt roller			
53	1	9743-3521-32	Nut			
60	1	1133-0974-01	Clutch linkage rod			
61	1	9699-0072-02	Washer			
62	1	9599-0020-02	Split pin			
70	1	1133-0935-01	Engine pulley			
71	1	1133-0931-01	Wdrf-key			
72	1	1132-0689-01	Screw			
75	1	1133-0990-01	Poly-v belt			
80	1	1133-0997-01	Frame side-R.H.			
81	1	1133-0996-01	Frame side-L.H.			
90	1	1133-0963-01	Frame support chann			
91	4	9988-3551-12	Screw			
92	4	9743-3521-32	Nut			
100	1	1133-0941-01	Fuel tank bracket			
101	2	9988-3519-16	Screw			
102	2	9743-3521-32	Nut			
110	1	1133-0954-01	Fuel tank			
111	4	1133-0939-01	Screw			
112	1	1133-0929-01	Fuel tank cap			
113	1	1133-0992-01	Fuel line tubing			
114	2	1133-0070-01	Fuel line clamp			
115	2	1133-1001-01	Bolting support pla			