



## Section: DINO

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1113	1137				
5	1	1	1111-9502-01	Blade		
6	1	1	9696-0011-01	Washer		
7	1	1	9987-5232-16	Bolt		
10	1	1	1111-9023-00	Blade holder		
11	1	1	9600-0014-00	.Key		
12		4	1111-2656-01	Wheel		
12	4		1111-2784-01	Wheel assy		
13	1		1111-9047-01	.Ball bearing kit		
14	1		1111-1184-01	..Bearing cone		
15	4		1111-1138-01	Spring		
16	4		1111-2785-01	Wheel cover		
18	1	1	1111-9035-01	Height adjust kit		
18	2	2	1111-1589-02	.Height adj.spring-		
19	2	2	1111-1589-01	.Height adj.spring-		
20	4	4	9675-0017-02	..Lock washer		
20	1	1	1111-9042-01	.Wheel lock kit		
22	2	2	1111-1590-01	Wheel axle		
23		4	1111-1335-02	Hub cap		
24	4		1111-1705-03	Hub cap		
26	3		9997-0830-16	Screw	L=30 mm	
26		3	9997-0835-12	Screw	L=35 mm	
27		3	9678-0009-02	Lock washer		
27	3		9683-0030-02	Lock washer		
28	3	3	9799-0831-02	Nut		
31	1	1	1111-3017-01	Handlebar clamp		
32	1	1	1111-1532-01	Pivot rod		
33	2	2	9670-0203-00	Lock washer		
34	2	2	1111-0035-01	.Locking knob		
34	2	2	1111-9030-02	Handle bolt kit		
35	1	1	1111-3062-01	Eyelink		
36	2	2	9699-0025-02	.Washer		
37	1	1	9899-3551-12	.Screw		
38	1	1	1111-2018-01	Cable holder		
39	1	1	9836-9216-12	Screw		
40	1	1	1111-3018-01	Handlebar-lower par		
41	1	1	1111-2957-01	Handle-upper		
45	4	4	1111-1593-01	Washer		
46	1	1	1111-3061-01	Chassis-yellow		
48		1	1111-2367-04	Gas control		
50	1	2	9747-0631-02	Lock nut		
51		1	9948-0645-16	Screw		
52	1	1	1111-1129-02	Ejection shield-yel		
53	2	2	9997-0612-16	Screw		
54	2	2	9747-0631-02	Lock nut		
55	2	2	9699-0025-02	Washer		
56	1	1	1111-2953-01	Control handle		
57	1		1111-2968-05	Engine brake cable		
57		1	1111-2968-06	Engine brake cable		
58	1		9948-0640-16	Screw	L=40 mm	
58		1	9948-0660-16	Screw	L=60 mm	
60	1	1	1111-2969-01	Cable attachment		
67	1	1	1111-2375-01	Spring		
99	1	1	1111-2893-01	Decal kit		