



## Section: TOTNADO 90S-900 PRO TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	4215	4318				
1	1	1	1111-2580-01		Front axle	
2	2	2	1111-2595-02		Bushing	
3	2	2	9699-0115-02		Washer	
4	4		1111-1456-01		Washer	
5		2	1111-2108-01		Cover plate	
6		4	9943-0610-16		Screw	
7		2	1111-2083-01		Gear wheel	
8	2	2	1111-2183-01		Spring	
9	4	4	9699-0100-02		Washer	
10	4	4	9943-0612-16		Screw	
11		8	9841-0410-16		Screw	
15		2	1111-2109-01		Gear ring	
16		2	1111-2346-01		Wheel w/o bearing	
17		4	9549-0001-00		Ball bearing	
18		2	1111-2077-01		Hub cap	
20	2		1111-2664-01		Hub cap	
21	2		1111-2676-01		Wheel cup	
22	2		1111-2665-01		Wheel assy	
23	1		1111-9047-01		.Ball bearing kit	
24	2		1111-1184-01		..Bearing cone	
25	2		1111-2600-02		Gear wheel	
26	2		1111-2561-01		Cover plate	
28	2	2	9836-9516-12		Screw	
29	2	2	1111-2922-01		Front support	
30	1	1	1111-2568-01		Transm.cover-yellow	
31	2	2	9848-8013-16		Screw	
35	1	1	1111-3056-01		Transmission assy	
38	2	2	1111-2382-01		Pin	
40	1	1	1151-0128-13		Drive belt	
43	1	1	1111-3060-01		Spring	
45		1	1111-2821-02		Engine pulley	
45	1		1111-2915-01		Engine belt pulley	
46	1	1	9910-0612-16		Set screw	
49	1	1	9403-0115-70		Cover plug	
51	1	2	9579-0008-00		Cable holder	
57	1	1	1111-2018-01		Cable holder	
58	1	1	9836-9216-12		Screw	
59	1	1	1111-2965-02		Clutch control	
60	2	2	9747-0631-02		Lock nut	
61	1	1	9836-9512-12		Screw	
62	2	2	9948-0655-16		Screw	
63	1	1	1111-1987-02		Control knob-black	