



## Section: 928e-1130e DRIVE TRAIN

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2837	2844				
190	1	1	1812-1218-01		Traction shaft	
191	2	2	1812-0328-01		Bushing	
192	2	2	9599-0073-02		Split pin	
193	1	1	1812-0364-01		Spring	
195	1	1	1812-1217-01		Traction spring lev	
196	1	1	9988-3516-16		Screw	
198	1	1	1812-0812-01		Locking nut	
210	1	1	1812-1269-01		Friction disc	
211	1	1	1812-1425-01		Grease zerk	
215	1	1	1812-1262-01		Traction hex shaft	
216	1	1	1812-0450-01		Bearing	
217	2	2	9699-0038-02		Flat washer	
221	1	1	1812-0402-01		Retaining ring	
222	1	1	1812-1238-01		Washer	
223	2	2	1812-1383-01		Ball bearing	
224	1	1	1812-1239-01		Square key	
225	1	1	1812-1236-01		Traction pulley	
226	1	1	1812-1237-01		Wave washer	
227	1	1	1812-1190-01		Flat washer	
228	1	1	9683-0025-02		Lock washer	
229	1	1	9988-3519-16		Screw	
230	1	1	1812-1200-01		Bearing retainer	
231	2	2	1812-0385-01		Screw	
232	2	2	9683-0030-02		Lock washer	
233	1	1	1812-1207-01		Ball bearing	
235	1	1	1812-1204-01		Washer	
240	1	1	1812-1312-01		Hex shaft	
243	1	1	1812-1164-01		Retainer ring	
244	2	2	9699-0038-02		Flat washer	
245	1	1	1812-1313-01		Trunion bearing	
246	1	1	1812-9002-01		Friction disc	
247	3	3	9988-3516-16		Screw	
249	3	3	9795-3531-02		Nut	
250	1	1	1812-1204-01		Washer	
255	1	1	1812-1200-01		Bearing retainer	
256	2	2	1812-0385-01		Screw	
257	2	2	9683-0030-02		Lock washer	
258	1	1	1812-1207-01		Ball bearing	
270	1	1	1812-1200-01		Bearing retainer	
271	2	2	1812-0385-01		Screw	
272	1	1	1812-1207-01		Ball bearing	
275	1	1	1812-1256-01		Jack shaft	
276	1	1	1812-1200-01		Bearing retainer	
277	2	2	1812-0385-01		Screw	
278	1	1	1812-1209-01		Chain	
279	1	1	1812-1207-01		Ball bearing	