



STIGA
842
SPARE PARTS

Section: COLLECTOR 48S-48SE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	4833	4932				
1	1	1	1117-1346-01	Handlebar-upper par		
2	2	2	9799-0531-02	Nut		
3	3	3	9699-0024-02	Flat washer		
4	2	2	1117-1278-01	Strip		
5	1	1	1117-1275-01	Throttle control		
6	1	1	1117-1276-01	Control handle		
7	1	1	1117-1276-01	Control handle		
8	1		1117-1284-01	Grip		
8		1	1117-1290-01	Grip		
9	2	1	9799-0631-02	Nut		
10	1	1	1117-1277-01	Clutch cable	Inkl. pos 50	
11	2	2	1117-1241-01	Bolt		
12		1	1117-1292-01	Front weight		
13	1	1	1117-1258-01	Knob		
14	3	3	1117-1280-01	Knob		
15	8	8	9799-0831-02	Nut		
16	2	2	1117-1281-01	Bushing		
17	1	1	1117-1347-01	Handlebar-lower par		
18	1	1	1117-1246-01	Knob		
19	1	1	1117-1282-01	Frame-grass bag		
20	1	1	1117-1283-01	Grass bag		
21	1	1	1117-1117-01	.Pulley		
22	1	1	1117-1230-01	Blade mount		
23	1	1	1117-1298-01	Hook		
24	1	1	1117-1261-01	Transmission	Inkl. pos 21, 69	
25	1	1	1117-1338-01	Rear axle		
26		1	9898-0825-16	Screw		
27	2	2	1117-1175-01	Washer		
28	4	4	1117-1251-01	Ball bearing		
29	2	2	1117-1333-01	Wheel		
30	2	2	1117-1253-01	Wheel cover		
31	4	4	9836-9516-12	Screw		
32	1	1	9997-0512-16	Screw		
33	2	2	9747-0531-02	Nut		
34	1	1	1117-1306-01	Rear attachment		
35	2	2	1117-1307-01	Adaptor cover		
36	1	1	1117-1289-01	Funnel		
37	1	1	1117-1336-01	Handle support-L.H.		
38	1	1	1117-1239-01	Knob		
39	1	1	1117-1332-01	Height adj.handle		
40	1	1	1117-1242-01	Bolt		
41	1	1	9696-0013-01	Bowed washer		
42	4	4	9699-0062-02	Flat washer		
43	3	3	9678-0009-02	Lock washer		
44	1	1	1117-1155-02	Flap holder-black		
45	1		1117-1339-01	Deck		
45		1	1117-1348-01	Deck		
46	1	1	1117-1331-01	Connection rod		
47	1	1	9683-0040-02	Lock washer		
48	1	1	1117-1263-01	Clips		
49	1	1	1117-1337-01	Handle support-R.H.		
50	1	1	1134-3203-04	.Cable protector		
51	1	1	1117-1330-01	Front axle		
52	2	2	1117-1238-01	Bushing		
53	4	4	9699-0028-02	Flat washer		
54	4	4	9997-0816-16	Screw		
55	2	2	1117-1176-01	Wheel bolt		
56	2	2	9694-0003-00	Washer		
57	2	2	1117-1248-01	Wheel		
58	2	3	9699-0078-02	Washer		
59	4	5	9747-0831-02	Lock nut		
60	1	1	9987-5251-12	Screw		
61	1	1	1117-1262-01	Spring		
62	1	1	1117-1235-01	Blade		
63	2	2	9997-0614-16	Screw		
64	4	4	1117-1252-01	Screw		

Section: COLLECTOR 48S-48SE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	4833	4932				
65	1	1	9600-0014-00	Key		
66	1	1	1117-1296-01	Transmission cover		
67	1	1	9997-0840-16	Screw		
68	1	1	1117-1250-01	V-belt		
69	1	1	1111-2382-01	.Pin		
70	2	2	9591-0011-00	Pin		
71	2	2	1117-1083-01	Safety ring		
72	4	4	1117-1121-01	Bushing		
73	2	2	1117-1211-01	Key		
74	2	2	1117-1115-01	Toothed wheel		
75	2	2	1117-1240-01	Bushing		
76	2	2	9549-0043-00	Ball bearing		
77	1	1	1117-1327-01	Battery cover		
78		1	1134-2848-01	Ignition key		
79	1	1	1117-1328-01	Throttle cover		
80		1	9400-0186-00	Starting switch ass		
81		1	1117-1287-01	Battery		
82	2	2	1117-1279-01	Knob		
83		1	1117-1291-01	Harness		
84		1	1117-1288-01	Battery charger		
85	1	1	1117-1237-01	Spring		
86	1	1	1117-1329-01	Battery box		
87	1	1	1117-1293-01	Handle		
88	1	1	1117-1297-01	Bushing		
89	2	2	1117-1244-01	Hub cap		
90	2	2	1117-1249-01	Hub cap		
91	1	1	9997-0830-16	Screw		
92	2	2	9997-0512-16	Screw		
93	1	1	1117-1143-01	Shaft		
94	1	1	1117-1156-02	Rear flap-black		
95	2	2	1117-1294-01	Screw		
96	2	2	1117-1126-01	Spring-rear flap		
97	2	2	1117-1295-01	Handle cap		
98	1	1	1117-1285-01	Engine brake cable		
99	1	1	1117-1243-01	Disc washer		
100	3	3	9699-0035-02	Flat washer		
101	2	2	9747-0421-02	Lock nut		
102	2	1	9898-0616-16	Screw		
103	1	1	9898-0635-12	Screw		
104	1		1117-1286-01	Cable holder		