



Section: 1130e GEAR CASE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2844					
300	1	1812-0228-01	Gear case-RH			
301	1	1812-0227-01	Gear case-LH			
303	7	9987-5125-16	Screw			
304	7	9743-5121-02	Nut			
306	1	1812-0346-01	Oil plug			
310	2	1812-0344-01	Ring			
311	2	1812-0343-01	Bearing			
312	2	1812-0345-01	Washer			
313	1	1812-1441-01	Auger shaft			
314	1	1812-0226-01	Gasket			
315	1	1812-0335-01	Worm gear			
316	2	1812-0409-01	Woodruffkey			
320	1	1812-0341-01	Ring			
321	1	1812-1259-01	Flange bearing			
322	1	1812-0857-01	Thrust washer			
323	1	1812-0285-01	Needle bearing			
324	1	1812-0857-01	Thrust washer			
326	1	1812-0307-01	Key			
327	1	1812-0336-01	Gear			
330	1	1812-0297-01	Bearing			
340	1	1812-1432-01	Impeller			
341	1	1812-1295-01	Impeller shaft			
342	2	9988-3557-12	Screw			
343	2	9699-0026-02	Flat washer			
344	2	1812-0812-01	Locking nut			
350	1	1812-0663-01	Gear box brace			
351	1	9987-5145-12	Screw			
352	1	9743-5121-02	Nut			
355	1	9988-3632-12	Screw			
356	2	9699-0028-02	Flat washer			
357	1	9683-0030-02	Lock washer			
358	1	9795-3631-02	Nut			