



Section: PFS FRONT P.T.O. ART.NO 14-1970-11

| Pos. | Quantity | Spare part No | Description | Kit | Notes | New |
|------|----------|---------------|--------------------|-----|-------|-----|
| | | 1970 | | | | |
| 1 | 1 | 1489-0471-01 | Clutch cable | | | |
| 2 | 1 | 9997-0625-16 | .Screw | | | |
| 3 | 1 | 1482-0572-01 | .Screw | | | |
| 4 | 1 | 1482-0679-01 | .Clutch handle | | | |
| 5 | 1 | 1482-0636-01 | .Catch-R.H. | | | |
| 6 | 1 | 1482-0637-01 | .Catch-L.H. | | | |
| 7 | 1 | 1482-0675-01 | .Bracket | | | |
| 8 | 1 | 9915-0810-15 | .Set screw | | | |
| 9 | 1 | 9747-0631-02 | .Lock nut | | | |
| 10 | 1 | 1482-0592-01 | .Change over lever | | | |
| 11 | 1 | 1482-0572-01 | .Screw | | | |
| 13 | 1 | 9942-0620-16 | Screw | | | |
| 14 | 1 | 1489-0472-01 | Dust cap | | | |
| 15 | 1 | 9650-0016-04 | Lock ring | | | |
| 16 | 1 | 9650-0010-04 | Lock ring | | | |
| 17 | 1 | 1489-0475-01 | Clamp | | | |
| 18 | 1 | 1489-0475-01 | Clamp | | | |
| 19 | 1 | 1489-0476-01 | Spring | | | |
| 20 | 1 | 1489-0477-01 | Tension arm | | | |
| 21 | 1 | 1489-0478-01 | Angle | | | |
| 22 | 1 | 1489-0479-01 | Bushing | | | |
| 23 | 1 | 1489-0496-01 | Tension roller | | | |
| 24 | 1 | 1489-0497-01 | Washer | | | |
| 25 | 1 | 1489-0180-01 | Screw | | | |
| 26 | 1 | 1489-0473-01 | O-ring | | | |
| 27 | 1 | 1489-0480-01 | Belt guard | | | |
| 28 | 1 | 1489-0473-01 | O-ring | | | |
| 29 | 1 | 9650-0038-04 | Lock ring | | | |
| 30 | 1 | 9594-0055-00 | Locating pin | | | |
| 31 | 1 | 1489-0481-01 | Clutch plate | | | |
| 32 | 1 | 1489-0482-01 | Reducing pipe | | | |
| 33 | 1 | 9549-0003-00 | Ball bearing | | | |
| 34 | 1 | 1489-0483-01 | Axle w.key slot | | | |
| 35 | 1 | 1482-0821-01 | Woodruff key | | | |
| 36 | 1 | 1489-0485-01 | Spacer tube | | | |
| 37 | 1 | 9549-0003-00 | Ball bearing | | | |
| 38 | 1 | 1482-0459-01 | Lock ring | | | |
| 39 | 1 | 1489-0494-01 | Belt pulley | | | |
| 40 | 1 | 1489-0486-01 | Washer | | | |
| 41 | 1 | 9924-0620-19 | Screw | | | |
| 42 | 1 | 1489-0495-01 | Belt | | | |
| 43 | 1 | 1489-0487-01 | Tipping plate | | | |
| 44 | 1 | 9747-0831-02 | Lock nut | | | |
| 45 | 1 | 9747-0631-02 | Lock nut | | | |
| 46 | 1 | 9747-0631-02 | Lock nut | | | |
| 47 | 1 | 9747-0631-02 | Lock nut | | | |
| 48 | 1 | 9747-0631-02 | Lock nut | | | |
| 49 | 1 | 1489-0488-01 | Spacer tube | | | |
| 50 | 1 | 9747-0831-02 | Lock nut | | | |
| 51 | 1 | 1489-0489-01 | Console | | | |
| 52 | 1 | 9898-0816-16 | Screw | | | |
| 53 | 1 | 1482-0817-01 | Screw | | | |
| 54 | 1 | 9898-0816-16 | Screw | | | |
| 55 | 1 | 9747-0831-02 | Lock nut | | | |
| 56 | 1 | 9997-0815-02 | Screw | | | |
| 57 | 1 | 9997-1230-16 | Screw | | | |
| 58 | 1 | 9799-0531-02 | Nut | | | |
| 59 | 1 | 9997-1230-16 | Screw | | | |
| 60 | 1 | 9598-0002-02 | Pin lock | | | |
| 61 | 1 | 1489-0490-01 | Dust cap | | | |
| 62 | 1 | 1482-0092-00 | Pin | | | |
| 63 | 1 | 9683-0030-02 | Lock washer | | | |
| 64 | 1 | 9799-0831-02 | Nut | | | |
| 65 | 1 | 9799-0831-02 | Nut | | | |
| 66 | 1 | 9683-0030-02 | Lock washer | | | |
| 67 | 1 | 9799-0831-02 | Nut | | | |

Section: PFS FRONT P.T.O. ART.NO 14-1970-11

| Pos. | Quantity | Spare part No | Description | Kit | Notes | New |
|------|----------|---------------|-------------|-----|-------|-----|
|------|----------|---------------|-------------|-----|-------|-----|

1970

| | | | | | | |
|----|---|--------------|--------------------|--|--|--|
| 68 | 1 | 9683-0030-02 | Lock washer | | | |
| 69 | 1 | 9699-0037-02 | Washer | | | |
| 70 | 1 | 9683-0055-02 | Lock washer | | | |
| 71 | 1 | 9799-1231-02 | Nut | | | |
| 72 | 1 | 9699-0037-02 | Washer | | | |
| 73 | 1 | 9799-1231-02 | Nut | | | |
| 74 | 1 | 9683-0055-02 | Lock washer | | | |
| 75 | 1 | 9997-0855-12 | Screw | | | |
| 76 | 1 | 9997-0855-12 | Screw | | | |
| 77 | 1 | 9997-0855-12 | Screw | | | |
| 78 | 1 | 1489-0453-01 | Mounting bracket | | | |
| 79 | 1 | 1489-0491-01 | Engine belt pulley | | | |

test