



STIGA
914
SPARE PARTS

Section: PARK PRO 16-PRO 18 ENGINE (w. catalytic conv.) BRAKE

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
		1818					
	1458	1448					
1	1	1	1134-2878-01	Fan cover			
2	4	4	9997-0512-16	Screw			
3	4	4	9699-0099-02	Washer			
4	1	1	1134-3355-01	Oil drain pipe assy			
5	1	1	1134-0997-01	.Fibre gasket			
6	1	1	1134-0995-01	.Plug			
7	1	1	9404-0020-00	.O-ring			
8	1	1	9997-0840-16	Screw		L = 40 mm	
9	2	2	9997-0840-16	Screw		L = 40 mm	
10	1	1	9997-0870-16	Screw		L = 70 mm	
11	1	1	1134-0041-02	Idler wheel bush			
12	4	4	9739-0831-22	Nut			
13	1	1	1134-3857-01	Exhaust pipe			
15	1	1	1134-3864-01	Muffler			
16	1	1	9959-0816-16	Screw			
17	1	1	9739-0831-22	Nut			
18	1	1	9578-0011-00	Clamp			
19	1		9600-0250-00	Key			
19		1	9600-0251-00	Key			
20	2	2	9579-0003-00	Cable holder			
27	1	1	9747-0631-02	Lock nut			
28	1	1	1134-3377-01	Control rod			
29	1	1	9675-0008-02	Locking washer			
30	1	1	1134-1889-01	Eyebolt			
31	1	1	1134-1023-00	Spring			
32	2	2	1134-3456-01	Bushing			
33	1	1	9747-0631-02	Lock nut			
41	1	1	1134-3593-01	Fuel tank			
42	1	1	1134-2877-02	Fuel tank cap			
43	2	2	1134-2941-01	Protection strip			
44	1	1	9997-0812-02	Screw			
45	1	1	9747-0831-02	Lock nut			
46	1	1	1134-3224-01	Fuel shut-off valve			
47	1	1	1134-3225-01	Grommet			
48	1	1	1134-2975-04	Fuel line		L = 710 mm	
49	2	2	1134-3499-01	Hose clamp			
58	1	1	1134-3450-02	Pedal assy		Vä sida/L.H. side	
59	1	1	1134-9024-01	.Bearing		Sats 4 st/kit of 4	
61	1	1	1131-1506-00	Spring			
62	1	1	1134-3584-01	Brake/clutch wire			
63	1	1	1134-3387-01	Attachment			
64	1	1	9959-0816-16	Screw			
65	1	1	9739-0831-22	Nut			
66	1	1	1134-1184-02	Bracket			
67	1	1	1134-2151-02	Stop			
68	1	1	1131-1497-01	Spring			
69	1	1	1134-0245-00	Shoulder screw			
70	1	1	9739-0831-22	Nut			
78	1	1	1134-1975-12	Throttle control			
79	1	1	9403-0035-10	Handle			
80	2	2	9849-8013-16	Screw			
81	1	1	1134-2872-01	Choke control			
82	1	1	9699-0028-02	Flat washer		8.4 x 16 x 1.5 mm	
83	1	1	9699-0062-02	Flat washer		8.4 x 22 x 1.5 mm	
90	1	1	1134-3863-01	Air valve			
91	1	1	1134-3856-01	Hose			
92	1	1	1134-3855-01	Filter			
93	1	1	1134-3889-01	Seal ring			
94	1	1	1134-3860-01	Bracket			
95		2	9942-0816-16	Screw			
96	1	1	9959-0816-16	Screw			
97	1	1	9739-0831-22	Nut			
98	1	1	1134-3868-01	Heat guard			
99	2	2	9959-0820-16	Screw			
100	2	2	9739-0831-22	Nut			