



Section: PARK PRO 18 POWER TAKE-OFF

| Pos. | Quantity | Spare part No | Description | Kit | Notes | New |
|------|----------|---------------|---------------------|-----|----------------|-----|
| | 1818 | | | | | |
| | 1448 | | | | | |
| 1 | 2 | 9739-0831-22 | Nut | | | |
| 2 | 1 | 1134-3638-01 | Electric pto-clutch | | | |
| 3 | 1 | 1134-3712-01 | Support stay | | | |
| 4 | 2 | 9959-0820-16 | Screw | | | |
| 5 | 2 | 9739-0831-22 | Nut | | | |
| 8 | 1 | 1134-2871-03 | Relay | | | |
| 9 | 1 | 9997-0520-16 | Screw | | | |
| 10 | 1 | 9739-0531-22 | Nut | | | |
| 23 | 1 | 1134-3379-01 | Spring | | | |
| 25 | 1 | 1134-1565-01 | Spacer | | | |
| 27 | 1 | 1134-3658-01 | Tensioning arm | | | |
| 28 | 1 | 9997-1040-12 | Screw | | | |
| 30 | 1 | 1134-3663-01 | Tension wheel | | | |
| 31 | 1 | 9739-1031-22 | Nut | | | |
| 34 | 1 | 9997-0850-16 | Screw | | | |
| 35 | 1 | 9699-0056-02 | Flat washer | | | |
| 36 | 1 | 1134-0052-00 | Bearing spacer | | | |
| 37 | 1 | 1134-1769-02 | Belt pulley assy | | | |
| 38 | 2 | 9651-0040-04 | .Retaining ring | | | |
| 40 | 1 | 1134-0051-09 | .Spacer | | | |
| 41 | 2 | 9549-0019-00 | .Ball bearing | | | |
| 43 | 1 | 9699-0109-02 | Flat washer | | | |
| 44 | 1 | 1134-0222-00 | Washer | | | |
| 45 | 1 | 9959-1025-16 | Screw | | | |
| 46 | 1 | 1134-1730-01 | Tension wheel arm | | | |
| 47 | 2 | 1134-1888-01 | Spacer | | | |
| 48 | 1 | 1134-1770-01 | Tension roller | | | |
| 52 | 1 | 1134-1893-01 | Spring attachment | | | |
| 53 | 2 | 9699-0062-02 | Flat washer | | | |
| 54 | 1 | 9997-0865-12 | Screw | | | |
| 55 | 1 | 1134-1322-01 | Spring | | | |
| 56 | 1 | 9987-5357-12 | Screw | | | |
| 57 | 1 | 1134-9047-01 | V-belt | | = 9585-0088-00 | |
| 60 | 1 | 1134-3654-01 | Finger guard | | | |
| 61 | 2 | 9739-0631-22 | Nut | | | |
| 62 | 2 | 9959-0612-16 | Screw | | | |